


Package contents

- Low wattage travel converter/adapter
- Quick Setup Guide

Features



Before using your new product, please read these instructions to prevent any damage.



Check out these important safety instructions to keep yourself and your devices safe.

- Read and review these instructions before using the converter/adapter.
- Before using the converter/adapter, check the product you intend to connect to the converter/adapter for the manufacturer's voltage and wattage rating, which should be located on the product.
- **Caution:** Adapters alone do not convert voltage. To avoid damaging your device, select **CONVERTER** when necessary.
- **DO NOT** use this product with hair dryers, curling irons, or other high-wattage devices.
- Do not leave the converter/adapter in the power outlet when not in use. Do not continue to use the converter/adapter if it is not working properly, has been damaged, or dropped in water.
- Check your appliance label to see if it requires less than 2.5A.
- No grounding. This product is for use with unearthened or double-insulated appliance only.

Warning: This product is intended for adult use. This product is NOT intended for use by unsupervised children. Choose proper settings and plug in this product before directly supervising children using devices connected to this product.

Making sure your device is compatible

Warning: Failure to select the correct voltage setting could damage your device. DO NOT use this converter with high-wattage devices, such as hair dryers and curling irons.



- 1 Determine the voltage of the power outlet you want to use. See the table on the next page for common voltages.
- 2 Check the voltage of the device you want to connect to the power outlet.

- 3 Compare the power outlet voltage to your device's voltage.

Note: The voltage of some devices will be a range. If your power outlet voltage is in the range of your device's voltage (for example, a 120-240V device and a 240V power outlet), use ADAPTER mode.

The power outlet voltage is:	Slide the mode switch to:
<ul style="list-style-type: none"> • The same as your device's voltage • In the range of your device's voltage • 100V and your device is 120V 	ADAPTER
<ul style="list-style-type: none"> • Greater than your device's voltage 	CONVERTER
<ul style="list-style-type: none"> • Less than your device's voltage* 	Your device is not compatible. Do NOT use this converter/adapter with your device

*Note: If the power outlet is 100V and your device is 120V, use **ADAPTER** mode.

- 4 Check the wattage of your device.

If you use ADAPTER mode:

Device wattage is:	Instructions:
275W max. at 100-120V 575W max. at 100-240V	You can use this adapter. See "Selecting your plug" for further instructions.
576W or more	Your device is not compatible. Do NOT use this adapter with your device.

If you use CONVERTER mode:

Device wattage is:	Instructions:
0-25W	You can use this converter. See "Selecting your plug" for further instructions.
26W or more	Your device is not compatible. Do NOT use this converter with your device.

Selecting your plug

Find the power outlet you want to connect your device to in the following table, then follow the corresponding instructions to open the plug. Make sure that you only open one plug at a time.

A North America/South America/Japan:

- 1 Slide the plug selector to **USA/AUST/NZ**.
- 2 Slide both side buttons forward to push out the prongs.




B Europe:

- 1 Slide the plug selector to **Europe**.
- 2 Use your finger to pull out and bring down the plug.



C Australia/New Zealand:

- 1 Slide the plug selector to **USA/AUST/NZ**.
- 2 Slide both side buttons forward to push out the prongs, then gently turn each prong inward until they stop.



D UK/Hong Kong:

- 1 Slide the plug selector to **UK**.
- 2 Push in and slide both side buttons forward to push out the top prongs, then use your finger to pull down the middle prong.



Plug types	Outlet types	Location	Voltage
A	Flat parallel	Japan	100V
		Parts of North America and Caribbean	120V
		Parts of South America, Caribbean, and China	240V
B	Round thin pin	Parts of Middle East, Africa, Asia, South America	120V
		Europe, parts of Middle East, Africa, Asia, South America	240V
		Northern Europe	240V
C	Flat angled blades	Australia, New Zealand, and Fiji	240V
D	3-prong blades	Great Britain, Ireland, parts of Africa, Hong Kong, and Singapore	240V

Using your adapter

- 1 Make sure your device is compatible and that you have selected the correct settings before use. Incorrect use could damage your device.
- 2 Connect your device to the adapter outlet, then plug the converter/adapter into a power outlet.

Note: When in converter mode, only use this product for short periods of time (approximately 10-15 minutes).

Troubleshooting

My converter/adapter or device is humming

- It is normal to hear a humming sound from your converter/adapter or device.

My device stopped working

- If your device has a built-in thermostat, it may have shut off prematurely.
- Make sure that you have selected the correct settings.
- Wait for your device to cool down, then resume normal operation.

My device is working slowly

- Some devices may operate slower in foreign countries that use 50 Hz of current (the U.S. operates on 60 Hz).

I don't know my device's voltage or wattage

- Check on your device, its power adapter, or in its manual.
- To calculate wattage, multiple voltage by amps (for example, 100V x 2.5 amps = 250 watts).
- Contact the device's manufacturer.

Specifications

AC power rated for adapter and converter

Converter mode:

Input: 220 - 240V AC, 50Hz
Output: 110 - 120V AC, 25W

Adapter mode:

Input: 100 - 240V AC
Output: 2.5A max.
275W max. at 100-120V
575W max. at 220-240V

One-year limited warranty

Visit www.insigniaproducts.com for details.

Contact Insignia:

For customer service, call 1-877-467-4289 (U.S. and Canada) or 01-800-926-3000 (Mexico)
www.insigniaproducts.com

INSIGNIA is a trademark of Best Buy and its affiliated companies.

Registered in some countries.

Distributed by Best Buy Purchasing, LLC, 7601 Penn Ave South, Richfield, MN 55423 U.S.A.

©2014 Best Buy. All rights reserved.

Made in China

V1 ENGLISH 14-0202

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>