

Stealthbox®

INSTALLATION GUIDE
for the

SB-GM-SLVCRW/10W1v2

1999 - 2006 Chevrolet Silverado / GMC Sierra
Crew Cab



Thank you for choosing a JL Audio Stealthbox® for your automotive sound system.

With proper installation, your new vehicle-specific enclosed subwoofer system will deliver years of listening pleasure.

We strongly recommend that you have your new Stealthbox® installed by your authorized JL Audio dealer. The installation professionals employed by your dealer have the necessary tools and experience to disassemble and reassemble your vehicle properly. Also, keep in mind that your warranty coverage extends to two (2) years if your system is installed or approved by your authorized JL Audio dealer. If you prefer to perform your own installation, please read this installation guide completely before beginning the process.

JL AUDIO®
Ahead of the Curve™

! IMPORTANT


If you choose to perform the installation yourself, it is absolutely vital that the Stealthbox® be properly mounted to the vehicle according to these instructions. Failure to mount the enclosure properly presents two problems:

- 1) The sub-bass performance will suffer due to the movement of the enclosure caused by the force exerted by the woofer(s).
- 2) A loose enclosure presents a serious safety hazard in the event of a collision or sudden deceleration.

INSTALLATION
DIFFICULTY:

5 OUT
OF 5

ESTIMATED TIME:
2-3 HOURS



STEP 1

Lower both sides of the rear seating.

Remove the jack (A), jack tools (B) and the rear window sill plate (C).



STEP 2

With a Phillips screw driver, remove the two screws that secure the passenger's side c-pillar to the rear wall.



STEP 3

Pull off the passenger's side rear door sill plate.

**STEP 4**

With a Phillips screw driver, remove the two screws that secure the driver's side c-pillar to the rear wall.

**STEP 5**

Pull off the driver's side rear door sill plate.


**STEP 6**

Pop the c-pillars off the wall.

Stretch out the seat belts and carefully place both c-pillars into the bed of the truck, so they are out of the way.

**STEP 7**

With a T-45 socket and ratchet, remove both the passenger's side and the driver's side seat belt retracting units.

**STEP 8****Passenger's side:**

Grab the black plastic box(vent column) and pull it towards the front of the truck, until it clears the threaded stud(circled). No mounting hardware secures this vent column to the truck.

After the vent column is free from the threaded stud, lift up and pull the vent column out.

The vent that is mounted to the rear wall, needs to stay in place.

**STEP 9****Driver's side:**

Grab the black plastic box(vent columns) and pull it towards the front of the truck, until it clears the threaded stud(circled). No mounting hardware secures this vent column to the truck.

After the vent column is free from the threaded stud, lift up and pull the vent column out.


The vent that is mounted to the rear wall, needs to stay in place.

**STEP 10**

If the truck is not equipped with the folding floor extensions, go to STEP 13.

Remove the driver's side and the passenger's side folding floor extensions from the mounting bar (circled).

Remove the rear wall carpeting.

**STEP 11**


With cut off wheels or a saw, remove both folding floor extension mounting bars from the rear seat mounting supports.

If you are to use cut off wheels, protect the interior from the sparks. Do not allow the sparks to shower upward. The sparks will cause cosmetic damage to the headliner.

**STEP 12**

With cut off wheels or a saw, remove the four (two are circled) rear wall ledges. These support the folding floor extensions.

Cut as flush to the rear wall as possible.

**STEP 13**

Remove the rear wall carpeting.

HD Series Only

With cutting wheels or a saw, cut the threaded studs from the rear wall(B). Cut as flush to the rear wall as possible.

1500 Series Only

With a set of pliers, work the threaded studs(B), until they break free from the rear wall. With an Unibit®, enlarge these holes to an 1/2-inch diameter.

**STEP 14**

Spray the areas that have been cut with paint. This is to prevent any rust from forming.

**STEP 15**

Mount the driver's and the passenger's seat belt retracting units, c-pillars and rear door sill plates back into place.

1500 Series Trucks, go to STEP 19.

**HD Series Trucks Only****STEP 16**

Place the pair of supplied wax square into place.

Passenger's side(pictured):

Place one of the supplied wax squares onto the lower left corner of the same emboss metal that the threaded stud was located on.

Driver's side(not pictured):

Place one of the supplied wax squares onto the lower right corner of the same emboss metal that the threaded stud was located on.

**HD Series Trucks Only****STEP 17**

Thread the supplied pair of socket cup set screws into the Stealthbox®, leaving 3/4-inch of thread exposed. Position the Stealthbox® in the mounting location and press onto the Stealthbox® firmly.

Remove the Stealthbox® carefully, leaving the wax squares in place. The socket cup set screws will leave impressions in the wax.

**HD Series Trucks Only****STEP 18**

Note: Before drilling, make sure that you are not going to be drilling into any gas lines, electrical wiring or anything else that might cause a reduction in your weekly pay. Always wear eye protection when drilling!

With a drill and a 1/2-inch drill bit, drill through the impression made in the wax square and through the cab wall.

Remove the wax squares, as seen in the picture at left.

**STEP 19**

Place the rear wall carpet back into place.

Feel for both drilled holes in the rear wall through the carpeting. With an utility knife cut an X that is in line with these drilled holes.

This is to allow the pair of socket cup set screws to pass through the carpeting, once the Stealthbox® is in place.



STEP 20

If an amplifier is to be mounted onto the Stealthbox®.

Drill the mounting holes in the proper location. Apply silicone to the four supplied Phillip head screws before securing the amplifier:

Run speaker wire from the amplifier location to the speaker terminals. Attach the speaker wire to the terminals.

Double check the woofers for proper operation.




STEP 21

1500 Series Trucks

Thread in the pair of socket cup set screws into the back of the Stealthbox®, leaving 1-1/2" of the threads exposed.

HD Series Trucks

Back out the pair of socket cup set screws, leaving 1-1/2" of the threads exposed.



STEP 22

From inside the truck, position the Stealthbox® into the mounting location. From the outside of the truck (between the cab wall and the bed wall) place the supplied fender washer, flat washer, lock washer and then nut onto each exposed socket cup set screw. Use a long 3/8" open end wrench or ratcheting box end to secure the mounting hardware. If you have big hands and arms, time to get that smaller friend of yours to help out.

Note: For added protection it is recommended that you apply a bead of silicone between the vehicle and the fender washer. After the bolt assembly is tightly secured, it is also recommended that vehicle undercoating material is applied to the exposed assembly.

CONGRATULATIONS

You have completed the installation for this model!

Please go back in the instructions in reverse to mount all factory paneling back to its original form.

Please refer to the Power Recommendation section for an amplifier recommendation and basic set-up help.



INCLUDED HARDWARE

- | | |
|---|---|
| (4) #10 x 3/4 Phillip pan head sheet metal screws | (2) 3/8" - 16 x 2-1/4" Socket Cup Set Screw |
| (2) 3/8" Split Lock Washer | (2) 3" x 3" Wax Squares |
| (2) 3/8" Flat Washer | |
| (2) 3/8" x 1-1/4" Fender Washer | |

POWER RECOMMENDATION

Enclosure Type: Acoustic Suspension (sealed)

Driver Type: 10W1v2-4


Nominal Impedance: 2 ohms mono

Continuous Power Handling: 300 Watts

POWER RECOMMENDATION

JL Audio recommends using a high quality amplifier such as the JL Audio 250/1.

The diagram below shows the recommended crossover, infrasonic filter and equalizer settings for the 250/1 when being used to power your Stealthbox®.



The JL Audio 250/1 is a very versatile audio component. Please consult the owner's manual for even more detailed information about installing and tuning this amplifier.

MID/HIGH FREQUENCY DRIVER FITMENT

A variety of JL Audio coaxial and component systems will fit in the factory speaker locations of your vehicle.

Front Speaker Size / Location: 6.5-inch / Front Doors

Fits JL Audio Models: TR650-CSi, TR650-CXi, C2-650, C2-650x, C3-650, C5-650, C5-650x & ZR650-CSi

Rear Speaker Size / Location: 6.5-inch / Rear Doors

Fits JL Audio Models: TR650-CXi, C2-650x, C3-650, C5-650x



JL AUDIO®

Ahead of the Curve™

(954) 443-1100

www.jlaudio.com

All specifications are subject to change without notice. "JL Audio" and the JL Audio logo, "Stealthbox" and the Stealthbox logo are registered trademarks of JL Audio, Inc. "Ahead of the Curve" and its respective logo is a trademark of JL Audio, Inc.
JL-A-SKU#011173; 09.21.2010 • Printed in USA • ©2006 JL Audio, Inc. • U.S. PATENTS: #5,734,734 #5,949,898 #6,118,884 #6,229,902 #6,243,479 #6,294,959 #6,501,844 #6,496,590 #6,441,685 #5,687,247 #6,219,431 #6,625,292 #D472,891 #D480,709 Other U.S. & Foreign patents pending. For more detailed information please visit us online at www.jlaudio.com.



Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>