+ECO Solar Weather Clock Model: BAR332ES / BAR332ESA / BAR332ESU

USER MANUAL

CONTENTS	ı
Earth Friendly2	
Overview 2	
Front View2	
Top View	
Bottom View	
Solar Panel4	
Remote Sensor 4	
Getting Started 4	
Solar Panel4	
Backup Power 6	
Remote Sensor 6	
Clock and Calendar 7	
Clock Reception	
Manually Set Clock7	
Alarm 8	
Temperature 8	
Weather forecast8	
Packlight 0	

Reset	9
Specifications	9
Precautions	9
About Oregon Scientific	10
EU-Declaration of Conformity	
FCC Statement	10

EARTH FRIENDLY


The +ECO line embodies our commitment to environmental concerns. Aware of threats facing the world we live in, Oregon Scientific™ has combined technological know-how, practicality and style to create this line of environmentally friendly products. These products provide practical solutions while enabling you and us to fulfill our environmental responsibility.

Simply detach the solar panel and face it directly towards the sun for a few hours to receive the amount of energy necessary to power the device.

Together we can improve the world we live in.

OVERVIEW

FRONT VIEW



OUT型

- Remote sensor reception indicator and outdoor channel selected
- Outdoor temperature
- 3. Indoor temperature

Download from Www.Somanuals.com. All Maratlats Search And Download.


- 5. O: Clock signal reception indicator
- 6. ((•)): Alarm time is displayed
- 7. Q: Daily alarm is On
- 8. AM / PM
- 9. Rechargeable battery status LED indicator
- 10. Outdoor remote sensor battery low
- 12. AC adaptor connected
- 13. 🜣: Rechargeable battery is low / solar panel detached
- 14. : Rechargeable battery level indicator
- 15. ZONE: Time zone offset
- 16. Calendar / Clock with weekday / seconds

TOP VIEW



- 1. **SNOOZE**: Activate snooze alarm / backlight
- A / ▼: Increase / decrease value of the setting; activate / deactivate clock reception signal
- 3. O: Change display; set clock
- □H: Toggle between outdoor temperature channels (1-3); initiate auto-toggle
- 5. ((•)): View alarm status; set alarm
- 6. Q: Activate / deactivate alarm function


BOTTOM VIEW



- 1. SEARCH: Initiate sensor search
- RESET: Reset unit to default settings
 - °C / °F: Select temperature unit

Download from Www.Somanuals.com.3All Manuals Search And Download.

SOLAR PANEL



- 1. CHARGING: charging in process
- 2. FULL: batteries fully charged (when TEST is pressed)
- 3. Solar panel
- 4. TEST establish if battery is full
- 5. Battery compartment

REMOTE SENSOR



- 1. LED status indicator
- 2. Wall mount hole
- 3. Battery compartment
- RESET: Reset unit to default settings
- CHANNEL switch

GETTING STARTED

SOLAR PANEL

This product uses two AAA rechargeable batteries which should be charged via the solar panel. For the batteries' first charge, it is strongly advised to charge it for at least 12 hours.

To charge the battery:

 Detach solar panel by exerting downward pressure and pulling at a 45° angle (approx.) away from main unit.



Insert 2 AAA rechargeable batteries in battery compartment located at the back of the solar panel.

IMPORTANT Place ONLY NiMH type rechargeable batteries in the solar panel battery compartment. Do not charge non-rechargeable batteries.

Expose the solar panel directly to sunlight for approximately 5-6 hours to charge the battery. The (red) CHARGING LED on solar panel will light up indicating there is sunlight and unit is charging. **TIP** Press and hold **TEST** located at the back of the solar panel. (Green) FULL LED indicates batteries have been fully charged.

 Align holes with protruding plastic. Push solar panel towards main unit and snap into place.

5-6 hours of battery charging will normally provide power to operate unit for 2 months.

When the rechargeable battery is nearly flat or when solar panel has been detached, the (green) LED indicator on the main unit and $\overset{*}{\sim}$ will flash.

TIPS

- For best results when charging the battery, place the solar panel directly with view to sunlight.
- Direct solar panel as follows:

Solar panel facing:	if you reside in the:
North	Southern Hemisphere
South	Northern Hemisphere

- Do not scratch the solar panel's surface or wipe it with strong detergent.
- Do not expose the solar panel to rain, snow or moisture.
- The duration of the rechargeable battery's charging or operating time is determined by either the intensity of sunlight or the position of the solar panel towards the sun.

BACKUP POWER

1 piece AAA battery

In the case when the rechargeable battery is flat or nearly flat or when the solar panel has been detached, the AAA battery can act as backup power supply for the main unit.

- Remove the battery compartment located at the base of the unit.
- 2. Insert the battery, matching the polarity.
- 3. Press **RESET** after each battery change.

Power adaptor (not included)

The adaptor powers the unit and can also be used for charging the rechargeable battery. When connected to the main unit, •• will be displayed.

NOTE The main unit and adaptor should not be exposed to wet conditions. No objects filled with liquid, such as vases, should be placed on the main unit and adaptor.

REMOTE SENSOR

This product can work with up to 3 sensors at any one time to capture temperature readings in various locations.

To set up the remote sensor:

1. Slide open the battery compartment.

- Slide channel switch to select a channel (1, 2, 3). Ensure you use a different channel for each sensor.
- 3. Insert the battery, matching the polarities.
- 4. Press RESET after each battery change.
- Close the battery compartment.
- Press and hold SEARCH for 2 seconds to initiate a sensor search.


NOTE Use alkaline batteries for longer usage and consumer grade lithium batteries in temperatures below freezing.

The remote sensor reception icon will show the following status:

ICONS	MEANING
OUT. → OUT.	Main unit is searching for sensor(s)
OUT. → OUT. → OUT. → OUT.	A sensor channel has been found
Tuo 2	No sensor found

TIP Ideal placements for the sensor would be in any location on the exterior of the home at a height of not more than 1.5 m (5 ft) and which can shield it from direct sunlight or wet conditions for an accurate reading.

Download from Www.Somanuals.com. All Manuals Search And Download.



CLOCK AND CALENDAR

CLOCK RECEPTION

This product is designed to synchronize its clock automatically with a clock signal.

BAR332ES: EU: DCF-77 signal: within 1500 km (932 miles) of Frankfurt, Germany.

BAR332ESU: UK: MSF-60 signal: within 1500 km (932 miles) of Anthorn, England.

BAR332ESA: WWVB-60 signal: within 3200km (2000 miles) of Fort Collins Colorado.

To enable / disable clock signal reception:

Press and hold ${\color{red} \blacktriangle}$ to enable or ${\color{red} \blacktriangledown}$ to disable clock signal reception.

NOTE Reception takes 2-10 minutes. If the signal is weak, it can take up to 24 hours to get a valid signal. If signal reception is unsuccessful, place your unit next to a window, press and hold \blacktriangle to force another signal search.

Clock signal reception indicator:

STRONG SIGNAL	WEAK / NO SIGNAL
6	<u>ي</u>

MANUALLY SET CLOCK

To set the clock manually, disable the clock signal reception first.

- Press and hold ∅.
- 2. Press \triangle / ∇ to change the settings.
- Press ♥ to confirm.

Download from Www.Somanuals.com.—All Manuals Search And Download.

The settings order is: time zone, 12/24 hr format, hour, minute, year, calendar mode (month – day / day – month), month, day and language.

BAR332ES / BAR332ESU: Time zone offset sets the clock +/- 23 hours from the received clock signal time. If you have deactivated the clock signal reception, do not set a value for time zone.

NOTE If you enter +1 in the time offset setting, this will give you your local time plus one hour. If you are in the US (BAR332ESA) set the clock to:

PA for Pacific time MO for Mountain time
CE for Central time EA for Eastern time

NOTE The language options are English (E), German (D), French (F), Italian (I), Spanish (S) and Russian (R).

To select clock display:

Press \bigodot to toggle between clock with seconds, clock with weekday and calendar.

ALARM

To set the alarm:

- 1. Press and hold ((•)) to enter alarm setting.
- 2. Press ▲ / ▼ to set hour / minute.
- 3. Press ((•)) to confirm.

Qindicates alarm is ON.

To activate / deactivate alarm:

Press Q

To silence the alarm:

Press SNOOZE to silence it for 8 minutes

OR

 Press any key to turn the alarm off and activate it again after 24 hours.

To display alarm:

Press ((•)).

TEMPERATURE

To toggle temperature unit:

Press °C / °F.

To toggle between each outdoor sensor's readings:

Press □H repeatedly

OR

Press and hold \(\subseteq \mathbb{H}\) for 2 seconds to initiate auto toggle of outdoor channels.

WEATHER FORECAST

This product forecasts the next 12 to 24 hours of weather forecast within a 30-50 km (19-31 mile) radius.

Download from Www.Somanuals.com. All Manuals Search And Download.

- Ö -	Sunny
	Partially cloudy
	Cloudy
	Rainy
* * *	Snowy

BACKLIGHT

Press **SNOOZE** to activate backlight for 3 seconds.

RESET

Press RESET to return to the default settings.

SPECIFICATIONS

MAIN UNIT

TYPE	DESCRIPTION
LxWxH	158 x 87 x 55mm (6.2 x 3.4 x 2.2 in)
Weight	280 g (9.88 oz) without battery

Signal frequency	433 MHz
Power	2 x UM-4 (AAA) rechargeable batteries; 6V AC adaptor (not included) 1 x UM-4 (AAA) battery (for backup)

REMOTE SENSOR (THN132N)	
LxWxH	96 x 50 x 22mm (3.78 x 1.97 x 0.87 in)
Weight	62 g (2.22 ounces) without battery
Transmission range	30 m (98ft) unobstructed
Temperature range	-20°C to 60°C (-4°F to 140°F)
Power	1 x UM-3 (AA) 1.5 V battery

PRECAUTIONS

- Do not subject the unit to excessive force, shock, dust, temperature or humidity
- Do not cover the ventilation holes with any items such as newspapers, curtains etc.
- Do not immerse the unit in water. If you spill liquid over it, dry it immediately with a soft, lint-free cloth.
- Do not clean the unit with abrasive or corrosive materials.
- Do not tamper with the unit's internal components. This invalidates the warranty.
- Only use fresh batteries. Do not mix new and old

Download from Www.Somanuals.com.oAll Manuals Search And Download.

- Images shown in this manual may differ from the actual display.
- When disposing of this product, ensure it is collected separately for special treatment.
- Placement of this product on certain types of wood may result in damage to its finish for which Oregon Scientific will not be responsible. Consult the furniture manufacturer's care instructions for information.
- The contents of this manual may not be reproduced without the permission of the manufacturer.
- Do not dispose old batteries as unsorted municipal waste. Collection of such waste separately for special treatment is necessary.
- Please note that some units are equipped with a battery safety strip. Remove the strip from the battery compartment before first use.

NOTE The technical specifications for this product and the contents of the user manual are subject to change without notice.

NOTE Features and accessories will not be available in all countries. For more information, please contact your local retailer

ABOUT OREGON SCIENTIFIC

Visit our website (www.oregonscientific.com) to learn more about Oregon Scientific products. If you're in the US and would like to contact our Customer Care department directly. please visit:

www2.oregonscientific Downstandersupp Wwwsp.Somanuals.com. All Manuals Search And Download.

For international inquiries, please visit: www2.oregonscientific.com/about/international.asp

EU-DECLARATION OF CONFORMITY

Hereby, Oregon Scientific, declares that this +ECO Solar Weather Clock (model: BAR332ES / BAR332ESU/ BAR332ESA) is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. A copy of the signed and dated Declaration of Conformity is available on request via our Oregon Scientific Customer Service











COUNTRIES RTTE APPROVED COMPLIED All EU countries, Switzerland CHD

and Norway (N)

FCC STATEMENT

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

WARNING Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

DECLARATION OF CONFORMITY

The following information is not to be used as contact for support or sales. Please visit our website at <a href="https://www2.com/service

W۵

Name: Oregon Scientific, Inc.

Address: 19861 SW 95th Ave., Tualatin.

Oregon 97062 USA

Telephone No.: 1-800-853-8883

declare that the product

Product No.: BAR332ES / BAR332ESU /

BAR332ESA

Product Name: +ECO Solar Weather Clock
Manufacturer: IDT Technology Limited

Address: Block C. 9/F. Kaiser Estate.

Phase 1, 41 Man Yue St.,

Hung Hom, Kowloon.

Hong Kong

is in conformity with Part 15 of the FCC Rules. Operation is subject to the following two conditions: 1) This device may not cause harmful interference. 2) This device must accept any interference received, including interference that may cause undesired operation.



Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com