INSTALLATION





Spectra® IV Series Spectra® IV SE Series





In-Ceiling Mount Back Box

Installation










5



- 1. Locate the center point of the mounting location and insert the compass tool. Draw a circle.
- 2. Cut the circle out of the ceiling.
- 3. Attach the conduit fitting, lock nut, and safety chain bracket. Install a safety chain/cable (not supplied) that will support up to 16 pounds (7.3 kg).
- 4. Open the hinged door to the back box. Push the tab lock towards the wall of the unit and lift the door open. Pull wiring into the back box through the conduit fitting. Refer to Table A, Table B, and Table C for wiring distances.
- 5. Install the back box by compressing the spring clips and pushing the back box through the hole. Tighten the screws until you hear a clicking noise.

Table A. Video Coaxial Cable Requirements

Cable Type*	Maximum Distance
RG59/U	750 ft (229 m)
RG6/U	1,000 ft (305 m)
RG11/U	1,500 ft (457 m)

^{*}Cable requirements:
75 ohms impedance
All-copper center conductor
All-copper braided shield with 95% braid
coverage

Table B. 24 VAC/24VDC Wiring Distances

The following are the recommended maximum distances for 24 VAC and 24 VDC applications and are calculated with a 10 percent voltage drop. (Ten percent is generally the maximum allowable voltage drop for AC- or DC-powered devices.)

AC/DC		Wire Gauge						
Total VA/	20 AWG	18 AWG						
Total Watts	(0.5 mm ²)	(1.0 mm²)						
23 VA/	123 ft	196 ft	311 ft	495 ft				
15 watts	(38 m)	(60 m)	(95 m)	(151 m)				
73 VA/	39 ft	62 ft	98 ft	156 ft				
65 watts	(12 m)	(19 m)	(30 m)	(48 m)				

NOTE: Input power for the dome is 24 VAC or 24 VDC. Using 24 VAC input power, power consumption is 23 VA per dome for indoor models and 73 VA for outdoor models. Using 24 VDC input power, power consumption is 0.7 A (15 watts) for indoor models and 3 A (65 watts) for outdoor models.


Use a 24 VAC transformer with the following minimum VA:


40 VA per dome For indoor models (without heater)
100 VA per dome For outdoor models (with heater)

Table C. UTP Wiring Distances

Receiver	Maximum Distance
Active	0-3,000 ft
(Video Only)	(0-914.4 m)
Passive	0-750 ft
(Video, Coaxitron, Pelco V-Sync)	(0-228.6 m)

NOTE: As a minimum, UTP requires Cat5, 100-ohm twisted pair cable.






- 6. **Suspended Ceiling Only:** Install the ceiling tile with the back box. Attach a T-rail clip on each side of the ceiling tile.
- **WARNING:** An electrical short in the back box may occur if the metal BNC connector is not completely covered by the protective boot.
- 7. Connect wiring to the circuit board inside the back box. When finished, close the door to the back box and turn on the power. The green LED will light.


NOTES:

- Aux 1: Maximum 2 A at low voltage (<40 V)
 Aux 2: Maximum 30 mA at 32 VDC
- If you are using both unshielded twisted pair (UTP) wiring and a translator board, install the UTP wiring before
 installing the translator board.
- If you are installing an environmental back box in a railway application, attach a ground wire from the circuit board power connector to a structural ground using at least 18-gauge wire.


8



10



9



- 8. Configure DIP switches SW1 and SW2 located on the top of the dome drive. For DIP switch settings, refer to the labels located on the top of the dome drive or to the *Switch Settings* section.
 - **NOTE:** When connecting more than one Spectra® dome to a single controller, terminate the unit farthest from the controller. To terminate the dome drive set the SW2-10 switch to the ON position.
- 9. Install the dome drive. Refer to Table D for a list of compatible dome drives and back boxes. Line up the blue and red tabs with the blue and red arrows on the hinged door inside the back box. Push in on the tabs. Insert one side and then the other side. Continue pushing on the ends of the tabs until both sides click into place.

Table D. Spectra Dome Drive and Back Box Compatibility

Dome Drive	Back Box						
	Spectra II	Spectra III	Spectra IV				
Spectra II®	•						
Spectra III™	•	•	•				
Spectra IV	•	•	•				

10. Install the lower dome. Snap the clip on the end of the trim ring leash into the hole on the lip of the back box. Snap the trim ring into the plastic snap washers on the mounting screws.

To use your dome, refer to the operation and programming manual.

Troubleshooting

If your dome does not power up properly after installation, use the following steps.

- 1. Check the fuse on the circuit board inside the back box for continuity. Replace the fuse if needed.
- 2. Check the wiring with a volt meter to ensure proper voltage is being received into the back box.

If your dome powers up correctly, but you do not have accurate control, use the following steps.

1. Check the signal with a volt meter or an oscilloscope.

NOTE: This step will not apply if you are using Coaxitron control.

- 2. Ensure that the switch settings on the dome drive are set correctly. Refer to the Switch Settings section.
- 3. If you are using a Pelco controller, ensure that the factory-installed 16-pin jumper has not been removed. If you are using a third-party controller, a TXB Series translator board must be installed. The dome will not function without this 16-pin jumper or a translator board installed.

Switch Settings



WARNING: If you are using D-type or P-type control, your system may not operate if the baud rate and address switches are not set correctly. The switches are set at the factory at the defaults for D-type control (2400 baud and address 1).

Table E. Switch Settings for SW2

Special Systems										
Switch Number	1	2	3	4	5	6	7	8	9	10
AD-32 Preset System	ON									
CM9502 Setting		ON								
Vicon	Not currently available; SW2-3 is reserved for future use.									
Serial Port Settings										
Switch Number	1	2	3	4	5	6	7	8	9	10
RS422				OFF	OFF					
RS485, Four Wire				OFF	ON					
RS485, Two Wire				ON	ON					
D or P Protocol Baud Rate										
Switch Number	1	2	3	4	5	6	7	8	9	10
2400 Baud (Default for D-type Control)						OFF	OFF	OFF		
4800 Baud (Default for P-type Control)						ON	OFF	OFF		
9600 Baud						OFF	ON	OFF		
Video Cable Type										
Switch Number	1	2	3	4	5	6	7	8	9	10
Coax Cable									OFF	
UTP Cable									ON	
Dome Termination										
Switch Number	1	2	3	4	5	6	7	8	9	10
Terminated										ON
Not Terminated										OFF

Table F. Switch Settings for SW1, P-Type Control

NOTE: For Coaxitron controls, SW1 is not used; set all switches OFF. For D-type control systems, refer to Table G.

SPECTRA		SW	ITCH SETT	ING	
ADDRESS	SW1-1	SW1-2	SW1-3	SW1-4	SW1-5
1	OFF	0FF	0FF	0FF	0FF
2	ON	0FF	0FF	0FF	0FF
3	0FF	ON	0FF	0FF	0FF
4	ON	ON	0FF	0FF	0FF
5	0FF	0FF	ON	0FF	0FF
6	ON	0FF	ON	0FF	0FF
7	0FF	ON	ON	0FF	0FF
8	ON	ON	ON	0FF	0FF
9	0FF	0FF	0FF	ON	0FF
10	ON	0FF	0FF	ON	0FF
11	0FF	ON	0FF	ON	0FF
12	ON	ON	0FF	ON	0FF
13	0FF	0FF	ON	ON	0FF
14	ON	0FF	ON	ON	0FF
15	0FF	ON	ON	ON	0FF
16	ON	ON	ON	ON	OFF

SPECTRA		SW	/ITCH SETTI	NG	
ADDRESS	SW1-1	SW1-2	SW1-3	SW1-4	SW1-5
17	OFF	0FF	0FF	0FF	ON
18	ON	0FF	0FF	0FF	ON
19	0FF	ON	0FF	0FF	ON
20	ON	ON	0FF	0FF	ON
21	0FF	0FF	ON	0FF	ON
22	ON	0FF	ON	0FF	ON
23	0FF	ON	ON	0FF	ON
24	ON	ON	ON	0FF	ON
25	0FF	0FF	0FF	ON	ON
26	ON	0FF	0FF	ON	ON
27	0FF	ON	0FF	ON	ON
28	ON	ON	0FF	ON	ON
29	0FF	0FF	ON	ON	ON
30	ON	0FF	ON	ON	ON
31	0FF	ON	ON	ON	ON
32	ON	ON	ON	ON	ON

Table G. Switch Settings for SW1, D-Type Control

NOTE: For Coaxitron controls, SW1 is not used; set all switches OFF. For P-type control systems, refer to Table F.

SPECTRA			;	SWITCH	SETTING	ì		
ADDRESS	SW1-1	SW1-2	SW1-3	SW1-4	SW1-5	SW1-6	SW1-7	SW1-8
1	ON	OFF	0FF	0FF	0FF	OFF	0FF	0FF
2	OFF	ON	0FF	OFF	0FF	0FF	0FF	0FF
3	ON	ON	0FF	OFF	0FF	0FF	0FF	0FF
4	0FF	0FF	ON	OFF	0FF	0FF	0FF	0FF
5	ON	0FF	ON	OFF	0FF	0FF	0FF	0FF
6	0FF	ON	ON	OFF	0FF	0FF	0FF	0FF
7	ON	ON	ON	OFF	0FF	0FF	0FF	0FF
8	0FF	0FF	0FF	ON	0FF	0FF	0FF	0FF
9	ON	0FF	0FF	ON	0FF	0FF	0FF	0FF
10	0FF	ON	0FF	ON	OFF	0FF	0FF	0FF
11	ON	ON	0FF	ON	0FF	0FF	0FF	0FF
12	0FF	0FF	ON	ON	0FF	0FF	0FF	0FF
13	ON	OFF	ON	ON	OFF	OFF	OFF	OFF
14	OFF	ON	ON	ON	OFF	OFF	0FF	0FF
15	ON	ON	ON	ON	OFF	OFF	0FF	0FF

SPECTRA			;	SWITCH	SETTING	ì		
ADDRESS	SW1-1	SW1-2	SW1-3	SW1-4	SW1-5	SW1-6	SW1-7	SW1-8
16	OFF	0FF	0FF	0FF	ON	0FF	0FF	0FF
17	ON	0FF	0FF	0FF	ON	0FF	0FF	0FF
18	OFF	ON	OFF	0FF	ON	OFF	0FF	OFF
19	ON	ON	0FF	0FF	ON	0FF	0FF	0FF
20	OFF	OFF	ON	0FF	ON	OFF	0FF	OFF
21	ON	OFF	ON	0FF	ON	0FF	0FF	0FF
22	OFF	ON	ON	OFF	ON	OFF	0FF	OFF
23	ON	ON	ON	0FF	ON	OFF	OFF	0FF
24	OFF	OFF	0FF	ON	ON	OFF	0FF	0FF
25	ON	OFF	OFF	ON	ON	OFF	OFF	OFF
26	OFF	ON	OFF	ON	ON	OFF	OFF	0FF
27	ON	ON	0FF	ON	ON	0FF	0FF	0FF
28	OFF	0FF	ON	ON	ON	0FF	0FF	0FF
29	ON	0FF	ON	ON	ON	0FF	0FF	0FF
30	OFF	ON	ON	ON	ON	OFF	OFF	OFF

SPECTRA			,	SWITCH	SETTING	ì		
ADDRESS	SW1-1	SW1-2	SW1-3	SW1-4	SW1-5	SW1-6	SW1-7	SW1-8
31	ON	ON	ON	ON	ON	OFF	OFF	OFF
32	OFF	OFF	OFF	OFF	OFF	ON	OFF	OFF
33	ON	OFF	0FF	OFF	OFF	ON	0FF	0FF
34	0FF	ON	0FF	0FF	0FF	ON	0FF	0FF
35	ON	ON	OFF	OFF	OFF	ON	OFF	0FF
36	OFF	OFF	ON	OFF	0FF	ON	OFF	0FF
37	ON	OFF	ON	OFF	0FF	ON	0FF	0FF
38	OFF	ON	ON	0FF	0FF	ON	0FF	OFF
39	ON	ON	ON	0FF	0FF	ON	0FF	0FF
40	0FF	0FF	0FF	ON	0FF	ON	0FF	0FF
41	ON	0FF	0FF	ON	OFF	ON	0FF	0FF
42	OFF	ON	0FF	ON	0FF	ON	0FF	0FF
43	ON	ON	OFF	ON	OFF	ON	OFF	0FF
44	OFF	0FF	ON	ON	0FF	ON	0FF	0FF
45	ON	OFF	ON	ON	OFF	ON	OFF	0FF
46	OFF	ON	ON	ON	0FF	ON	0FF	0FF
47	ON	ON	ON	ON	OFF	ON	OFF	0FF
48	OFF	0FF	0FF	0FF	ON	ON	0FF	0FF
49	ON	OFF	OFF	OFF	ON	ON	OFF	0FF
50	OFF	ON	0FF	0FF	ON	ON	0FF	OFF
51	ON	ON	0FF	OFF	ON	ON	0FF	0FF
52	0FF	0FF	ON	0FF	ON	ON	0FF	0FF
53	ON	OFF	ON	OFF	ON	ON	0FF	0FF
54	OFF	ON	ON	OFF	ON	ON	0FF	OFF
55	ON	ON	ON	OFF	ON	ON	OFF	OFF
56	OFF	OFF	0FF	ON	ON	ON	0FF	0FF
57	ON	OFF	OFF	ON	ON	ON	OFF	OFF
58	OFF	ON	0FF	ON	ON	ON	0FF	0FF
59	ON	ON	OFF	ON	ON	ON	OFF	OFF
60	OFF	OFF	ON	ON	ON	ON	0FF	OFF
61	ON	OFF	ON	ON	ON	ON	OFF	OFF
62	OFF	ON	ON	ON	ON	ON	0FF	OFF
63	ON	ON	ON	ON	ON	ON	OFF	0FF
64	OFF	OFF	OFF	OFF	OFF	OFF	ON	0FF
65	ON	OFF	OFF	OFF	OFF	OFF	ON	OFF
66	OFF	ON	OFF	OFF	OFF	OFF	ON	0FF
67	ON	ON	OFF	OFF	OFF	OFF	ON	OFF
68	OFF	OFF	ON	OFF	0FF	0FF	ON	0FF
69	ON	OFF	ON	OFF	OFF	OFF	ON	0FF
70	0FF	ON	ON	0FF	OFF	OFF	ON	0FF

SPECTRA			\$	SWITCH	SETTING	ì		
ADDRESS	SW1-1	SW1-2	SW1-3	SW1-4	SW1-5	SW1-6	SW1-7	SW1-8
71	ON	ON	ON	OFF	OFF	OFF	ON	0FF
72	0FF	0FF	0FF	ON	0FF	OFF	ON	0FF
73	ON	OFF	OFF	ON	OFF	OFF	ON	0FF
74	OFF	ON	0FF	ON	0FF	OFF	ON	0FF
75	ON	ON	OFF	ON	OFF	OFF	ON	0FF
76	OFF	OFF	ON	ON	OFF	0FF	ON	0FF
77	ON	OFF	ON	ON	OFF	OFF	ON	OFF
78	OFF	ON	ON	ON	OFF	OFF	ON	OFF
79	ON	ON	ON	ON	0FF	0FF	ON	0FF
80	OFF	OFF	0FF	OFF	ON	OFF	ON	0FF
81	ON	OFF	OFF	0FF	ON	OFF	ON	0FF
82	OFF	ON	0FF	OFF	ON	OFF	ON	0FF
83	ON	ON	0FF	OFF	ON	OFF	ON	0FF
84	0FF	0FF	ON	OFF	ON	OFF	ON	0FF
85	ON	OFF	ON	0FF	ON	0FF	ON	0FF
86	0FF	ON	ON	0FF	ON	OFF	ON	0FF
87	ON	ON	ON	OFF	ON	OFF	ON	0FF
88	OFF	0FF	0FF	ON	ON	0FF	ON	0FF
89	ON	OFF	OFF	ON	ON	OFF	ON	0FF
90	OFF	ON	0FF	ON	ON	0FF	ON	0FF
91	ON	ON	OFF	ON	ON	OFF	ON	0FF
92	OFF	0FF	ON	ON	ON	0FF	ON	0FF
93	ON	OFF	ON	ON	ON	OFF	ON	0FF
94	OFF	ON	ON	ON	ON	OFF	ON	0FF
95	ON	ON	ON	ON	ON	0FF	ON	0FF
96	0FF	0FF	0FF	0FF	0FF	ON	ON	0FF
97	ON	OFF	OFF	OFF	OFF	ON	ON	0FF
98	OFF	ON	0FF	0FF	0FF	ON	ON	0FF
99	ON	ON	OFF	OFF	OFF	ON	ON	OFF
100	OFF	0FF	ON	0FF	0FF	ON	ON	0FF
101	ON	OFF	ON	OFF	OFF	ON	ON	OFF
102	OFF	ON	ON	0FF	OFF	ON	ON	0FF
103	ON	ON	ON	OFF	OFF	ON	ON	OFF
104	OFF	OFF	OFF	ON	OFF	ON	ON	OFF
105	ON	OFF	OFF	ON	OFF	ON	ON	OFF
106	OFF	ON	0FF	ON	0FF	ON	ON	0FF
107	ON	ON	OFF	ON	OFF	ON	ON	OFF
108	OFF	OFF	ON	ON	0FF	ON	ON	0FF
109	ON	OFF	ON	ON	OFF	ON	ON	OFF
110	OFF	ON	ON	ON	0FF	ON	ON	0FF

SPECTRA			\$	SWITCH	SETTING	ì		
ADDRESS	SW1-1	SW1-2	SW1-3	SW1-4	SW1-5	SW1-6	SW1-7	SW1-8
111	ON	ON	ON	ON	OFF	ON	ON	OFF
112	OFF	OFF	OFF	0FF	ON	ON	ON	0FF
113	ON	0FF	0FF	0FF	ON	ON	ON	0FF
114	0FF	ON	0FF	0FF	ON	ON	ON	0FF
115	ON	ON	OFF	OFF	ON	ON	ON	0FF
116	0FF	0FF	ON	0FF	ON	ON	ON	0FF
117	ON	OFF	ON	OFF	ON	ON	ON	OFF
118	OFF	ON	ON	OFF	ON	ON	ON	0FF
119	ON	ON	ON	0FF	ON	ON	ON	0FF
120	0FF	0FF	0FF	ON	ON	ON	ON	0FF
121	ON	OFF	OFF	ON	ON	ON	ON	0FF
122	OFF	ON	OFF	ON	ON	ON	ON	0FF
123	ON	ON	OFF	ON	ON	ON	ON	0FF
124	OFF	OFF	ON	ON	ON	ON	ON	0FF
125	ON	OFF	ON	ON	ON	ON	ON	0FF
126	0FF	ON	ON	ON	ON	ON	ON	0FF
127	ON	ON	ON	ON	ON	ON	ON	0FF
128	0FF	0FF	0FF	0FF	OFF	0FF	0FF	ON
129	ON	OFF	OFF	OFF	OFF	OFF	OFF	ON
130	0FF	ON	0FF	0FF	0FF	0FF	0FF	ON
131	ON	ON	OFF	OFF	OFF	OFF	OFF	ON
132	0FF	0FF	ON	0FF	0FF	0FF	0FF	ON
133	ON	0FF	ON	0FF	0FF	0FF	0FF	ON
134	0FF	ON	ON	0FF	0FF	0FF	0FF	ON
135	ON	ON	ON	0FF	0FF	0FF	0FF	ON
136	0FF	0FF	0FF	ON	0FF	0FF	0FF	ON
137	ON	0FF	0FF	ON	0FF	0FF	0FF	ON
138	0FF	ON	0FF	ON	0FF	0FF	0FF	ON
139	ON	ON	OFF	ON	OFF	0FF	0FF	ON
140	0FF	0FF	ON	ON	0FF	0FF	0FF	ON
141	ON	OFF	ON	ON	OFF	OFF	OFF	ON
142	0FF	ON	ON	ON	0FF	0FF	0FF	ON
143	ON	ON	ON	ON	OFF	OFF	OFF	ON
144	OFF	OFF	OFF	OFF	ON	OFF	OFF	ON
145	ON	OFF	OFF	OFF	ON	OFF	OFF	ON
146	OFF	ON	OFF	0FF	ON	OFF	OFF	ON
147	ON	ON	OFF	OFF	ON	OFF	OFF	ON
148	OFF	OFF	ON	0FF	ON	OFF	OFF	ON
149	ON	OFF	ON	0FF	ON	OFF	OFF	ON
150	0FF	ON	ON	0FF	ON	0FF	0FF	ON

SPECTRA			9	SWITCH	SETTING	ì		
ADDRESS	SW1-1	SW1-2	SW1-3	SW1-4	SW1-5	SW1-6	SW1-7	SW1-8
151	ON	ON	ON	OFF	ON	OFF	OFF	ON
152	0FF	0FF	0FF	ON	ON	0FF	0FF	ON
153	ON	OFF	OFF	ON	ON	OFF	OFF	ON
154	OFF	ON	OFF	ON	ON	OFF	OFF	ON
155	ON	ON	0FF	ON	ON	OFF	OFF	ON
156	OFF	0FF	ON	ON	ON	OFF	OFF	ON
157	ON	OFF	ON	ON	ON	OFF	OFF	ON
158	0FF	ON	ON	ON	ON	0FF	0FF	ON
159	ON	ON	ON	ON	ON	OFF	OFF	ON
160	0FF	OFF	OFF	0FF	OFF	ON	0FF	ON
161	ON	OFF	OFF	OFF	OFF	ON	OFF	ON
162	0FF	ON	OFF	0FF	OFF	ON	0FF	ON
163	ON	ON	OFF	OFF	OFF	ON	OFF	ON
164	0FF	OFF	ON	0FF	OFF	ON	0FF	ON
165	ON	OFF	ON	OFF	OFF	ON	OFF	ON
166	0FF	ON	ON	0FF	OFF	ON	0FF	ON
167	ON	ON	ON	OFF	OFF	ON	OFF	ON
168	0FF	OFF	OFF	ON	OFF	ON	0FF	ON
169	ON	OFF	OFF	ON	OFF	ON	OFF	ON
170	0FF	ON	OFF	ON	OFF	ON	0FF	ON
171	ON	ON	OFF	ON	OFF	ON	OFF	ON
172	0FF	OFF	ON	ON	OFF	ON	0FF	ON
173	ON	OFF	ON	ON	0FF	ON	0FF	ON
174	0FF	ON	ON	ON	0FF	ON	0FF	ON
175	ON	ON	ON	ON	OFF	ON	OFF	ON
176	0FF	OFF	OFF	0FF	ON	ON	0FF	ON
177	ON	OFF	OFF	0FF	ON	ON	0FF	ON
178	0FF	ON	0FF	0FF	ON	ON	0FF	ON
179	ON	ON	OFF	OFF	ON	ON	OFF	ON
180	0FF	0FF	ON	0FF	ON	ON	0FF	ON
181	ON	OFF	ON	OFF	ON	ON	OFF	ON
182	OFF	ON	ON	0FF	ON	ON	0FF	ON
183	ON	ON	ON	OFF	ON	ON	OFF	ON
184	OFF	OFF	OFF	ON	ON	ON	OFF	ON
185	ON	OFF	OFF	ON	ON	ON	OFF	ON
186	OFF	ON	OFF	ON	ON	ON	OFF	ON
187	ON	ON	OFF	ON	ON	ON	OFF	ON
188	OFF	OFF	ON	ON	ON	ON	OFF	ON
189	ON	OFF	ON	ON	ON	ON	OFF	ON
190	OFF	ON	ON	ON	ON	ON	OFF	ON

SPECTRA	SWITCH SETTING							
ADDRESS	SW1-1	SW1-2	SW1-3	SW1-4	SW1-5	SW1-6	SW1-7	SW1-8
191	ON	ON	ON	ON	ON	ON	0FF	ON
192	OFF	OFF	0FF	OFF	OFF	OFF	ON	ON
193	ON	OFF	0FF	OFF	OFF	OFF	ON	ON
194	0FF	ON	0FF	OFF	OFF	0FF	ON	ON
195	ON	ON	0FF	OFF	OFF	OFF	ON	ON
196	OFF	OFF	ON	OFF	OFF	OFF	ON	ON
197	ON	OFF	ON	OFF	OFF	0FF	ON	ON
198	OFF	ON	ON	OFF	OFF	0FF	ON	ON
199	ON	ON	ON	OFF	OFF	0FF	ON	ON
200	OFF	OFF	0FF	ON	OFF	0FF	ON	ON
201	ON	OFF	OFF	ON	OFF	OFF	ON	ON
202	OFF	ON	0FF	ON	OFF	0FF	ON	ON
203	ON	ON	OFF	ON	OFF	OFF	ON	ON
204	OFF	OFF	ON	ON	OFF	0FF	ON	ON
205	ON	OFF	ON	ON	OFF	OFF	ON	ON
206	OFF	ON	ON	ON	OFF	OFF	ON	ON
207	ON	ON	ON	ON	OFF	OFF	ON	ON
208	OFF	OFF	OFF	OFF	ON	OFF	ON	ON
209	ON	OFF	OFF	OFF	ON	OFF	ON	ON
210	OFF	ON	OFF	OFF	ON	OFF	ON	ON
211	ON	ON	OFF	OFF	ON	OFF	ON	ON
212	OFF	OFF	ON	OFF	ON	OFF	ON	ON
213	ON	OFF	ON	OFF	ON	OFF	ON	ON
214	0FF	ON	ON	0FF	ON	0FF	ON	ON
215	ON	ON	ON	OFF	ON	0FF	ON	ON
216	0FF	OFF	0FF	ON	ON	0FF	ON	ON
217	ON	OFF	0FF	ON	ON	0FF	ON	ON
218	0FF	ON	0FF	ON	ON	0FF	ON	ON
219	ON	ON	0FF	ON	ON	OFF	ON	ON
220	OFF	OFF	ON	ON	ON	OFF	ON	ON
221	ON	OFF	ON	ON	ON	OFF	ON	ON
222	OFF	ON	ON	ON	ON	0FF	ON	ON

SPECTRA	SWITCH SETTING							
ADDRESS	SW1-1	SW1-2	SW1-3	SW1-4	SW1-5	SW1-6	SW1-7	SW1-8
223	ON	ON	ON	ON	ON	OFF	ON	ON
224	0FF	0FF	0FF	0FF	0FF	ON	ON	ON
225	ON	OFF	OFF	OFF	0FF	ON	ON	ON
226	OFF	ON	OFF	OFF	0FF	ON	ON	ON
227	ON	ON	OFF	OFF	OFF	ON	ON	ON
228	OFF	OFF	ON	OFF	OFF	ON	ON	ON
229	ON	OFF	ON	OFF	OFF	ON	ON	ON
230	OFF	ON	ON	OFF	OFF	ON	ON	ON
231	ON	ON	ON	OFF	0FF	ON	ON	ON
232	0FF	0FF	0FF	ON	OFF	ON	ON	ON
233	ON	OFF	OFF	ON	OFF	ON	ON	ON
234	0FF	ON	0FF	ON	OFF	ON	ON	ON
235	ON	ON	OFF	ON	OFF	ON	ON	ON
236	0FF	0FF	ON	ON	OFF	ON	ON	ON
237	ON	OFF	ON	ON	OFF	ON	ON	ON
238	OFF	ON	ON	ON	0FF	ON	ON	ON
239	ON	ON	ON	ON	0FF	ON	ON	ON
240	OFF	0FF	0FF	0FF	ON	ON	ON	ON
241	ON	0FF	0FF	OFF	ON	ON	ON	ON
242	0FF	ON	0FF	0FF	ON	ON	ON	ON
243	ON	ON	OFF	OFF	ON	ON	ON	ON
244	OFF	OFF	ON	OFF	ON	ON	ON	ON
245	ON	OFF	ON	OFF	ON	ON	ON	ON
246	OFF	ON	ON	OFF	ON	ON	ON	ON
247	ON	ON	ON	OFF	ON	ON	ON	ON
248	0FF	0FF	0FF	ON	ON	ON	ON	ON
249	ON	0FF	0FF	ON	ON	ON	ON	ON
250	OFF	ON	0FF	ON	ON	ON	ON	ON
251	ON	ON	OFF	ON	ON	ON	ON	ON
252	OFF	OFF	ON	ON	ON	ON	ON	ON
253	ON	OFF	ON	ON	ON	ON	ON	ON
254	0FF	ON						

Specifications

GENERAL

Construction

Back Box **Plastic**

Dome Drive

Aluminum, thermoplastic

Lower Dome Cable Entry (Back Box)

Acrvlic 0.75-inch conduit fitting

Pan Movement

360° continuous pan rotation Unobstructed +2° to -92°

Vertical Tilt Manual Pan/Tilt Speeds*

0.1°-80°/sec manual operation,

32° to 122°F (0° to 50°C)

(Assumes no wind chill factor)

140°F (60°C) absolute maximum;

150°/sec turbo Tilt 0.1°-40°/sec manual operation

Preset Speeds

Pan 400°/sec Tilt 200°/sec

Environment

In-Ceiling Indoor **Environmental In-Ceiling** Outdoor

Operating Temperature

In-Ceiling Indoor

Environmental In-Ceiling Maximum

122°F (50°C) sustained maximum -60°F (-51.1°C) absolute minimum; Minimum prevents icing at sustained minimum of -50°F (-45°C); de-ices 0.1 inch (2.5 mm) within 3 hours after power-up

Weight (approximate)

Back Box

In-Ceiling Indoor 1.5 lb (0.68 kg) Environmental In-Ceiling 2.1 lb (0.95 kg) Dome Drive 3.3 lb (1.48 kg)

Lower Dome

In-Ceiling Indoor 0.2 lb (0.09 kg) Environmental In-Ceiling 0.6 lb (0.27 kg)

ELECTRICAL (Dome Drive Only)

18-32 VAC; 24 VAC nominal Input Voltage

22-27 VDC; 24 VDC nominal

Input Power

24 VAC 23 VA nominal (indoor, without heater)

73 VA nominal (outdoor, with heater)

24 VDC 0.7 A nominal (indoor, without heater) 3 A nominal (outdoor, without heater)


Fuse 1.25 A


Auxiliary Outputs 2 (Spectra IV SE only) 7 (Spectra IV SE only) Alarm Inputs

Relay Contacts AUX 1 AUX 2 Output Type Form C Open collector transistor output Voltage Low voltage (<40 V) 32 VDC maximum

Current 2 A maximum

Environmental In-Ceiling





150 mA maximum

NOTE: VALUES IN PARENTHESES ARE CENTIMETERS; ALL OTHERS ARE INCHES.

☼ Green The materials used in the manufacture of this document and its components are compliant to the requirements of Directive 2002/95/EC.



This equipment contains electrical or electronic components that must be recycled properly to comply with Directive 2002/96/EC of the European Union regarding the disposal of waste electrical and electronic equipment (WEEE). Contact your local dealer for procedures for recycling this equipment.

^{*}For variable-speed operation an appropriate controller is required. With fixed-speed controllers, pan/tilt speed is 20°/sec. The CM6700/CM6800 controller with the KBD200A keyboard has programmable fixed speeds.

PRODUCT WARRANTY AND RETURN INFORMATION

WARRANTY

Pelco will repair or replace, without charge, any merchandise proved defective in material or workmanship **for a period of one year** after the date of shipment.

Exceptions to this warranty are as noted below:

- Five years on FR/FT/FS Series fiber optic products and TW3000 Series unshielded twisted pair transmission products.
- Three years on Spectra® IV products.
- Three years on Genex® Series products (multiplexers, server, and keyboard).
- Three years on Camclosure® and fixed camera models, except the CC3701H-2, CC3701H-2X, CC3751H-2, CC3651H-2X, MC3651H-2, and MC3651H-2X camera models, which have a five-year warranty.
- · Three years on PMCL200/300/400 Series LCD monitors.
- . Two years on standard motorized or fixed focal length lenses.
- Two years on Legacy®, CM6700/CM6800/CM9700 Series matrix, and DF5/ DF8 Series fixed dome products.
- Two years on Spectra III™, Esprit®, ExSite™, and PS20 scanners, including when used in continuous motion applications.
- Two years on Esprit and WW5700 Series window wiper (excluding wiper blades)
- Two years (except lamp and color wheel) on Digital Light Processing (DLP®) displays. The lamp and color wheel will be covered for a period of 90 days. The air filter is not covered under warranty.
- Eighteen months on DX Series digital video recorders, NVR300 Series network video recorders, and Endura[™] Series distributed network-based video products.
- One year (except video heads) on video cassette recorders (VCRs). Video heads will be covered for a period of six months.
- Six months on all pan and tilts, scanners or preset lenses used in continuous motion applications (that is, preset scan, tour and auto scan modes).

Pelco will warrant all replacement parts and repairs for 90 days from the date of Pelco shipment. All goods requiring warranty repair shall be sent freight prepaid to Pelco, Clovis, California. Repairs made necessary by reason of misuse, alteration, normal wear, or accident are not covered under this warranty.

Pelco assumes no risk and shall be subject to no liability for damages or loss resulting from the specific use or application made of the Products. Pelco's liability for any claim, whether based on breach of contract, negligence, infringement of any rights of any party or product liability, relating to the Products shall not exceed the price paid by the Dealer to Pelco for such Products. In no event will Pelco be liable for any special, incidental or consequential damages (including loss of use, loss of profit and claims of third parties) however caused, whether by the negligence of Pelco or otherwise.

The above warranty provides the Dealer with specific legal rights. The Dealer may also have additional rights, which are subject to variation from state to state.

If a warranty repair is required, the Dealer must contact Pelco at (800)|5289-9100 or (559) 292-1981 to obtain a Repair Authorization number (RA), and provide the following information:

- 1. Model and serial number
- 2. Date of shipment, P.O. number, Sales Order number, or Pelco invoice number
- 3. Details of the defect or problem

If there is a dispute regarding the warranty of a product which does not fall under the warranty conditions stated above, please include a written explanation with the product when returned.

Method of return shipment shall be the same or equal to the method by which the item was received by Pelco.

RETURNS

In order to expedite parts returned to the factory for repair or credit, please call the factory at (800) 289-9100 or (559) 292-1981 to obtain an authorization number (CA number if returned for credit, and RA number if returned for repair).

All merchandise returned for credit may be subject to a 20% restocking and refurbishing charge.

Goods returned for repair or credit should be clearly identified with the assigned CA or RA number and freight should be prepaid. Ship to the appropriate address below

If you are located within the continental U.S., Alaska, Hawaii or Puerto Rico, send goods to:

Service Department

Pelco

3500 Pelco Way

Clovis, CA 93612-5699

If you are located outside the continental U.S., Alaska, Hawaii or Puerto Rico and are instructed to return goods to the USA, you may do one of the following:

If the goods are to be sent by a COURIER SERVICE, send the goods to:

Pelco

3500 Pelco Way

Clovis, CA 93612-5699 USA

If the goods are to be sent by a FREIGHT FORWARDER, send the goods to:

Pelco c/o Expeditors

473 Eccles Avenue

South San Francisco, CA 94080 USA

Phone: 650-737-1700

Fax: 650-737-0933

REVISION HISTORY

Manual #	Date	Comments
C3417M	8/06	Original version.
C3417M-A	9/06	Corrected illustration 7.
C3417M-B	11/06	Inserted compatibility table. Added serial port settings to Table E.

Pelco, the Pelco logo, Camciosure, Esprit, Genex, Legacy, and Spectra are registered trademarks of Pelco. Endura, ExSite, and Spectra III are trademarks of Pelco. DLP is a registered trademark of Texas Instruments, Inc.

@Copyright 2006, Pelco. All rights reserved.



Worldwide Headquarters 3500 Pelco Way Clovis, California 93612 USA

> USA & Canada Tel: 800/289-9100 Fax: 800/289-9150

International Tel: 1-559/292-1981 Fax: 1-559/348-1120

www.pelco.com

IS09001

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com