

One Year Limited Warranty

This product is warranted against defects in materials or workmanship for one (1) year from date of original purchase for the original purchaser. It does not cover damages or wear resulting from accident, misuse, abuse, or unauthorized adjustment and/or repair. Should this product require service (or replacement at our option) while under warranty, please pack the item carefully and return it prepaid, along with receipt showing date of purchase and a note explaining reason for return to:

Taylor Precision Products

2220 Entrada Del Sol
Las Cruces, New Mexico 88001 USA
Customer Service Phone: 1-800-225-4834
Customer Service Fax: 1-575-526-4347
www.taylorusa.com

There are no expressed warranties except as listed above. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

©2012 Taylor Precision Products, Inc. and its affiliated companies, all rights reserved. Taylor® and Leading the Way in Accuracy® are trademarks of Taylor Precision Products, Inc. and its affiliated companies. All rights reserved.

**Made to our exact specifications in China.
NOT LEGAL FOR TRADE**

TR250SS 1.12R2

Congratulations on your purchase of a Taylor® Mechanical Receiving Scale. Your Taylor® scale is an example of superior design and craftsmanship. Please read this instruction manual carefully before use. Keep these instructions handy for future reference.

General Operation


1. Place the scale on a hard, level surface.
2. Allow the scale to reach room temperature before use.
3. Place a weight on the scale and allow the pointer to come to rest.
4. Remove the weight and allow the pointer to come to rest.
5. Repeat this cycle two or three times. Remove the weight from the platform. Adjust the pointer to zero using the adjustment dial on the right side of the scale.
6. If the scale is relocated or bumped during weighing, a readjustment to zero may be required. To do so, repeat the above steps. When weighing, evenly distribute weight on the platform.
7. Place a weight on the platform. Wait a few seconds for the dial to come to rest. If the dial window is not visible, press down on the **"PRESS TO LOCK"** lever

TAYLOR® Heavy Duty Stainless Steel Receiving Scale

TR250SS

Capacity: 250lb x 1lb

Leading the Way in Accuracy®



Instruction Manual

General Operation *Continued*

located under the dial window. This will lock the dial in place, so when the item is removed, the pointer will still indicate the weight.

8. Pull up the **"PRESS TO LOCK"** lever to release the dial for the next weighing.

Care and Maintenance

1. The body and the mechanism are not dishwasher safe. Immersing the scale in water may trap liquid between the lens and the body that can not be effectively dried out. This damage will void the warranty.
2. An occasional cleaning of exposed parts with a soft, slightly damp cloth will keep your Taylor® scale clean and attractive. To remove stains, use a mild soap. Never use detergents, excess water, treated cloths, harsh cleaning agents, or sprays. Your Taylor® scale does not require oiling or lubrication of any kind.
3. Do not tamper with the scale's internal components. Doing so will invalidate the warranty on this scale and may cause damage. The scale contains no user-serviceable parts.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>