



# myPDFmanuals

You can read the recommendations in the user guide, the technical guide or the installation guide for WHIRLPOOL RBS305PV. You'll find the answers to all your questions on the WHIRLPOOL RBS305PV in the user manual (information, specifications, safety advice, size, accessories, etc.). Detailed instructions for use are in the User's Guide.

## User manual WHIRLPOOL RBS305PV User guide WHIRLPOOL RBS305PV Operating instructions WHIRLPOOL RBS305PV Instructions for use WHIRLPOOL RBS305PV Instruction manual WHIRLPOOL RBS305PV

### Whirlpool® 30" (76.2 CM) ELECTRIC SINGLE AND DOUBLE BUILT-IN OVEN

#### PRODUCT MODEL SERIES

GBD309PV RBD307PV  
GBS305PV RBS305PV  
RBD305FPV RBS307PV

**Electrical Requirements:** Oven must be connected to the proper electrical voltage and frequency as specified on the model/serial number rating plate. The model/serial number rating plate is located at the bottom of the right-hand mounting rail. See the following illustrations.



Single Oven A: Mounting rail on cabinet plate  
Double Oven A: Mounting rail on cabinet plate


Models rated from 7.3 to 9.6 kW at 240 volts (5.5 to 7.2 kW at 208 volts) require a separate 40 amp circuit. Models rated at 7.2 kW and below at 240 volts (5.4 kW and below at 208 volts) require a separate 30 amp circuit.

A circuit breaker is recommended. Connect directly to the circuit breaker box (or fused disconnect) through flexible, armored or nonmetallic, sheathed copper cable (with grounding wire). Flexible conduit from the oven should be connected directly to the junction box. Do not cut the conduit. The length of conduit provided is for serviceability of the oven. A UL listed or CSA approved conduit connector must be provided. If the house has aluminum wiring, follow the procedure below:

1. Connect a section of solid copper wire to the pigtail leads.
2. Connect the aluminum wiring to the added section of copper wire using special connectors and/or tools designed and UL listed for joining copper to aluminum.

Follow the electrical connector manufacturer's recommended procedure. Aluminum/copper connections must conform with local codes and industry accepted wiring practices.


#### PRODUCT DIMENSIONS



Single Oven  
A: 28 1/2" (72.6 cm) max. cabinet width  
B: 27" (68.6 cm) max. oven height  
C: 26 1/2" (67.3 cm) max. oven depth  
D: 27" (68.6 cm) max. recessed depth  
E: 27 1/2" (70.2 cm) max. recessed height


Double Oven  
A: 28 1/2" (72.6 cm) max. recessed width  
B: 51" (129.5 cm) max. overall height  
C: 26 1/2" (67.3 cm) max. oven depth  
D: 27" (68.6 cm) max. recessed depth  
E: 28 1/2" (72.6 cm) max. recessed height

#### CABINET DIMENSIONS



Single Oven Installed in Cabinet  
A: 30" (76.2 cm) min. cabinet width  
B: 1" (25.4 mm) max. gap at top of cabinet  
C: 30" (76.2 cm) max. cabinet depth  
D: 27" (68.6 cm) max. cabinet height  
E: 1 1/2" (38.1 mm) max. cabinet depth  
F: 27 1/2" (70.2 cm) max. cabinet height

Double Ovens Installed in Cabinet  
A: 30" (76.2 cm) min. cabinet width  
B: 1" (25.4 mm) max. gap at top of cabinet  
C: 26 1/2" (67.3 cm) max. cabinet depth  
D: 27" (68.6 cm) max. cabinet height  
E: 1 1/2" (38.1 mm) max. cabinet depth  
F: 28 1/2" (72.6 cm) max. cabinet height



Cabinet Size View - Single or Double Oven  
A: 30" (76.2 cm) min. cabinet depth  
B: 27" (68.6 cm) max. recessed oven depth  
C: Oven front  
D: Recessed oven  
E: Cabinet

Single Oven Undercounter (without knocktop) installed in cabinet  
A: 30" (76.2 cm) min. cabinet width  
B: 1" (25.4 mm) max. gap at top of cabinet  
C: 26 1/2" (67.3 cm) max. cabinet depth  
D: 28 1/2" (72.6 cm) max. cabinet height  
E: 27 1/2" (70.2 cm) max. cabinet height

Because Whirlpool Corporation policy includes a continuous commitment to improve our products, we reserve the right to change materials and specifications without notice. Dimensions are for planning purposes only. For complete details, see installation instructions packed with product. Specifications subject to change without notice. Ref: W117121000 09-05-08



[Your user manual](#)  
[WHIRLPOOL RBS305PV](#)

**Manual abstract:**

Approved Built-In Oven and Electric Cooktop Combinations A B C C F D E G H A. 24" (61 cm) cabinet depth B. 25" (63.5 cm) countertop depth C. Recommended oven and cooktop junction box locations D. Allow 1" (1.6 cm) for oven trim to overlap on each side. E. 27¾" (70.5 cm) minimum cutout height F.

36" (91.4 cm) from cabinet base to countertop G. 4" (11.7 cm) from floor H. See Cutout Dimensions chart.

CUTOUT DIMENSIONS Oven Size 24" (61 cm) 27" (68.6 cm) 30" (76.2 cm) 36" (91.4 cm) Oven Cutout Dimension 22½" (57.2 cm) 25½" (64.8 cm) 28½" (72.4 cm) 34½" (87.6 cm) For the approved model number combinations, refer to the undercounter label located on top of the oven chassis and on the bottom of the cooktop burner box. NOTE: For undercounter installation, it is recommended that the junction boxes for oven and cooktop be located in the adjacent right or left cabinet. A 1" (2.5 cm) minimum diameter hole should have been drilled in the upper rear right or left corner of the side wall surface to pass the appliance cable through to the junction box. On models with Steam-Assist, it will be necessary to drill a ½" (1.3 cm) minimum diameter hole in the upper right or left rear corner of the side wall to pass the water supply tubing through to the undersink water filter. If water supply tubing hole is drilled on the same side as the oven cable hole, a minimum of 2" (5.1 cm) is required between the 2 holes.

WI0373101A Approved Built-In Oven and Induction Cooktop Combinations A B C C F D E G H A. 24" (61 cm) cabinet depth B. 25" (63.5 cm) countertop depth C. Recommended oven and cooktop junction box locations D. Allow 1" (1.6 cm) for oven trim to overlap on each side. E. 27¾" (70.5 cm) minimum cutout height F.

36" (91.4 cm) from cabinet base to countertop G. 3" (9.2 cm) from floor H. See Cutout Dimensions chart.

CUTOUT DIMENSIONS Oven Size 24" (61 cm) 27" (68.6 cm) 30" (76.2 cm) Oven Cutout Dimension 22½" (57.2 cm) 25½" (64.8 cm) 28½" (72.4 cm) 34½" (87.6 cm) For the approved model number combinations, refer to the undercounter label located on top of the oven chassis and on the bottom of the cooktop burner box. NOTE: For undercounter installation, it is recommended that the junction boxes for oven and cooktop be located in the adjacent right or left cabinet. A 1" (2.5 cm) minimum diameter hole should have been drilled in the upper rear right or left corner of the side wall surface to pass the appliance cable through to the junction box. On models with Steam-Assist, it will be necessary to drill a 1" (1.3 cm) minimum diameter hole in the upper right or left rear corner of the side wall to pass the water supply tubing through to the undersink water filter. If water supply tubing hole is drilled on the same side as the oven cable hole, a minimum of 2" (5.1 cm) is required between the 2 holes. 2 Approved Built-In Oven and Gas Cooktop Combinations A B C D E F G I J L K E D H M N A. 24" (61 cm) cabinet depth B.

1" (2.5 cm) clearance to bottom of countertop C. 25" (63.5 cm) countertop depth D. Recommended oven junction box locations E. 1" (2.5 cm) clearance to cabinet F. 27¾" (70.5 cm) minimum cutout height G. Allow 1" (1.6 cm) for oven trim to overlap on each side. H. 36" (91.4 cm) from cabinet base to countertop I. Gas line through wall 10½" (26.7 cm) to center of cutout J. 3¼" (8.3 cm) K. Gas line through floor 10½" (26.7 cm) to center of cutout L.

3½" (8.9 cm) M. 4" (11.7 cm) from floor N. See Cutout Dimensions chart. CUTOUT DIMENSIONS Oven Size 24" (61 cm) 27" (68.6 cm) 30" (76.2 cm) 36" (91.4 cm) Oven Cutout Dimension 22½" (57.2 cm) 25½" (64.8 cm) 28½" (72.4 cm) 34½" (87.6 cm) For the approved model number combination refer to the undercounter label located on top of the oven chassis. NOTE: For undercounter installation, it is recommended that the junction box for oven be located in the adjacent right or left cabinet. A 1" (2.5 cm) minimum diameter hole should have been drilled in the upper rear right or left corner of the side wall surface to pass the appliance cable through to the junction box. On models with Steam-Assist, it will be necessary to drill a ½" (1.3 cm) minimum diameter hole in the upper right or left rear corner of the side wall to pass the water supply tubing through to the undersink water filter. If water supply tubing hole is drilled on the same side as the oven cable hole, a minimum of 2" (5.1 cm) is required between the 2 holes.



[Your user manual](#)  
[WHIRLPOOL RBS305PV](#)

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>