



## SURFboard® DOCSIS® 3.0 eXtreme Cable Modems

- A** Power On Self Test (POST). If LED remains off, modem is faulty.
- B** Scanning downstream frequencies.
- C** Scanning upstream frequencies.
- D** Downstream and upstream acquired. Modem processing for DHCP, TFTP, and TOD.
- E** Ready. PC/Activity is solid when a CPE is connected and blinks when transmitting or receiving data.
- F** Powered off.
- G** Modem is successfully registered but Network Access Control (NACO) is disabled via DOCSIS configuration file.
- H** Performing firmware upgrade.



## LED Status


Notes	Power	Receive	Send	Online	Link	
A						Power On
B						Downstream Scan
C						Upstream Range
D						Network Connect
E						LINK/Channel Bond
F						Power Off
G						Network Access Off
H						Firmware Upgrade in Progress

- On (Receive and Send - Connected Single Channel)  
(Link - 10Base-T or 100Base-T Ethernet)

- Off

- On (Receive and Send - Connected Bonded Channel)  
(Link - High-speed Gigabit Ethernet)

- Flashing



Motorola, the stylized M Logo, and SURFboard are registered in the US Patent & Trademark Office. DOCSIS is a registered trademark of Cable Television Laboratories, Inc. All other product or service names are the property of their respective owners.

© Motorola Inc. 2010. All rights reserved.

571642-001-b 03/10

## Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>