4CCUSPLIT. ALLIANCE^T 390 TALKING PEDOMETER

OPERATING INSTRUCTIONS

SETTING UP

Push RESET button on left side of pedometer and hold until you hear "All clear." All results will be reset to zero

-Push and hold SET 1-2-4 (MODE) button until you hear "Enter your step length." -Press ♠ or ♥ to increase or decrease Step Length by one in. increments between 1-8 Feet (instructions for finding step length are below). -Press SET 1-2-4 button briefly. You will hear

"Enter your weight." -Press \blacklozenge or \blacktriangledown to increase or decrease Weight by one Lb., from 40 to 300 Lbs. -Press SET 1-2-4 again to exit the Setting Mode. -Press and hold "((.))" (SET3) to turn the auto voice report feature on or off. Unit will announce "Auto Report On (Off)" and "((.))" will appear (disappear) from display. -Clip the pedometer on your belt or clothing, near the outside of either hip. Ensure that the pedometer is in a vertical position for accurate recording.

-Attach the leash to your clothing as well. This will reduce the chance of the pedometer being lost, should it become dislodged.

STEP COUNT MODE (STEP)

RECISTER NOW Please return your AL390 Registration to the Repair Center address in the warranty, & we will let

User Email (preferred)

you know about future products

I

I

I

-Displays all the step count activity since last Reset.

-Press TALK, and the unit will announce your current step count. -Press MODE for Distance Mode.

DISTANCE MODE (MILES) -Displays the mileage walked since last Reset. -Press TALK, and the unit will announce mileage walked or ran

-Press MODE for Calorie Mode

CALORIE MODE (CAL)

-Displays the amount of calories burned through step activity since last Reset. -Press TALK, and the unit will announce number of calories burned.

-Press MODE for Time Mode.

TIME MODE (HR/MIN)

-Displays the amount of time spent in step activity since last Reset.

-Press TALK, and the unit will announce the amount of time spent in step activity. -Press MODE to return to STEP mode

IMPORTANT INFORMATION ABOUT

THE DISPLAYED NUMBERS -This pedometer uses an intelligent mechanism to ensure accurate recording of your activity level. While the Step counter records each and every step taken, the Distance, Time, and Calories Burned counters keep track of continuous activity (such as walking, running, dancing, etc.).

MEASURING YOUR STEP LENGTH

Measure your step length toe-to-toe or heel-toheel. Measure the distance you walk in 10 normal steps (moving each foot five times), then divide that distance by 10 to get a more accurate step length. For your reference, the average step length is around 22 inches.

AUTO VOICE ANNOUNCEMENT

When the Auto Voice Announcement mode is ON, the pedometer will announce your progress every 1,000 steps, 0.5 miles, 50 Calories, and every 10 minutes of activity.

POWER RESET AND CHANGING BATTERIES

-If display goes blank, or unit otherwise malfunctions, use a paper clip to depress the recessed RESET button on back of pedometer for five seconds.

-If the sound weakens, distorts, or the display dims, replace the batteries. This pedometer uses two AG13 cells housed in a tray that pulls out from the bottom of the unit. Be sure to match up battery polarity with the tray markings.

EXCLUSIVE DISTANCE ACCURACY TIP

After setting Stride Length per instructions above, maximize the accuracy of Distance measurement by:

-Walking a measured 0.5 or 1.0 mile/km. (we recommend that you use a 1/4-mile/400 meter track like those found at a "high school"). -Comparing the DISTANCE recorded to the measured distance, and

-If UNDER recorded, resetting the STEP LENGTH to a longer setting, or if OVER recorded, resetting the STEP LENGTH to a shorter setting

-Reset display to zero. -Walking the track again to test the adjustment,

and re-adjusting accordingly. -Once adjusted DO NOT ALLOW ANYONE ELSE TO CHANGE THE SETTING, because the Activity

Pedometer is now set for your style.

-You are now ready to walk any route, change that

route freely and still get an accurate measurement of distance for your fitness or recreation program.

1-800-965-2008 or 1-925-226-0888 FAX: 925-463-0147 support@accusplit.com www.accusplit.com

MADE IN PRCHINA © 2005 ACCUSPLIT

ACCUSPLIT ALLIANCE ACTIVITY PEDOMETER NO- PROOF-OF-PURCHASE LIMITED WARRANTY TW effubish-repair-replacement service, return with day phone# (between 7/1/06 and 0 add S8 fee) to: AST Repair Center, 2290A Ringwood Ave., San Jose, CA 95131 USA

For r 4/1/10

F

~

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com