

ALTO-SHAAM.

9

LOW TEMPERATURE COOKING **AND HOLDING GUIDELINES**

ecosmart

ALTO SHAAM. HALO HEAT.

Electronically Operated Ovens



ALTO SHAAM HALO HEAT

LOW TEMPERATURE COOKING AND HOLDING OVENS GENERAL INDEX

SECTION 1 • Low Temperature Cooking Introduction
Alto-Shaam Halo Heat1
Low Temperature Cooking Facts
Meat and Nutrition2
Shrinkage Control and Cooking Time3
Preventing Bacteria Growth3
Labor and Equipment Cost Reduction4
Options and Accessories

SECTION 2 • Low Temperature Cooking Operation General Operation — Manual Ovens

Oven Characteristics
Start-Up
Control Panel Identification
Cooking & Holding Procedures 12 - 18

SECTION 3 • Cleaning and Maintenance ... 19 - 20

SECTION 4 • Cooking Guideline

Product Index
Cooking Notes
Beef
Veal
Lamb
Pork
Processed Meats 43
Poultry
Fish
Miscellaneous

SECTION 5 • Smoker Operation
General Operation — Smokers
Cooking/Smoking/Holding Procedures 70
Smoking Times70
Hot Smoke71
Cold Smoke72

SECTION 6 • Cooking & Smoking Guidelines

Smoked Beef Brisket
Smoked Fresh Hams74
Smoked Pork Ribs75
Smoked Duck
Smoked Turkey
Smoked Cod
Smoked Salmon79
Smoked Shrimp 80
Smoked Beans81
Cold Smoked Salmon

SECTION 7 • Food Holding and Sanitation

Food Holding - Function & Value
General Holding Guidelines84
General Holding Cabinet Operation85
Holding Temperature Range85
Sanitation and Handling86
Food Safety Guidelines

W164 N9221 Water Street • P.O. Box 450 • Menomonee Falls, Wisconsin 53052-0450 • U.S.A. PHONE: (262)251-3800 (800)558-8744 u.s.a./caNada • FAX: (262)251-7067 (800)329-8744 u.s.a. • www.alto-shaam.com

ALTO SHAAM

HALO

Welcome to the cost saving convenience of Low Temperature Cooking.

In 1968, Alto-Shaam invented the first automatic, commercial cook and hold oven featuring the principle of Halo Heat. The heating method provided by Halo Heat low temperature cooking and holding ovens consists of an electric thermal cable that encircles the entire cooking and holding chamber. This creates a gentle blanket or HALO of radiant heat — surrounding food with a consistent and uniform temperature with no air movement inside the oven compartment. This gentle heating concept cooks at low temperatures and at a high level of humidity to preserve product moisture, flavor, and nutrition. Halo Heat ovens are designed to convert automatically from a cooking temperature to a holding temperature where the product can remain until it is ready to be served.

Halo Heat is an entirely different system of cooking. Utilizing this uniform heat source, Halo Heat dramatically reduces meat shrinkage; provides natural enzyme (aging) action for more tender, flavorful meat; and preserves natural juices along with nutritional values in all foods. Halo Heat cooking reduces energy cost, cuts back on labor and handling, and solves kitchen space problems. There is no mechanical ventilation or oven hood necessary in most areas so the ovens can be moved wherever they are needed.

Read this booklet carefully. Halo Heat is a cooking system that requires minimal care once you have learned the basic principles. For best results with many products, we recommend you start your cooking cycle the evening before — for serving the next day. In many areas, off-peak power rates are also lower at night.

If anything you cook in a Halo Heat low temperature cooking and holding oven doesn't meet your highest standards of quality, please contact one of our food service professionals for help. Usually, only a minor change in procedure is required.

LOW TEMPERATURE COOKING FACTS

MEAT AND NUTRITION

Meat plays a significant role in the diet; therefore, one of the primary goals in food preparation is proper nutrition. Meat is one of the best sources of protein; is a rich source of B vitamins such as thiamine, riboflavin, and niacin; and includes fats, carbohydrates, minerals, pigments, enzymes, and water.

All of these elements are affected by cooking, but over-heating destroys many of them. Low temperature Halo Heat cooking helps preserve unstable, heat-sensitive vitamins and nutrients. A report on the Nutrient Analysis of Roast Beef, conducted by the University of Wisconsin-Stout in July 1971, concluded, "...it is apparent that the Alto-Shaam cooking method results in lower moisture losses. Even after a 24 hour holding period, the Alto-Shaam product is nutritionally equal to, and possibly better than beef roast cooked in a conventional oven and removed immediately after cooking."

Fat contributes greatly to the flavor of meat. During the cooking process, fat not only melts, but also changes chemically. With low temperature cooking there is less chemical change and less fat melt resulting in a more flavorful finished product.

The enzymes found in meat break down the tissues and act as natural tenderizing agents. A premium price is paid for aged meats where this enzyme action has already started; however, enzymes are destroyed by high temperatures. Low temperature cooking does not destroy these enzymes and, particularly in the hold cycle, creates this natural chemical action to tenderize or age the meat right in the oven. For this reason, it is important to use fresh beef and it is essential to allow the product to remain in the hold cycle for at least the minimum amount of time suggested in the individual procedures. The longer meat is left in the hold cycle the more tender it becomes, making the purchase of more expensive, aged meat unnecessary.

Meat is seventy to seventy-five percent water. High temperatures cause this water to evaporate during cooking resulting in loss of product moisture. Cooking at low temperatures in a Halo Heat oven retains the maximum amount of water content resulting in a juicier finished product and an extended holding life.

Along with better nutrition, a more tender finished product, less shrinkage and higher moisture content, meat will not require the addition of as much salt as needed with conventional cooking methods. Natural flavors are preserved. This is a significant factor in today's health conscious diets.

LOW TEMPERATURE COOKING FACTS

SHRINKAGE CONTROL AND COOKING TIME

THERE ARE TWO MAJOR FACTORS CONTROLLING MEAT SHRINKAGE OR COOKING LOSSES.

1. Temperature at which meat is cooked:

The higher the temperature at which meat is cooked the more shrinkage will result. Over-cooked meat also results in higher losses. Higher temperatures and over-cooking draws moisture to the surface and this moisture evaporates or drips out of the meat.

2. Internal temperature of the meat:

Like over-cooking, as meat is brought to a higher internal temperature shrinkage is increased. For these two reasons, it is suggested most cuts of red meat be cooked at 250°F (121°C) and that all cooking be based on internal product temperature. The use of a metal-stemmed [pocket-type], indicating thermometer is encouraged.

THERE ARE FOUR MAJOR FACTORS INVOLVED IN DETERMINING COOKING TIMES FOR MEAT:

- 1. The degree of aging on the meat: Aged meat will cook faster, shrink more, and has a much shorter holding life than fresh meat.
- 2. Internal temperature before cooking:

Meat should be placed in a preheated oven directly from a refrigerated temperature of 38° to 40°F (3° to 4°C). Meat cooked from a frozen state will require approximately one and one-half to two times the normal cooking time. In addition, freezing ruptures tissue cells creating additional moisture loss during the cooking process and will result in more shrinkage.

3. Desired degree of doneness:

The higher the degree of internal temperature required, the longer the necessary cooking time. Cooking times in this guideline are based on the most popular internal product temperatures.

4. Quantity and quality of product.


TO CA	LCULATE ME	AT SHR	INKAGE					
STARTING WEIGHT (Weight of Raw Product)								
-MINUS	: ENDING WEIGHT (W	eight of Cook	ed Product)					
Ī	EQUALS: AMOUNT (OF SHRINKA	AGE					
	AMOUNT OF SHRINKAGE (Total Weight Lost in Cooking) ÷ DIVIDED BY: STARTING WEIGHT (Weight of Raw Product)							
E	QUALS: PERCENT	OF SHRINK	AGE					
EXAMPLE:	Raw Beef Roast: Cooked Beef Roast:	100 lb -95 lb	(45 kg) (-43 kg)					
= AMOU	NT OF SHRINKAGE:	5.0 lb	(2 kg)					
SHRINKAGE DIVIDED BY $0.05 = 5\%$ $0.05 = 5\%$ STARTING WEIGHT: $100 \sqrt{5.0}$ $45 \sqrt{2.0}$								
EQUALS: PERCENT OF SHRINKAGE								

PREVENTING BACTERIA GROWTH

The surface of raw meat may become contaminated in processing, handling by the butcher or chef, or by other means. Food contamination can also be caused by unsanitary personal hygiene and work habits, unclean slicers, knives, and probes, or by faulty operational procedures. It is important, therefore, that sanitary procedures be followed at all times during food preparation and handling. This is your main protection in guarding against food contamination. For additional information see the *Cleaning and Maintenance* section of this manual.

LABOR AND EQUIPMENT COST REDUCTION

Halo Heat ovens are easy to operate and maintain. After the raw product is placed in the oven and the controls are set, there is no need to check, stir, or adjust the time or the temperature. Minimal time is spent attending the product during cooking. This advantage, combined with the automatic conversion to the hold cycle, frees key personnel to concentrate on other tasks including final product and presentation.



When cooking in a Halo Heat oven at a temperature of 250°F (121°C), outside venting and expensive exhaust hoods are not necessary in most areas. Kitchens remain cooler, lowering energy costs by reducing the exchange of heated air. Because the ovens do not need outside venting, they can be put almost anywhere — in the corner of the kitchen, on a buffet line, or in a banquet room. The ovens can also be built into a counter or, to save space, can be stacked in combination with another Halo Heat oven or holding cabinet of the same or similar dimensions.

Cooking at low temperatures also reduces cleaning time. Most food does not normally carbonize or burn on the interior of the oven.



COOK AND HOLD OVENS



COMPACT COOK & HOLD

Single compartment oven with electronic controls and probe. All stainless steel construction. Stackable design.

MODEL	PRODUCT CAPACITY		ODUCT CAPACITY		OVERALL DIMENSIONS
NUMBER	POUNDS	SHELVES	12" x 20"	18" x 26"	H x W x D
AS-250	25	1	1	_	18-1/4" x 33-9/16" x 16-3/4"





SINGLE COMPARTMENT

Single compartment oven with 3-1/2" (89mm) casters, electronic controls and probe. All stainless steel construction. Stackable design.

MODEL		PRODU	JCT CA	OVERALL DIMENSIONS		
NUMBER	POUNDS	SHELVES	12" x 20"	18" x 26"	18" x 13"	H x W x D
500-TH/III	40	2	4	_	11**	33-1/16" x 18-1/16" x 25-7/16"
750-TH/III	100	3*	10	11**	22**	33-3/16" x 25-3/4" x 30-15/16"
1000-TH/III	120	3*	3**	8**	16**	39-7/8" x 22-5/8" x 30-3/4"



DOUBLE COMPARTMENT

Dual control, double compartment oven

with 5" (127mm) casters, electronic controls and probes.

HD: All Stainless Steel Exterior STD: Stucco Aluminum Exterior

MODEL	PRODUCT CAPACITY			ITY	OVERALL DIMENSIONS
NUMBER	POUNDS	SHELVES	12" x 20"	18" x 26"	H x W x D
1200-TH/III/HD	240	6*	6	16	75-9/16" x 22-9/16" x 31-3/16"
1200-TH/III/STD	240	6*	6	16	75-9/16" x 22-9/16" x 31-3/16"

*NUMBER OF SHELVES INCLUDED AS STANDARD.

EACH COMPARTMENT WILL ACCOMMODATE UP TO EIGHT WIRE SHELVES.

12" x 20" pan capacities are always based on 2-1/2" deep pans unless otherwise indicated.



MODEL		PRODUCT CA	OVERALL DIMENSIONS		
NUMBER	POUNDS	SHELVES	12" x 20"	18" x 26"	H x W x D
767-SK/III	100	2 FLAT WIRE SHELVES			
SMOKER		1 rib rack shelf	7	4*	33-3/16" x 25-3/4" x 30-15/16"
1767-SK/III	200	4 FLAT WIRE SHELVES			
SMOKER		2 RIB RACK SHELVES	14	8*	61-7/8" x 25-3/4" x 31-1/16"

*MAXIMUM CAPACITY SHOWN — ADDITIONAL WIRE SHELVES REQUIRED.

DESCRIPTION	1200-TH/III	1000-TH/III	750-TH/III	500-TH/III	AS-250
BUMPER, FULL PERIMETER RUBBER	5005103	5005103	5004861	5006782	—
CARVING HOLDER PRIME RIB STEAMSHIP ROUND	HL-2635 4459	HL-2635 4459	HL-2635 4459	HL-2635 4459	HL-2635 —
CASTER PACKAGE 2 RIGID, 2 SWIVEL W/ BRAKE 5" (127mm) 3-1/2" (89mm) 2-1/2" (64mm)	standard 5008017 —	5004862 standard 5008022	5004862 standard 5008022	5004862 standard 5008022	_
DOOR LOCK with KEY EACH HANDLE	LK-22567	LK-22567	LK-22567	LK-22567	_
DRIP PAN STANDARD WITH DRAIN, 1-7/16" (37mm) STANDARD WITH DRAIN, 1-11/16" (43mm) STANDARD WITH DRAIN, 1-7/8" (48mm) EXTRA DEEP, 2-7/16" (62mm)		 14824 1115	— 14831 — 1115	14813 — — —	
LEGS, 6" (ONE SET OF 4) FLANGED	5004863	5004863	5004863	5004863	—
PAN GRID, WIRE 18" x 26" PAN INSERT	PN-2115	PN-2115	PN-2115	—	—
SHELF, STAINLESS STEEL FLAT WIRE RIB RACK	SH-2325 SH-2773	SH-2325 SH-2773	SH-2324 SH-2743	SH-2326 —	SH-2786 —
STACKING HARDWARE		5004864	5004864	5004864	4928

COOK & HOLD SMOKERS — OPTI	ONS & ACC	CESSORIES
DESCRIPTION	767-SK/III	1767-SK/III
BUMPER, FULL PERIMETER RUBBER	5004861	5004861
CARVING HOLDER PRIME RIB	HL-2635	HL-2635
STEAMSHIP ROUND	4459	4459
CASTER PACKAGE 5" (127mm) - 2 rigid, 2 swivel w/ brake 3-1/2" (89mm) - 2 rigid, 2 swivel w/ brake 2-1/2" (64mm) - 2 rigid, 2 swivel w/ brake	5004862 standard 5008022	standard 5008017 —
DOOR LOCK with KEY EACH HANDLE	LK-2763	LK-2763
DRIP PAN STANDARD WITH DRAIN, 1-11/16" (43mm)	14831	14831
LEGS, 6" (ONE SET OF 4) FLANGED	5004863	5004863
PAN GRID, WIRE18" x 26" pan insert	PN-2115	PN-2115
SHELF, STAINLESS STEEL FLAT WIRE	SH-2324	SH-2324
RIB RACK	SH-2743	SH-2743
STACKING HARDWARE	5004864	—
WOOD CHIPS (20 lb bulk pack)		
Apple	WC-22543	WC-22543
Cherry	WC-22541	WC-22541
Hickory	WC-2829	WC-2829
Sugar Maple	WC-22545	WC-22545

OVEN CHARACTERISTICS

The cabinet is equipped with a special, low-heatdensity, heating cable. Through the **Halo Heat**[®] concept, the heating cable is mounted against the walls of the cooking and holding compartment to provide an evenly applied heat source, controlled by an oven sensor. The design and operational characteristics of the unit eliminate the need for a moisture pan or a heat circulating fan. Through even heat application, the food product is cooked uniformly and provides the ability to hold foods for longer periods of time.

HEAT RECOVERY


The patented SureTemp[™] heat recovery system in this oven reacts immediately to compensate for any loss of heat whenever the door is opened. If the door remains open for more than three minutes, the solid state electronic control will sound three rapid beeps every ten seconds until the door is closed.

START-UP

- **1. Before operating the oven,** clean both the interior and exterior of the oven with a damp cloth and any good commercial detergent at the recommended strength. Rinse surfaces by wiping with a sponge and clean warm water to remove all detergent residue. Wipe dry with a clean cloth or air dry.
- **2. Wipe door gaskets** and control panel dry with a soft cloth.
- **3. Clean and install** the oven side racks, oven shelves, and external drip tray. Shelves are installed with curved edge up and toward the back of the oven. Insert the drip pan on the interior bottom surface of the oven.
- 4. Before operating the oven with product, become familiar with the operation of the controls. Read the following "Control Identification and Function" and the "Control Operation" sections of this cooking guide and begin by operating the various control functions.

DANGER AT NO TIME SHOULD THE INTERIOR OR EXTERIOR BE STEAM CLEANED, HOSED DOWN, OR FLOODED WITH WATER OR LIQUID SOLUTION OF ANY KIND. DO NOT USE WATER JET TO CLEAN. SEVERE DAMAGE OR ELECTRICAL HAZARD COULD RESULT. WARRANTY BECOMES VOID IF

APPLIANCE IS FLOODED



1. ON/OFF KEY

• The ON/OFF control system key operates the functions of the control panel. If there is any power loss during operation, the ON/OFF indicator light will flash. To clear, push key and release.

2. COOK KEY

- Temperature range 200° to 325°F (93° to 162°C).
- Used to select cooking mode and to review the cook temperature setting.

3. TIME KEY

- Maximum time 24 hours.
- Used to select cook time and to review set time.

4. PROBE KEY

- Temperature range 50° to 195°F (10° to 91°C).
- Used to select internal product probe temperature mode and to review probe temperature setting.

5. HOLD KEY

- Temperature range 60° to 205°F (15° to 96°C).
- Used to select food holding mode and to review the holding temperature.

6. LOCK INDICATOR

 When illuminated, this symbol indicates that the settings used in the cooking sequence are locked and cannot be changed. Lock function is controlled by preset key "I" — ITEM ⁽⁷⁾.

7. OVEN PREHEAT INDICATOR

• Illuminates until the oven is preheated.

8. LED DISPLAY

• Indicates interior oven air temperature, internal product probe temperature, and time. When used in conjunction with other keys, the display will review original cooking, holding, and probe temperature settings. The display will also indicate various programming and diagnostic information.

9. READY INDICATOR LIGHT

• Illuminates when the oven has finished preheating or has finished a cook cycle.

10. UP AND DOWN ARROWS

• Used to increase or decrease set time, in addition to cooking, holding, and probe temperature settings.

CONTROL IDENTIFICATION & FUNCTION

11. START KEY

• Used to initiate a selected mode sequence when pressed and released. Any mode of operation can be stopped by pressing and holding the Start Key until the control produces an audible signal.

12. GREEN INDICATOR LIGHTS

• Located within each function key, the green light functions as an operator prompt to indicate additional operator action is required. These indicators also identify current mode of operation.

13. AMBER INDICATOR LIGHTS

- Located below the Cook, Time, Probe and Hold Keys, these indicators will illuminate to identify the current mode of operation and allows the operator to identify the information currently shown in the LED display.
- SMOKER KEY (ON COOK/ HOLD/ SMOKER MODELS ONLY)
 Smoking can be accomplished in any of the cook and hold modes. This function key can also be used to cold smoke product. Load the smoker tray with the recommended wood chips prior to engaging key. *See page 70 of this manual for operation instructions.*

15. HALO HEAT INDICATOR

• When the oven is preheating, the Halo Heat indicator will illuminate and remain steady until the oven reaches the set cooking temperature. When the temperature has stabilized, the indicator will illuminate periodically as the oven calls for heat.

16. PRESET PROGRAM KEYS

• Provides memory storage and operation of up to eight operator set cooking programs for specific products (A thru H).

17. LOCK KEY

• "I" enables and disengages control locking function indicated by the lock indicator light (ITEM 6).

18. CANCEL KEY

• Used to erase a program from memory storage.

AUDIBLE SIGNALS

The audible signal or **OVEN BEEP** is used to indicate a **YES** or **NO** response to operator input. ((These signals also indicate mode changes and error conditions.

One brief beep indicates a **YES** (enabled) response to the information entered into the control.

Two brief beeps indicate a **NO** (disabled) response to the information entered into the control.

A beep that lasts for one second indicates an oven mode transition. EXAMPLE: Preheat to Ready-Start.

Three brief beeps indicate the oven is in the **READY MODE** for product loading and start-up.

Four brief beeps indicate an existing fault condition. Refer to Trouble Shooting in the Operation & Care Manual.

Beeper volume can be changed. With the control in the **OFF MODE, PRESS AND HOLD** the Down $\mathbf{\nabla}$ Arrow key. After 4 seconds, the display will indicate one of the four volume levels consisting of "**O**" for volume **OFF** to setting number "**3**" which is the highest volume available. Release the Down $\mathbf{\nabla}$ Arrow key after each change and repeat the process to select the next volume level.



CONTROL IDENTIFICATION & FUNCTION

OPERATING FEATURES



To turn the oven control panel ON and OFF: *Press and hold* the ON/OFF Key for three seconds. The oven will beep once. The ON/OFF indicator light will illuminate for oven ON condition and will go out for an OFF condition.



To Stop an Operation:

PRESS AND HOLD the Start Key for several seconds until the control beeps to indicate the operation has been cancelled. The oven will remain in a POWER-ON state.



Arrow Keys:

COOK, HOLD and PROBE TEMPERATURE set points can be adjusted by 1° by pressing the Arrow Keys. To change a set point more rapidly, *press and hold* the Arrow Key along with the key for the oven mode function being changed and the temperature will change in steps of 10°F or 5°C.

The **TIME** setting is adjusted in increments of one minute by pressing the Arrow Keys. To make a more rapid adjustment, *press and hold* the Time Key and Arrow Key together to change the time in steps of ten minutes.

Probe Usage:



When the probe is left in the probe bracket, the LED temperature display will indicate the ambient air temperature inside the oven. To use the probe for cooking, remove the metal probe from the bracket and wipe the full probe length with a disposable alcohol pad to clean and sanitize before inserting in a product.

Only the tip of the probe senses the internal product temperature, therefore, it is important the tip of the probe is properly placed in the product for internal temperature accuracy. Push the probe tip halfway into the product, positioning the tip at the center of the food mass. When inserting the probe into solid foods such as a meat roast or poultry, push the probe in from a straight downward position or in from the side to the center position. If placing the probe into a semi-liquid or liquid product, the probe cable must be secured to keep the probe positioned properly. Do not let the probe tip touch the edges, bottom, or side of a container. Tape the probe cable to the lip or edge of the container.

Display High/ Low Probe Temperatures:

To observe the recorded maximum or minimum probe temperature during a cooking program, press the following keys:

Highest Temperature: Press Probe key and Up ▲ Arrow key at same time.

Lowest Temperature: Press Probe key and Down ▼ Arrow key at same time.


Halo Heat Indicator:

When the oven is preheating, the Halo Heat indicator light (5) will remain illuminated until it reaches the set cook temperature. Once the temperature has stabilized, this indicator will illuminate periodically as the oven calls for heat.

Green and Amber Indicators:


Each program key includes a green light ⁽¹⁾ which indicates a requirement for additional programming by the operator or the current operational state of the oven.

The COOK, TIME, PROBE, and HOLD keys include an amber indicator light (3) to identify the information being displayed.



Power Fail Detect:

If the power were to fail for any reason while heating, the control memory will retain the programmed operating conditions. When power is restored, the control will resume operating from the point it was interrupted and the ON/OFF indicator light will flash, indicating that such an event did occur. The operator can turn off the flashing light by pressing the ON/OFF key. *If such an event occurs, it is strongly recommended that steps are taken to ensure the food is kept safe for consumption in accordance with local health* (hygiene) regulations.



Beeper Volume Selection

With the control in the *OFF mode*, *press* and hold the Down \blacksquare Arrow key.



After 4 seconds, the display will indicate one of the four volume levels consisting of "**0**" for volume **oFF** to setting number "**3**" which is the highest volume available. Release the Down ▼ Arrow key after each change and repeat the process to select the

next volume level.

Preset Keys Lock and Unlock

Preset Keys A through H can be locked in order to prevent storing a new program, altering an existing program or erasing a current program. To lock the preset keys, *press and hold* the "I" key for four seconds. The oven will beep. Release the "I" key. The green indicator on the "I" key will illuminate. Oven Preset Keys A through H are now locked.

Note: Only the oven Preset keys A through H are affected by this lock-out which will allow the oven to be used in an unprogrammed Cook, Probe, or Hold mode.

To unlock the Preset keys, *press and hold* the Cancel Key along with the "I" key for four seconds. The oven control will beep. Release all keys. The green indicator on the "I" key will extinguish to indicate the oven preset keys are no longer locked.

Fahrenheit or Celsius Selection

With the control in the *OFF mode*, *press* and hold the Up ▲ Arrow key. After 4 seconds, "°**F**" or "°**C**" will show in the display. Release the arrow key.

Press and hold the Up \blacktriangle Arrow key again to change to the opposite display setting.

Control Panel Lock and Unlock

The control panel can be locked at any time in order to prevent inadvertent or accidental setting changes. To lock the control panel, *press and hold* the Up \blacktriangle Arrow key and then press the ON/OFF key. The oven will produce a brief beep and the panel lock indicator ③ will illuminate. Release all keys. The oven control panel is now locked.

NOTE: The control panel is now fully locked with the exception of the ON/OFF key and Arrow keys. When the control panel is locked, the oven control cannot be turned to the *OFF* position.

To unlock the control panel, *press and hold* the Down \checkmark Arrow key followed by pressing the ON/OFF Key. The oven control will produce two brief beeps and the panel lock indicator will extinguish. Release all keys. The panel is now unlocked and ready for normal use.



OOK BY PROBE:

PRESS AND RELEASE ON/OFF KEY.



- The green indicator light on the ON/OFF key will illuminate.
- The oven will beep for one second and will begin operating in the hold mode.
- The amber hold indicator will illuminate.
- The previously set hold temperature will be displayed.



PRESS COOK KEY TO PREHEAT

• The green indicator light on the COOK Key will illuminate.

- Last set cooking temperature will be displayed.
 - ► To change the cook temperature, press the Up \blacktriangle or Down \checkmark Arrow key.
- The green indicator light on the Time Key and on the Probe Key alternately flash.

PRESS PROBE KEY

- The green indicator light on the PROBE Key will illuminate.
- Last set internal product temperature is displayed.
 - ► To change the internal product temperature, press the Up \blacktriangle or Down ▼ Arrow key.
- The green indicator light on the Probe Key will illuminate.
- Halo Heat and Pre-Heat indicator will illuminate.
 - ► The oven is automatically programmed to preheat to the cook temperature.
- The oven will beep when preheated and the preheat indicator light will go out.
- Both the Ready and Start indicator lights will flash.
 - ➡ The set cook temperature will be maintained by the oven and will appear in the display while in the ready/start mode.



PRESS HOLD KEY

- To change the hold temperature, press the Up \blacktriangle or Down \blacktriangledown Arrow key.
- **NOTE:** If the oven is being used for hot food holding only, adjust the set holding temperature. **Do not** press the COOK, TIME, or PROBE keys.

LOAD THE FOOD INSIDE OVEN. REMOVE **PROBE FROM ITS BRACKET. WIPE THE** PROBE TIP WITH A DISPOSABLE ALCOHOL PAD AND INSERT PROBE PROPERLY INTO THE PRODUCT. CLOSE THE OVEN DOOR.

NOTE: The oven will beep 3 times every 25 seconds until the oven is loaded and the Start Key pressed.

BEFORE PRESSING THE START KEY:

To prevent a false probe temperature reading, wait for 60 seconds after inserting the probe into the product to allow the preheated oven probe temperature to decrease to the internal temperature of product.

ふ

START

AFTER 60 SECONDS PRESS AND RELEASE START KEY.

- The oven will beep.
- The green indicators for power, cook, probe, and start will illuminate.
- The display will alternate between showing the set cook temperature and the elapsed time.

СООК

- The oven will beep when the set probe temperature has been reached.
- The green indicator for cook will remain illuminated.
- The display will alternate between showing the set hold temperature and the amount of time the product has remained in the holding mode.

HOLD

- The Ready indicator light will illuminate after 2 hours in the hold mode.
 - **NOTE:** The ready indicator does not necessarily indicate a product-ready state. For best results, the product must remain in the oven at the set holding temperature for the minimum number of hours indicated in the individual cooking instructions.
- The oven will remain operating in the hold mode until the control ON/OFF Key is pressed.



COOK BY TIME:



PRESS AND RELEASE ON/OFF KEY.

- The green indicator light on the ON/OFF key will illuminate.
- The oven will beep for one second and will begin operating in the hold mode.
- The amber hold indicator will illuminate.
- The previously set hold temperature will be displayed.



PRESS COOK KEY TO PREHEAT

- The green indicator light on the COOK Key will illuminate.
- Last set cooking temperature will be displayed.
 - To change the cook temperature, press the Up ▲ or Down ▼ Arrow key.
- The green indicator light on the Time Key and on the Probe Key alternately flash.



PRESS TIME KEY

- The green indicator light on the TIME Key will illuminate.
- Last set time is displayed.
- ➡ To change the cook time, press the Up
 ▲ or Down ▼ Arrow Key.
- The green indicator light on the Time Key will illuminate.
- Halo Heat and Pre-Heat indicator will illuminate.
 - The oven is automatically programmed to preheat to the cook temperature.
- The oven will beep when preheated and the preheat indicator light will go out.
- Both the Ready and Start indicator lights will flash.
 - The set cook temperature will be maintained by the oven and will appear in the display while in the ready/start mode.



PRESS HOLD KEY

- To change the hold temperature, press the Up ▲ or Down ▼ Arrow key.
- **NOTE:** If the oven is being used for hot food holding only, adjust the set holding temperature. <u>Do not</u> press the COOK, TIME, or PROBE keys.

Load the food inside oven and close the oven door.

NOTE: The oven will beep 3 times every 25 seconds until the oven is loaded and the Start Key pressed.

PRESS AND RELEASE START KEY.

- The oven will beep.
- The green indicators for power, cook, time, and start will illuminate.
- The display will alternate between showing the set cook temperature and the remaining time.

соок

な

- The oven will beep at the end of the timed cooking cycle.
- The green indicator for cook will remain illuminated.
- The display will alternate between showing the set hold temperature and the amount of time the product has remained in the holding mode.

HOLD

- The Ready indicator light will illuminate after 2 hours in the hold mode.
 - **NOTE:** The ready indicator does not necessarily indicate a product-ready state. For best results, the product must remain in the oven at the set holding temperature for the minimum number of hours indicated in the individual cooking instructions.
- The oven will remain operating in the hold mode until the control **ON/OFF** key is pressed.





PROGRAMMING:

PRESET MENU KEYS

Alto-Shaam Cook and Hold ovens allow the operator to set up to eight cooking programs. Each cooking program can be preset in any program mode to cook by time or internal product temperature. Cooking programs are recalled and stored using the Preset Keys labeled "A through H." These keys, along with the key labeled "I" share additional functions described in the "User Options" section of this guide.

TO PROGRAM A COOKING PROCEDURE

Select the product to be programmed and begin with the oven control power OFF.



PRESS AND RELEASE ON/OFF KEY

- The oven will beep for one second and power to the unit will be indicated by an illuminated green indicator light located in the upper left corner of the **ON/OFF** key.
- The oven will begin operating in the hold mode.
- The amber hold indicator will be illuminated and the last set hold temperature will be displayed.



PRESS COOK KEY TO PREHEAT

- The green indicator light on the COOK Key will illuminate.
- Last set cooking temperature will be displayed.
- → To change the cook temperature, press the Up \blacktriangle or Down \blacktriangledown Arrow key.



TO COOK BY PROBE: PRESS PROBE KEY

- Last set internal product temperature is displayed.
 - To change the internal product temperature, press the Up ▲ or Down ▼ Arrow key.



TO COOK BY TIME: PRESS TIME KEY

- Last set time is displayed.
 - ➡ To change the cook time, press the Up ▲ or Down ▼ Arrow Key.



PRESS HOLD KEY

→ To change the hold temperature, press the Up \blacktriangle or Down \checkmark Arrow key.



PROGRAMMING:

THE OVEN PREHEAT INDICATOR WILL ILLUMINATE.

The oven is now in the preheat mode and is automatically programmed to preheat to the cook temperature.

Select a letter code for the product programmed by the previous steps.

PRESS AND HOLD THE SELECTED PRESET KEY UNTIL YOU HEAR A BRIEF, FOUR SECOND BEEP.



- The letter key program indicator light will illuminate.
- The product programmed is now stored in memory for the specific letter key pressed.
- Additional programs can be stored in the remaining Preset Keys if not previously programmed.
- **NOTE:** The last Preset Key used will be the oven cooking run sequence for the next product to be programmed. Settings can be manually changed for the next product and an alternate pre-programmed letter key can be selected.

IMPORTANT:

After programming a specific product into memory in a programmable preset key, it is very important to make a permanent written record of the product and the program letter assigned. Menu card (PE-23384) is provided for this purpose.

ERASING A COOKING PROGRAM:



To erase a program no longer used, or to revise a previously programmed Preset Key, the oven must be in either the power-up hold mode or in the preheat mode. The oven cannot be running a Preset Menu program at the time of cancellation or revision. When the oven is in the power-up hold mode or in the preheat mode, press and hold both the Cancel Key and the appropriate letter Preset Key to be erased. The oven will beep in approximately four seconds and the program's indicator light will go out to indicate the program has been erased.



PROGRAMMING:

COOKING WITH PRESET MENU KEYS:



PRESS AND RELEASE ON/OFF KEY.

- The green indicator light on the **ON/OFF** key will illuminate.
- The oven will beep for one second and will begin operating in the hold mode.
- The amber hold indicator will illuminate.
- The previously set hold temperature will be displayed.
- A green indicator on each *programmed* Preset Key will illuminate.

PRESS PROGRAMMED PRESET KEY DESIRED

(A THROUGH H)

PRESETS	1	A
	<u> </u>	

- Halo Heat indicator and Pre-Heat indicator will illuminate.
- The oven will automatically preheat to the programmed cook temperature.
- The oven will beep when preheated and the preheat indicator will go out.
- Both the Ready and Start indicator lights will flash.
- The set cook temperature will be maintained by the oven and appear in the display while in the ready/start mode.

LOAD THE FOOD INSIDE OVEN. IF COOKING BY PROBE, REMOVE PROBE FROM ITS BRACKET, WIPE THE PROBE TIP WITH A DISPOSABLE ALCOHOL PAD AND INSERT PROBE PROPERLY INTO PRODUCT. CLOSE THE OVEN DOOR.

NOTE: The oven will beep 3 times every 25 seconds until the oven is loaded and the Start key pressed.



PRESS AND RELEASE START KEY.

- The oven will beep.
- The green indicators for power, cook, probe or time, and start will illuminate.
 - If programmed to cook by time, the display will alternate between showing the set cook temperature and the time remaining.
 - If programmed to cook by probe, the display will alternate between showing the set cook temperature and the elapsed time.

соок

- The oven will beep when the set probe temperature has been reached or set time has elapsed.
- The green indicator for cook will remain illuminated.
- The display will alternate between showing the set hold temperature and the amount of time the product has remained in the holding mode.

HOLD

- The Ready indicator light will illuminate after 2 hours in the hold mode.
 - **NOTE:** The ready indicator does not necessarily indicate a product-ready state. For best results, the product must remain in the oven at the set holding temperature for the minimum number of hours indicated in the individual cooking instructions.
- The oven will remain operating in the hold mode until the control **ON/OFF** Key is pressed.

GENERAL COOKING GUIDELINES:

1. PREPARE OVEN FOR COOKING

- A. Insert and adjust the required number of shelves inside the cooking compartment.Place the curved edge of the shelf toward the back of the oven.
- B. Adjust the inside door vents as indicated in the individual cooking procedure selected.
- C. Insert drip pan directly on the bottom surface of the oven compartment.

2. PREHEAT OVEN

A. Refer to control operation to cook by probe, time, or preset program menu keys.

3. PREPARE PRODUCT FOR COOKING

A. Refer to individual cooking instructions.

4. LOAD PRODUCT ON SHELVES

- A. Refer to individual cooking instructions. <u>DO NOT</u> overload the oven.
- B. Most meat products are cooked directly on wire shelves. For many products, the use of pans is not recommended.

5. CLOSE DOOR

A. Keep door closed during the cooking cycle.

6. OVERNIGHT COOK AND HOLD

A. For maximum meat tenderizing and to reduce labor during peak preparation hours, overnight cook and hold is highly recommended for many products. Refer to individual cooking instructions.

7. DETERMINING IF PRODUCT IS COOKED

A. Before opening the oven door, leave the product in the "HOLD" cycle for a minimum of one hour. This time period will allow the oven temperature to decrease from the "COOK" setting to the selected "HOLD" temperature. During this one hour period, the product will continue to cook.

8. REHEATING

- A. Any over production must be removed from the oven, wrapped, rapidly chilled, and refrigerated.
- B. Product can be removed from refrigerator, returned to the oven, and reheated the next day.
- C. Products must be reheated at a temperature range of 250° to 275°F (121° to 135°C). Refer to individual cooking instructions for the correct thermostat setting for the product being reheated.

D. Length of time necessary to reheat a product depends on the type of product and the quantity to be reheated. Time should be based on internal product temperature. Use a pocket thermometer or the oven probe to determine the internal product temperature of the reheated product.

United States food code requirements indicate cooked foods that have been cooled, followed by reheating for hot food holding, must be reheated to 165°F (74°C). The temperature of 165°F (74°C) must be maintained for a period of 15 seconds.

NOTE: Always follow federal and local health (hygiene) codes for the time and internal temperature required for reheating products.

In the United States, FDA food code requires products such as red meat to remain in "HOLD" for a specified time period. This holding time requirement is based on the internal product temperature desired for the finished product and includes the one hour time period while the oven decreases from the cooking temperature to the holding temperature and the product continues to cook.

INTERNAL PRODUCT TEMPERATURE	TIME* IN HOLD CYCLE REQUIRED BY FOOD CODE					
130°F (54°C)	1 HOUR, 52 MINUTES					
131°F (55°C)	1 HOUR, 29 MINUTES					
133°F (56°C)	56 MINUTES					
135°F (57°C)	36 MINUTES					
136°F (58°C)	28 MINUTES					
138°F (59°C)	18 MINUTES					
140°F (60°C)	12 MINUTES					
142°F (61°C)	8 MINUTES					
144°F (62°C)	5 MINUTES					
145°F (63°C)	4 MINUTES					
147°F (64°C)	2 MINUTES, 14 SECONDS					
149°F (65°C)	1 MINUTES, 25 SECONDS					
151°F (66°C)	54 SECONDS					
153°F (67°C)	34 SECONDS					
155°F (68°C)	22 SECONDS					
157°F (69°C)	14 SECONDS					
158°F (70°C)	0 SECONDS					
*HOLDING TIME MAY INCLUDE POST-OVEN HEAT RISE						

CHEF OPERATING TIPS

- **1.** For cooking specific products, refer to individual cook and hold instructions.
- When cooking at 250°F (121°C), it takes approximately one hour for the cooking temperature to decrease to the selected holding temperature. During this one hour time period, the product will continue to cook.
- **3.** The cooking times in this guide are based on meat taken directly from a refrigerated temperature of 38° to 40°F (3.3° to 4.4°C), and placed in a preheated oven. Adjustments must be made for cooking products at other than refrigerated temperatures.
- **4.** It is recommended the oven door remain closed during the cooking cycle. Opening the door will only increase the length of time necessary to cook the product.
- Puncturing an item with any sharp instrument may introduce bacteria inside the product. Avoid using a fork to handle products, and always use standard sanitary methods when handling any food item.
- **6.** Use a metal-stemmed thermometer to check the internal temperature of a product. Be certain to sanitize the thermometer before each use.
- **7.** Aged meat will cook faster, shrink more, and cannot be held as long as fresh meat. Because of the tenderizing capabilities of the oven, aged meat or tenderizing agents such as M.S.G. are not necessary, and are not recommended.
- **8.** When cooking full loads, never cook below the first shelf spacing from the bottom of the oven compartment.

9. Fully clean the oven interior, drip pan, shelves, and side racks on a daily basis.



- 10. Since there is no air movement inside the Halo Heat_® low temperature cooking and holding oven, condensation will form on the inside of the door during operation and may leak out of the oven door vents. This is a normal operating condition; however, any condensation spilling on the floor should be periodically wiped as a safety precaution. There is an External Drip Tray included as standard with most ovens.
- 11. Drip pan overflow is a condition caused by cooking some cuts of beef to an internal temperature in excess of 130°F (54°C). The External Drip Tray will help alleviate some of this overflow problem. There is also an extra large drip pan available as an option for the 1000-TH series ovens.
- Overflow may also be caused by overloading the oven compartment. DO NOT OVERLOAD THE OVEN. Follow the recommended load capacities listed in each individual procedure.
- **13.** For best results, many products should be cooked on an overnight cook-and-hold basis. Consult individual procedures for this recommendation.



NEED SOME HELP?

The Alto-Shaam staff includes corporate executive chefs who welcome questions. You are invited to contact anyone on our staff by phone (800.558.8744) or e-mail through the Contact Us section of our web site (www.alto-shaam.com) for help with any cook and hold procedure.

CLEANING & MAINTENANCE

CLEANING AND PREVENTIVE MAINTENANCE

PROTECTING STAINLESS STEEL SURFACES



It is important to guard against corrosion in the care of stainless steel surfaces. Harsh, corrosive, or inappropriate chemicals can completely destroy the

protective surface layer of stainless steel. Abrasive pads, steel wool, or metal implements will abrade surfaces causing damage to this protective coating and will eventually result in areas of corrosion. Even water, particularly hard water that contains high to moderate concentrations of chloride, will cause oxidation and pitting that result in rust and corrosion. In addition, many acidic foods spilled and left to remain on metal surfaces are contributing factors that will corrode surfaces.

Proper cleaning agents, materials, and methods are vital to maintaining the appearance and life of this appliance. Spilled foods should be removed and the area wiped as soon as possible but at the very least, a minimum of once a day. Always thoroughly rinse surfaces after using a cleaning agent and wipe standing water as quickly as possible after rinsing.

CLEANING AGENTS

Use non-abrasive cleaning products designed for use on stainless steel surfaces. Cleaning agents must be chloride-free compounds and must not contain quaternary salts. Never use hydrochloric acid (muriatic acid) on stainless steel surfaces. Always use the proper cleaning agent at the manufacturer's recommended strength. Contact your local cleaning supplier for product recommendations.

CLEANING MATERIALS

The cleaning function can usually be accomplished with the proper cleaning agent and a soft, clean cloth. When more aggressive methods must be employed, use a non-abrasive scouring pad on difficult areas and make certain to scrub with the visible grain of surface metal to avoid surface scratches. Never use wire brushes, metal scouring pads, or scrapers to remove food residue.



TO PROTECT STAINLESS STEEL SURFACES, COMPLETELY AVOID THE USE OF ABRASIVE CLEANING COMPOUNDS, CHLORIDE BASED CLEANERS, OR CLEANERS CONTAINING QUATERNARY SALTS. NEVER USE HYDROCHLORIC ACID (MURIATIC ACID) ON STAINLESS STEEL. NEVER USE WIRE BRUSHES, METAL SCOURING PADS OR SCRAPERS.

CLEANING & MAINTENANCE



The cleanliness and appearance of this equipment will contribute considerably to operating efficiency and savory, appetizing food. There is an important relationship between cleanliness and food flavor and aroma. Good equipment that is kept clean works better and lasts longer.

Under normal circumstances, this oven should provide you with long and trouble-free service. There is no preventative maintenance required, however, the following Equipment Care Guide will maximize the potential life and trouble-free operation of this oven.

1. CLEAN THE OVEN DAILY

D



DISCONNECT UNIT FROM POWER SOURCE BEFORE CLEANING OR SERVICING.

Disconnect the oven from the power source. Remove all detachable items such as wire shelves, side racks, and drip pans. Clean these items separately. Clean the interior metal surfaces of the oven with a damp, clean cloth and any good commercial detergent or grease solvent at the recommended strength. Use a plastic scouring pad or oven cleaner for difficult areas. Rinse carefully to remove all residue and wipe dry. Clean any glass with a window cleaner.

NOTE: Avoid the use of abrasive cleaning compounds, chloride based cleaners, or cleaners containing quaternary salts. Never use hydrochloric acid (muriatic acid) on stainless steel. Always



follow appropriate state or local health (hygiene) regulations regarding all applicable cleaning and sanitation requirements for equipment.

DANGER



AT NO TIME SHOULD THE INTERIOR OR EXTERIOR BE STEAM CLEANED, HOSED DOWN, OR FLOODED WITH WATER OR LIQUID SOLUTION OF ANY KIND. DO NOT USE WATER JET TO CLEAN.

```
SEVERE DAMAGE OR
ELECTRICAL HAZARD
COULD RESULT.
```

WARRANTY BECOMES VOID IF APPLIANCE IS FLOODED

2. CLEAN THE EXTERIOR OF THE CABINET

To help maintain the protective film coating on polished stainless steel, clean the exterior of the cabinet with a cleaner recommended for stainless steel surfaces. Spray the cleaning agent on a clean cloth and wipe with the grain of the stainless steel.

3. CHECK OVERALL CONDITION OF THE OVEN ONCE A MONTH.

Check the oven once a month for physical damage and loose screws. Correct any problems before they begin to interfere with the operation of the oven.

4. <u>CHECK THE COOLING FAN</u> IN THE OVEN CONTROL AREA.

While the oven is warm, check that the cooling fan in the oven control area is functioning. The fan is located at the back of the oven, toward the top.

5. CLEAN THE PROBES DAILY

Remove all food soil from probes. Wipe entire probe and cable assembly with warm detergent




solution and a clean cloth. Remove detergent by wiping each probe and cable with clean rinse water and a cloth. Wipe probes and probe brackets with disposable alcohol pad or sanitizing solution recommended for food contact surfaces. Allow probe and cable to air dry in probe holding bracket.

6. CLEAN THE DOOR VENTS

Door vents need to be inspected and cleaned as required.

COOKING PROCEDURE GUIDELINE INDEX













NOTE: ALL CAPACITIES SHOWN IN THIS MANUAL ARE BASED ON U.S. PAN SIZES. GASTRONORM PANS MAY HOLD MORE OR LESS THAN THE FOOD QUANTITIES INDICATED.

COOKING GUIDE	SMOKING GUIDE				
BEEF					
Beef Brisket	23	Smoked Beef Brisket	73		
Beef Striploin	24				
Beef Short Ribs	25				
Corned Beef	26				
Hamburgers	27				
Prime Rib (#109)	28				
Prime Rib, Special	29				
Ribeye Roll	30				
Beef Round	31				
Beef Round, Cafeteria or Steamship	32				
Tenderloin	33				
Veal Loin	34				
LAMB					
Lamb, Leg	35	[
Lamb Racks (FRENCHED)	36				
PORK					
Ham, Fresh	37	Smoked Fresh Hams	74		
Ham, Cured & Smoked	38	Smoked Pork Ribs	75		
Pork Loin	39		75		
Pork Ribs	40				
Pork Chops, Pork Chops, Stuffed	41				
Pork Shoulder	41				
	42				
Sausage POULTRY	43				
Chicken Breasts	44	Smoked Duck, Whole	76		
Chicken, Pieces & Halves	44		78		
Chicken, Whole	43	Smoked Turkey			
Cornish Hens	40				
Duck, Whole	47				
	48 49				
Turkey, Whole					
Turkey Breast	50				
Turkey Roll	51				
FISH	50		70		
Fish, Baked	52	Smoked Cod	78		
Salmon Steaks	53	Smoked Salmon	79		
Trout	54	Smoked Shrimp	80		
MISCELLANEOUS			01		
Potatoes, Baked	55	Smoked Beans	81		
Quiche	56				
Rice	57	Cold Smoke	00.00		
Baked Egg Custard	58	Cold Smoked Salmon	82-83		
Sheet Cake	59				
Cheese Cake	60				
Precooked Frozen Finger Foods	61				
Frozen Convenience Entrée PANS	62-63				
Frozen Convenience Portioned Entrées	64				
Breakfast Sandwiches	65				
Cookies	66				
Doughnuts	67				
Dough Proofing	68				
Procedure Blank	69				


COOKING NOTES

BEEF BRISKET

PRODUCT SPECIFICATIONS and PREPARATION

Beef Brisket, Fresh: 9 to 13 lb (4 to 6 kg)

Season brisket and wrap individually in clear plastic wrap for cooking. Place wrapped brisket directly on wire shelves.



BEEF STRIPLOIN

PRODUCT SPECIFICATIONS and PREPARATION

Loin, Strip Loin, Short-Cut, Boneless: 8 to 12 lb (4 to 5 kg)

Season as desired. Place roasts directly on the wire shelves with fat side down. Place larger roasts toward the top of the oven compartment.


MODELS	AS-250	500 SERIES	750 SERIES	1000 SE	RIES	1200 SERIES PER COMPARTMENT		
NUMBER OF SHELVES	2	2	2	3		3		
ITEMS PER SHELF	1 roast	2 roasts	4 roasts	3 roast	S	3 roasts		
APPROXIMATE Maximum Capacity	2 roasts up to 24 lb (11 kg)	4 roasts up to 40 lb (18 kg)	8 roasts up to 100 lb (45 kg	9 roast g) up to 100 lb		9 roasts up to 100 lb (45 kg)		
PANS	none	none	none	none		none		
22 PRNIGHT	ERNIGHT COOK & H OPTIONAL	ONE-	R VENTS: HALF OPEN	FINAL INTERN AFTER OVERF	RIDE:	are: 130°F (54°C)		
ТС	О СООК ВҮ	PROBE		то соок	BY -	TIME		
• P	ress and release control	ON/OFF key.	•	Press and release o	control ON	n/OFF key.		
• P:	ress the HOLD key. ress the up and down ar emperature to 140°F (60°			temperature to 140°F (60°C).				
• P:	ress the COOK key. ress the up and down ar emperature to 250°F (121			• Press the up and down arrows to set the cooking temperature to 250°F (121°C).				
OVERRIDE	ALLOWANCE: 30			Press the TIME ke	5			
	ress the PROBE key.	pending on size			t roast (18	kg): 8 minutes per 8 minutes per kilogram) n additional roast.		
te	ress the up and down ar emperature to 90°F (32°C nsert the product probe.	rows to set the probe C).	·	 12 lb ROASTS (5 kg): 10 minutes per pound for the first roast (22 minutes per kilogram) <i>plus</i> add 8 minutes for each additional roast. 				
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA			CLOSE THE OVEN IT FOR THE AUDIE INDICATE OVEN HAS	BLE SIGN			
MIN	IMUM HOLDING TI	ME REQUIRED		MAXIMUM HO	LDING	ТІМЕ		
	4 Hours			12 Hc	ours			
THE TIME AND PR DUE TO VARIATION	ED IN "HOLD" CY NOBE TEMPERATURE ARE S S IN PRODUCT QUALITY, WE DINGLY. ALWAYS FOLLOW LO	UGGESTED GUIDELINES ON IGHT, AND DESIRED DEGRE	LY. ALL COOKING SH	COOKING TIMER OR PR	ROBE TEMP	ERATURE MAY NEED TO BE		

BEEF SHORT RIBS

PRODUCT SPECIFICATIONS and PREPARATION

Short Ribs: 2 to 3 lb (1 to 1,3 kg), 10-12 oz. portions

Season as desired. Place ribs side-by-side in pans. For an overnight cook and hold, cover pans loosely with clear plastic wrap to retain additional product moisture.



CORNED BEEF

PRODUCT SPECIFICATIONS and PREPARATION

Corned Beef: 9 to 12 lb (4 to 5 kg)

Leave the corned beef in the original plastic bag and place the corned beef bag directly on the wire shelf.

MODELS	AS-250	500 si	ERIES	750 SERIES	S	1000 SERIES	1200 SERIES PER COMPARTMENT
NUMBER OF SHELVES	2	2		2		3	3
ITEMS PER SHELF	1	2 roasts		3 to 4 roasts		2 to 3 roasts	2 to 3 roasts
APPROXIMATE MAXIMUM CAPACITY	2 roasts up to 24 lb (11 kg)	4 roa up to 40 lb		6 to 8 roasts up to 100 lb (45 l	kg)	6 to 9 roasts up to 100 lb (45 kg)	6 to 9 roasts up to 100 lb (45 kg)
PANS	none	non	e	none		none	none
OV CZERNIGH OV	ERNIGHT COOK & H <u>MUST</u> DO OVERNI			R VENTS: IALF OPEN		NAL INTERNAL TEN TER OVERRIDE:	IPERATURE 175°F (79°C)
Т	О СООК ВҮ	PROBE			Т	О СООК ВУ	ГІМЕ
	COOKING BY PF	RODUCT I	PROBE		• Pre	ss and release control ON	√/OFF key.
	TEMPERATU RECOMMENDED		-		• Pre	ss the HOLD key. ss the up and down arro perature to 160°F (71°C)	
	ALLOWANCE:				• Pre	ss the COOK key. ss the up and down arro perature to 250°F (121°C	
					• 20 1 (44 <i>plu</i>	ss the TIME key. minutes per pound for tl minutes per kilogram) <i>s</i> d 30 minutes for each ado	
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA				AIT I	OSE THE OVEN DOOR. FOR THE AUDIBLE SIGN/ CATE OVEN HAS PREHEATE	///
MIN	IMUM HOLDING TI	ME REQU	IRED		MA	XIMUM HOLDING	ТІМЕ
TIME REQUIRE	6 or More Hour		E SERVIN	à.		24 Hours	
DUE TO VARIATION	S IN PRODUCT QUALITY, WE	IGHT, AND DES	IRED DEGREI	OF DONENESS, THE	соок) BE BASED ON INTERNAL (Ing Timer or probe temp Ial temperature requiren	ERATURE MAY NEED TO BE

HAMBURGERS

PRODUCT SPECIFICATIONS and PREPARATION

Ground Beef (fresh, not frozen): 5 oz (142 grams) per patty (minimum) Ground Beef, frozen: 5 oz (142 grams) per patty (MINIMUM)

Place hamburger patties side-by-side directly on sheet pans.

ADDITIONAL INFORMATION: Cooking time depends on the desired degree of doneness. Check internal product temperature before removing the product from the oven. Always follow local health (hygiene) regulations for all internal temperature requirements.

	-			. 70				_
MODELS	AS-250	500 s	500 SERIES 7		750 SERIES		1000 SERIES	1200 SERIES PER COMPARTMENT
NUMBER OF SHELVES	3	5			5		none	none
ITEMS PER SHELF	1 half-size sheet pan	1 half-size sheet pan 1		1	full-size sheet pan		1 full-size sheet pan	1 full-size sheet pan
APPROXIMATE Maximum Capacity	3 half-size sheet pans	5 half-size s	heet pans	5 f	ull-size sheet p	ans	8 full-size sheet pans	8 full-size sheet pans
PANS	18" x 13" x 1" (GN 1/1 x 20mm deep) (NO SHELVES REQUIRED)	18" x 13" x 1 (GN 1/1 x 20 (NO SHELVES)mm deep)	(G]	x 26" x 1" on shi N 2/1 x 20mm de 10 shelves requiri	eep)	18" x 26" x 1" (GN 1/1 x 20mm deep) (ON WIRE SHELVES)	18" x 26" x 1" (GN 1/1 x 20mm deep) (on wire shelves)
ov	ERNIGHT COOK & H	OLD:	DOO	RV	ENTS:	FI	NAL INTERNAL TEM	IPERATURE
2 ERNIGHT	Not Recommend	led	ONE-I	HAL	F OPEN	AF	TER OVERRIDE:	165°F (74°C
Т	О СООК ВҮ	PROBE				Т	О СООК ВУ	ГІМЕ
	COOKING BY PF	RODUCT	PROBE			• Pre	ns and release control ON	N/OFF key.
	TEMPERATI RECOMMENDED					• Pre	ss the HOLD key. ss the up and down arro perature to 150°F (66°C)	
COOK	ALLOWANCE:					• Pre	ss the COOK key. ss the up and down arro perature to 250° to 275°.	
						• [*] Fr	ss the TIME key. esh, not frozen: Approxis ozen: 2-3 hours.	mately 1 hour.
	CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED.					AIT F	OSE THE OVEN DOOR. FOR THE AUDIBLE SIGN/ CATE OVEN HAS PREHEATE	
MIN	MINIMUM HOLDING TIME REQUIRED					MA	XIMUM HOLDING	TIME
none TIME REQUIRED IN "HOLD" CYCLE BEFORE SERVING.							4 Hours	
DUE TO VARIATION	IS IN PRODUCT QUALITY, WI	EIGHT, AND DES	SIRED DEGRE	E OF	DONENESS, THE	соок) BE BASED ON INTERNAL CING TIMER OR PROBE TEMP IAL TEMPERATURE REQUIREN	ERATURE MAY NEED TO BE

PRIME RIB

PRODUCT SPECIFICATIONS and PREPARATION

Beef Rib, Roast Ready, with Fat Cap, #109: 20 lb (9 kg) Average Weight

Season as desired. Place roasts directly on wire shelves with the larger roasts toward the top of the oven compartment.


MODELS	AS-250	500 si	ERIES	750 SERIES	\$	1000 SERIES	1200 SERIES PER COMPARTMENT	
NUMBER OF SHELVES	1	2		2		3	3	
ITEMS PER SHELF	1 Roast	1 Roast		3 Roasts		2 Roasts	2 Roasts	
APPROXIMATE MAXIMUM CAPACITY	1 Roast 20 lb (9 kg)	2 Roasts 40 lb (18 kg)		6 Roasts 120 lb (54 kg)		6 Roasts 120 lb (54 kg)	6 Roasts 120 lb (54 kg)	
PANS	none	non	e	none		none	none	
PERNICH	ERNIGHT COOK & H Highly Recommen	ded	One-	R VENTS: Half Open	AF		are: 130°F (54°C)	
тс	О СООК ВҮ	PROBE			T	соок ву	ГІМЕ	
• P1	ress and release control	on/off key.			• Pre	ss and release control OM	√OFF key.	
• Pr	ress the HOLD key. ress the up and down ar mperature to 140°F (60°		ne holding		temperature to 140°F (60°C).			
• Pr	ress the COOK key. ress the up and down ar mperature to 250°F (121		ne cooking	 Press the COOK key. Press the up and down arrows to set the cooking temperature to 250°F (121°C). 				
OVERRIDE	ALLOWANCE: 30	°F (17°C)		соок	ten		-).	
• Pr	ress the PROBE key. ress the up and down ar mperature to 100°F (38° isert the product probe.		ne probe		• 10 ı (22	ss the TIME key. minutes per pound for tl minutes per kilogram) <i>s</i> add 30 minutes for eac		
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA		SS START	CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED.				
MINI	MUM HOLDING TI	TIME REQUIRED MAXIMUM HOLDING TIME						
4 to 6 Hours 24 Hours 24 Hours								
THE TIME AND PR DUE TO VARIATIONS	OBE TEMPERATURE ARE S S IN PRODUCT QUALITY, WE	UGGESTED GUI EIGHT, AND DES	DELINES ONL' GIRED DEGREE	Y. ALL COOKING SH	соок) BE BASED ON INTERNAL (ING TIMER OR PROBE TEMP IAL TEMPERATURE REQUIREN	ERATURE MAY NEED TO BE	

PRIME RIB SPECIAL

PRODUCT SPECIFICATIONS and PREPARATION

Beef Rib, Roast Ready Special, Tied: 14 to 18 lb (6 to 8 kg) Average Weight

Season as desired. Place roasts directly on wire shelves with the larger roasts toward the top of the oven compartment.



RIBEYE

PRODUCT SPECIFICATIONS and PREPARATION

Beef Ribeye Roll, Lip On, #112A: 8 to 12 lb (3 to 5 kg)

Season as desired. Place roasts directly on the wire shelves, fat side down. Place larger roasts toward the top of the oven compartment.

MODELS	AS-250	500 SERIES		750 SERIES		1000 SERIES	1200 SERIES PER COMPARTMENT	
NUMBER OF SHELVES	1	2		2		3	3	
ITEMS PER SHELF	1 Roast	2 Roasts		3 Roasts		3 Roasts	3 Roasts	
APPROXIMATE MAXIMUM CAPACITY	1 Roast 12 lb (5 kg)	4 Roasts up to 40 lb (18 kg) u		6 Roasts 1p to 100 lb (45 kg	g)	9 Roasts up to 100 lb (45 kg)	9 Roasts up to 100 lb (45 kg)	
PANS	none	none		none		none	none	
OVE	ERNIGHT COOK & H Optional			VENTS: alf Open		IAL INTERNAL TEM TER OVERRIDE: R.	IPERATURE are: 130°F (54°C)	
ТС	ОСООК ВУ	PROBE			ТС	COOK BY	ГІМЕ	
• Pro	ess and release control	on/off key.		•	Pres	s and release control ON	N/OFF key.	
• Pr	ess the HOLD key. ess the up and down ar nperature to 140°F (60°		ıg	 Press the HOLD key. Press the up and down arrows to set the holding temperature to 140°F (60°C). 				
• Pro	ess the COOK key. ess the up and down ar nperature to 250°F (121		ng	 Press the COOK key. Press the up and down arrows to set the cooking temperature to 250°F (121°C). 				
		9-40°F (17-22°C) epending on size		 Press the TIME key. 8 to 11 lb ROASTS (4 to 4,5 kg): 8 minutes per pound for the first roast (18 minutes per kilogram) <i>plus</i> add 10 minutes for each additional roast. 				
• Protection	ess the PROBE key. ess the up and down a nperature to 100°F (38° sert the product probe.			 • 12 lb ROASTS (5 kg): 10 minutes for each additional roast. • 12 lb ROASTS (5 kg): 10 minutes per pound for the first roast (22 minutes per kilogram) <i>plus</i> add 10 minutes for each additional roast. 				
	LOSE THE OVEN DOOR. FOR THE AUDIBLE SIG ICATE OVEN HAS PREHEA		Ż-	CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED.				
MINI	MUM HOLDING TI	ME REQUIRED			MA	XIMUM HOLDING	TIME	
TIME REQUIRE	4 Hours D IN "HOLD" CY	CLE BEFORE SERV	ING.			12 Hours		
THE TIME AND PRODUCE TO VARIATIONS	DBE TEMPERATURE ARE S IN PRODUCT QUALITY, WE	UGGESTED GUIDELINES Eight, and desired deg	ONLY. REE OI	F DONENESS, THE C	соокі	BE BASED ON INTERNAL NG TIMER OR PROBE TEMP AL TEMPERATURE REQUIREM	ERATURE MAY NEED TO BE	

BEEF ROUND

PRODUCT SPECIFICATIONS and PREPARATION

Beef Round, Top (Inside), Untrimmed: 14 to 23 lb (6 to 10 kg) Beef Round, Bottom (Gooseneck), Untrimmed: 14 to 23 lb (6 to 10 kg)

Season as desired. Place roasts directly on wire shelves with fat side down. Place larger roasts toward the top of the oven compartment.

MODELS	AS-250	500 SE	RIES	750 se	RIES	1000 SERIES	1200 SERIES PER COMPARTMENT	
NUMBER OF SHELVES	1	1 or	2	2		3	3	
ITEMS PER SHELF	1 Roast	1: 23 lb (10 kg) Roast 2: 14 lb (6 kg) Roasts		3 roas	sts	2: 23 lb (10 kg) Roasts 3: 14 lb (6 kg) Roasts	2: 23 lb (10 kg) Roasts 3: 14 lb (6 kg) Roasts	
APPROXIMATE MAXIMUM CAPACITY	1 Roast up to 23 lb (10 kg)	2 Large Roasts or 4 Small Roasts up to 40 lb (18 kg)		6 Roa up to 100 ll		6 Large Roasts or 9 Small Roasts up to 100 lb (45 kg)	6 Large Roasts or 9 Small Roasts up to 100 lb (45 kg)	
PANS	none	none	e	non	e	none	none	
Sn Sn	ERNIGHT COOK & H nall Cuts: Optiona urge Cuts: Highly Recomm	I		R VENTS: Half Open	A	NAL INTERNAL TEM FTER OVERRIDE: R	APERATURE Are: 130°F (54°C)	
ТС	о соок ву	PROBE	1		Т	о соок ву	TIME	
• P:	ress and release control	on/off key.			• Pre	ess and release control ON	N/OFF key.	
• Pi	ress the HOLD key. ress the up and down ar emperature to 140°F (60°		e holding	HOLD	• Pre	ess the HOLD key. ess the up and down arro nperature to 140°F (60°C		
• Pi	ress the COOK key. ress the up and down ar emperature to 250°F (121		e cooking	СООК	• Preten	ess the COOK key. ess the up and down arro nperature to 250°F (121°C		
	ALLOWANCE: 30 ress the PROBE key.)°F (17°C)		ТІМЕ	← • 14	ess the TIME key. Ib (6 kg) ROASTS: 10 m first roast (22 minutes p as add 15 minutes for eac	er kilogram)	
• Pi	ress the up and down ar emperature to 100°F (38° nsert the product probe.		le probe		por	to 23 lb (7 to 10 kg) ROA und for the first roast (22 <i>s</i> add 30 minutes for eac	minutes per kilogram)	
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA		SS STAR		(WAIT	LOSE THE OVEN DOOR. FOR THE AUDIBLE SIGN ICATE OVEN HAS PREHEATE		
MIN	IMUM HOLDING TI	ME REQU	IRED		M	AXIMUM HOLDING	TIME	
14 lb (6 kg) ROASTS: 4 to 6 Hours 14 lb (6 kg) ROASTS: 12 Hours 15 to 23 lb (7 to 10 kg) ROASTS: 8 to 10 Hours 15 to 23 lb (7 to 10 kg) ROASTS: 24 Hours TIME REQUIRED IN "HOLD" CYCLE BEFORE SERVING. 15 to 23 lb (7 to 10 kg) ROASTS: 24 Hours								
THE TIME AND PROBE TEMPERATURE ARE SUGGESTED GUIDELINES ONLY. ALL COOKING SHOULD BE BASED ON INTERNAL PRODUCT TEMPERATURES. DUE TO VARIATIONS IN PRODUCT QUALITY, WEIGHT, AND DESIRED DEGREE OF DONENESS, THE COOKING TIMER OR PROBE TEMPERATURE MAY NEED TO BE								

ADJUSTED ACCORDINGLY. ALWAYS FOLLOW LOCAL HEALTH (HYGIENE) REGULATIONS FOR ALL INTERNAL TEMPERATURE REQUIREMENTS.

BEEF ROUND, CAFETERIA or STEAMSHIP

PRODUCT SPECIFICATIONS and PREPARATION

Any one of a variety of beef round used for carving on a buffet line. May be bone-in or boneless and may have a handle on or off as required.

WEIGHT RANGE: 40 to 50 lb (18 to 23 kg)

50 to 80 lb (23 to 36 kg)

Meat should be at a refrigerated internal temperature of 38° to 40°F (3 to 4°C) when placing in a preheated oven.

MODELS	AS-250	500 si	ERIES	750 SERIES	6	1000 SERIES	1200 SERIES PER COMPARTMENT
NUMBER OF SHELVES		1		1		1	1
ITEMS PER SHELF	_	1 roast		1 to 2 roasts		1 to 2 roasts	1 to 2 roasts
APPROXIMATE MAXIMUM CAPACITY	_	40 lb (1	8 kg)	up to 80 lb (36 kg	g)	up to 80 lb (36 kg)	up to 80 lb (36 kg)
PANS	_	non	e	none		none	none
OV RENIGH	ERNIGHT COOK & H <u>MUST</u> Do Overnig			R VENTS: Half Open		NAL INTERNAL TEN TER OVERRIDE: R	APERATURE are: 135°F (57°C)
тс	О СООК ВҮ	PROBE			Т	о соок ву	ГІМЕ
	COOKING BY PF TEMPERATU RECOMMENDED	JRE IS NO	OT		 Pre Pre terr Pre terr Pres 40 to 	ss and release control ON ss the HOLD key. ss the up and down arro operature to 150°F (66°C) ss the COOK key. ss the up and down arro operature to 250°F (121°C) ss the TIME key. o 49 lb (18 to 22 kg): 10 the first roast (22 minute	ows to set the holding). ows to set the cooking C). minutes per pound
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA		SS JART	R((((w	<i>plus</i> 50 to 7 n <u>CL</u> AIT F	o 80 lb (23 to 36 kg): one ninutes per pound (15 m OSE THE OVEN DOOR. FOR THE AUDIBLE SIGNA CATE OVEN HAS PREHEATE	erond roast. e roast only — iinutes per kilogram).
MINI	IMUM HOLDING TI	ME REQU	IRED		MA	XIMUM HOLDING	TIME
50 to 8	49 lb (18 to 22 kg) Roasi 80 lb (23 to 36 kg) Roast ED IN "HOLD" сч	s: 8 to 12 Ho	urs	i.		24 Hours	
DUE TO VARIATION		IGHT, AND DES	IRED DEGREE	OF DONENESS, THE	соок	BE BASED ON INTERNAL	


ADJUSTED ACCORDINGLY. ALWAYS FOLLOW LOCAL HEALTH (HYGIENE) REGULATIONS FOR ALL INTERNAL TEMPERATURE REQUIREMENTS.

TENDERLOIN

PRODUCT SPECIFICATIONS and PREPARATION

Beef Loin, Full Tenderloin, Side Muscle Off, Skinned: 4 to 6 lb (2 to 3 kg)

Season as desired. Place tenderloin directly on wire shelves.



VEAL LOIN

PRODUCT SPECIFICATIONS and PREPARATION

Veal Loin, Trimmed: 8 to 10 lb (4 to 5 kg)


Season as desired and place directly on wire shelves.

MODELS	AS-250	500 SERIES		750 SERIES		1000 SERIES	1200 SERIES PER COMPARTMENT	
NUMBER OF SHELVES	1	2		2		3	3	
ITEMS PER SHELF	1 Roast	2 Roasts		4 Roasts		3 Roasts	3 Roasts	
APPROXIMATE MAXIMUM CAPACITY	1 Roast	4 Roasts		8 Roasts		9 Roasts	9 Roasts	
PANS	none	none		none		none	none	
CALL OV	ERNIGHT COOK & H Not Recommend			/ENTS: alf pen		NAL INTERNAL TEN TER OVERRIDE: MEDIUM RARE	IPERATURE : 140°F (60°C)	
тс	О СООК ВҮ	PROBE			тс	о соок ву т	ГІМЕ	
• P1	ress and release control	on/off key.		•	Pres	ss and release control ON	1/OFF key.	
• Pr	ress the HOLD key. ress the up and down ar mperature to 150°F (66°		ing		Pres	ss the HOLD key. ss the up and down arro perature to 140°F (60°C)		
Соок Ри te	ress the COOK key. ress the up and down ar mperature to 250°F (121 ALLOWANCE: 40	°C).	ing	 Press the COOK key. Press the up and down arrows to set the cooking temperature to 250°F (121°C). 				
Pr Pr te	ress the PROBE key. ress the up and down ar mperature to 100°F (38° isert the product probe.	rows to set the prob	e		12 ı (26	ss the TIME key. minutes per pound for minutes per kilogram s add 20 minutes for e	.)	
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA			IT F	OSE THE OVEN DOOR. FOR THE AUDIBLE SIGNA CATE OVEN HAS PREHEATE	/ /		
MINIMUM HOLDING TIME REQUIRED MAXIMUM HOLDING TIME								
1 Hour 10 Hours								
THE TIME AND PR DUE TO VARIATIONS	OBE TEMPERATURE ARE S S IN PRODUCT QUALITY, WE	UGGESTED GUIDELINES Sight, and desired de	ONLY. Egree oi	DONENESS, THE O	соок	BE BASED ON INTERNAL ING TIMER OR PROBE TEMP AL TEMPERATURE REQUIREM	ERATURE MAY NEED TO BE	

LAMB, LEG

PRODUCT SPECIFICATIONS and PREPARATION

Lamb, Leg, Boneless, Tied: 8 to 11 lb (4 to 5 kg) Season as desired and place directly on wire shelves.



LAMB RACKS (FRENCHED)

PRODUCT SPECIFICATIONS and PREPARATION

Rack, Roast Ready, Single, Frenched: 7-bone

Season as desired. Place racks on sheet pans with icing racks inserted in pans.




HAM, FRESH

PRODUCT SPECIFICATIONS and PREPARATION

Pork Fresh Ham: 14 to 17 lb (6 to 8 kg)

Season as desired and place directly on wire shelves.



HAM, CURED AND SMOKED

PRODUCT SPECIFICATIONS and PREPARATION

Ham, Boneless, Skinless, Cured and Smoked: 10 to 14 lb (4,5 to 6 kg)

Place ham directly on wire shelves for cooking.


MODELS	AS-250	500 SERIES	750 SERIES	1000 SERIES	1200 SERIES PER COMPARTMENT			
NUMBER OF SHELVES	2	2	2	3	3			
ITEMS PER SHELF	1 Ham	2 Hams	4 Hams	3 Hams	3 Hams			
APPROXIMATE MAXIMUM CAPACITY	2 Hams	4 Hams up to 40 lb (18 kg)	8 Hams up to 100 lb (45 kg)	9 Hams up to 100 lb (45 kg)	9 Hams up to 100 lb (45 kg)			
PANS	none	none	none	none	none			
OVE	ERNIGHT COOK & H Optional			FINAL INTERNAL TEI AFTER OVERRIDE:	MPERATURE 160°F (71°C)			
тс	О СООК ВҮ	PROBE	1	о соок ву	TIME			
• Pr	ess and release control	on/off key.	• F	• Press and release control ON/OFF key.				
• Pr	ess the HOLD key. ess the up and down ar mperature to 160°F (71°	rows to set the holding C).	• F	temperature to 160°F (71°C).				
Соок Рr ter	ess the COOK key. ess the up and down ar mperature to 250° to 27 ALLOWANCE: 12		• F	• Press the up and down arrows to set the cooking temperature to 250° to 275°F (121° to 135°C).				
• Pr ter	ess the PROBE key. ess the up and down ar mperature to 148°F (64° sert the product probe.			 Press the TIME key. 12 minutes per pound for the first ham (26 minutes per kilogram) plus add 30 minutes for each additional ham. 				
	LOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA	/ /		CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED.				
MINI	MUM HOLDING TI	ME REQUIRED	Ν	IAXIMUM HOLDING	TIME			
TIME REQUIRE	1 to 2 Hours d in "HOLD" cy	CLE BEFORE SERVIN	G.	10 Hours				
DUE TO VARIATIONS	S IN PRODUCT QUALITY, WE	IGHT, AND DESIRED DEGRE	E OF DONENESS, THE CO	LD BE BASED ON INTERNAL OKING TIMER OR PROBE TEMP RNAL TEMPERATURE REQUIREI	PERATURE MAY NEED TO BE			

PORK LOIN

PRODUCT SPECIFICATIONS and PREPARATION

Pork Loin, Boneless, Tied: 8 to 10 lb (4 to 5 kg)

Season as desired and place roasts directly on wire shelves for cooking.



PORK RIBS

PRODUCT SPECIFICATIONS and PREPARATION

Spareribs: 1-1/2 down (38 kg or less)

Pork Loin, Back Ribs (baby back ribs): 1-1/2 down (38 kg or less)

Ribs can be cooked from frozen or thawed. Season as desired. Place ribs on sheet pans, slightly overlapping, and cover with clear plastic wrap only if cooking overnight. If desired, barbecue sauce can be included with initial seasoning to allow it to cook into the ribs.

MODELS	AS-250	500 s	ERIES	750	SERIES	5	1000 SERIES	1200 SERIES PER COMPARTMENT
NUMBER OF SHELVES	3	3			4		none	none
ITEMS PER SHELF	1 half-size sheet pan	1 half-size sheet pan 1		1 full-siz	1 full-size sheet pan		1 full-size sheet pan	1 full-size sheet pan
APPROXIMATE MAXIMUM CAPACITY	3 half-size sheet pans APPROXIMATELY 20 lb (9 kg)	APPROXIN	3 half-size sheet pans APPROXIMATELY 4 20 lb (9 kg)			ans	5 full-size sheet pans	5 full-size sheet pans
PANS	18" x 13" x 1" (GN 1/1: 530 x 325 x 20mm) (NO SHELVES REQUIRED	18" x 13" x 1 (GN 1/1: 530 x (NO SHELVES	325 x 20mm)	18" x 26" (GN 2/1: 53 (NO SHEL)		mm)	18" x 26" x 1" (GN 1/1 x 20mm) (on wire shelves)	18" x 26" x 1" (GN 1/1 x 20mm) (ON WIRE SHELVES)
OVERNIGHT COOK & HOLD: DOOR					VENTS: alf Open FINAL INTERNAL TEMPERATURE AFTER OVERRIDE: Well DONE: 160°F (71°C)			
Т	О СООК ВҮ	PROBE				ТС	О СООК ВУ	TIME
COOKING BY PRODUCT PROBE						• Pre	ss and release control Of	√OFF key.
						 Press the HOLD key. Press the up and down arrows to set the holding temperature to 160°F (71°C). 		
OVERRIDE	ALLOWANCE:			Coo		Pre	ss the COOK key. ss the up and down arro perature to 250°F (121°C	
						• TH	ss the TIME key. AWED RIBS: 2-1/2 to OZEN RIBS: 3-1/2 to	
CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED.					CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED.			
MIN	IMUM HOLDING TI	ME REQU	IRED			MA	XIMUM HOLDING	ТІМЕ
TIME REQUIRE	1-1/2 Hours TIME REQUIRED IN "HOLD" CYCLE BEFORE SERVING.					12 Hours		
THE TIME AND PF DUE TO VARIATION	ROBE TEMPERATURE ARE S Is in product quality, we Dingly. Always follow L(UGGESTED GUI EIGHT, AND DES	DELINES ONI Sired Degre	Y. ALL CO	IESS, THE	соок	ING TIMER OR PROBE TEMP	ERATURE MAY NEED TO BE

PORK CHOPS

PRODUCT SPECIFICATIONS and PREPARATION

Pork Loin Chops: 6 to 8 oz (170 to 227 grams) approximate weight range, 1-inch to 1-1/2-inches thick (25 to 38mm) or

Pork Loin Rib Chops with Pocket (STUFFED): 6 to 8 oz (170 to 227 grams), 1-inch to 1-1/2-inches thick (25 to 38mm)

Season as desired. Place chops side-by-side on sheet pans.

MODELS	AS-250	500 SERIES	750 SERIES	100	0 SERIES	1200 SERIES PER COMPARTMENT	
NUMBER OF SHELVES	3	4	4		none	none	
ITEMS PER SHELF	1 half-size sheet pan	1 half-size sheet pan	1 full-size sheet pa	an 1 full-s	ize sheet pan	1 full-size sheet pan	
APPROXIMATE MAXIMUM CAPACITY	3 half-size sheet pans	4 half-size sheet pans	4 full-size sheet pa	ns 5 full-si	ze sheet pans	5 full-size sheet pans	
PANS	18" x 13" x 1" (GN 1/1: 530 x 325 x 20mm) (NO SHELVES REQUIRED)	18" x 13" x 1" on shelves (GN 1/1: 530 x 325 x 20mm) (NO SHELVES REQUIRED)	18" x 26" x 1" on she (GN 2/1: 530 x 650 x 201 (NO SHELVES REQUIRED	mm) (GN 2/1: 3	x 26" x 1" 530 x 650 x 20mm) VIRE SHELVES)	18" x 26" x 1" (GN 2/1: 530 x 650 x 20mm (ON WIRE SHELVES)	
ov	ERNIGHT COOK & H		OR VENTS:		,		
PRNIGH	Not Recommend		-Half Open	AFTER O	VERRIDE:	0°F (71°C)	
T	О СООК ВҮ	PROBE		то со	ОК ВҮ	ГІМЕ	
• P	ress and release control	on/off key.		Press and rel	lease control ON	J/OFF key.	
• P	ress the HOLD key. ress the up and down a emperature to 160°F (71		· _	 Press the HOLD key. Press the up and down arrows to set the holding temperature to 160°F (71°C). 			
Соок Р te	ress the COOK key. ress the up and down at emperature to 250°F (121	°C).		• Press the up and down arrows to set the cooking temperature to 250°F (121°C).			
• P	ALLOWANCE: 30 Press the PROBE key. Press the up and down and emperature to 130°F (54°	rrows to set the probe		$\overbrace{\mathbf{TME}}^{\mathbf{COOK}} \stackrel{\bullet}{\overset{\bullet}{\overset{\bullet}{\overset{\bullet}{\overset{\bullet}}}}} + \operatorname{Press} \text{ the TIME key.} \\ \bullet \text{ Set time for } 3-1/2 \text{ hours.}$			
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA	/ ·		IT FOR THE	OVEN DOOR. AUDIBLE SIGN/ NHAS PREHEATE	AL PRESS	
MIN	IMUM HOLDING T	ME REQUIRED		MAXIMUN	I HOLDING	TIME	
TIME REQUIRI	1-1/2 Hours ed in "HOLD" cy	CLE BEFORE SERVIN	IG.	6 to 8 Hours			
THE TIME AND PE DUE TO VARIATION	ROBE TEMPERATURE ARE S Is in product quality, we dingly. Always follow L(UGGESTED GUIDELINES ON Eight, and desired degri	ILY. ALL COOKING SHO EE OF DONENESS, THE (OOKING TIMER	OR PROBE TEMP	ERATURE MAY NEED TO BE	

PORK SHOULDER

PRODUCT SPECIFICATIONS and PREPARATION

Pork Shoulder, Boston Butt, Boneless: 8 to 10 lb (4 to 5 kg)

Season as desired and place in pans.

MODELS	AS-250	500 s	ERIES	750 SERIES	S	1000 SERIES	1200 SERIES PER COMPARTMENT	
NUMBER OF SHELVES	1	2		none		3	3	
ITEMS PER SHELF	2 roasts per pan 1 pan	2 roasts per pan 2 pans		2 roasts per pan 2 pans		2 roasts per pan 2 pans	2 roasts per pan 2 pans	
APPROXIMATE MAXIMUM CAPACITY	2 roasts	4 roasts up to 40 lb (18 kg) ι		10 roasts up to 100 lb (45 l	kg)	12 roasts up to 100 lb (45 kg)	12 roasts up to 100 lb (45 kg)	
PANS	12" x 20" x 2-1/2"	12" x 20" :	x 2-1/2"	12" x 20" x 2-1/	/ 2"	12" x 20" x 2-1/2"	12" x 20" x 2-1/2"	
PANS	(GN 1/1 x 65mm)	(GN 1/1)	x 65mm)	(GN 1/1 x 65m	im)	(GN 1/1 x 65mm)	(GN 1/1 x 65mm)	
OV PERNICH OV	ERNIGHT COOK & H Highly Recommer			R VENTS: Half Open		NAL INTERNAL TEM FTER OVERRIDE: 165° to 17	IPERATURE ′0°F (74° to 77°C)	
Т	О СООК ВҮ	PROBE			Т	о соок вүт	ГІМЕ	
$[\Theta]$	COOKING BY PF	RODUCT	PROBE		• Pre	ess and release control ON	I/OFF key.	
					 Press the HOLD key. Press the up and down arrows to set the holding temperature to 160°F (71°C). 			
COOK	ALLOWANCE:				• Pre	ess the COOK key. ess the up and down arro pperature to 250°F (121°C		
					 Press TIME key. Press the up and down arrows to set 15 minutes per pound for the first roast (33 minutes per kilogram) <i>plus,</i> add 30 minutes for each additional roast. 			
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA		SS KART		AIT I	OSE THE OVEN DOOR. FOR THE AUDIBLE SIGN/ CATE OVEN HAS PREHEATE	/ / /	
MIN	IMUM HOLDING T	ME REQU	IRED		M A	XIMUM HOLDING	TIME	
TIME REQUIRE	2 Hours Ed in "HOLD" Cy	CLE BEFOR	E SERVING	12 Hours				
DUE TO VARIATION	S IN PRODUCT QUALITY, WE	EIGHT, AND DES	SIRED DEGREE	OF DONENESS, THE	соок) BE BASED ON INTERNAL (ING TIMER OR PROBE TEMP IAL TEMPERATURE REQUIREN	ERATURE MAY NEED TO BE	

SAUSAGE

PRODUCT SPECIFICATIONS and PREPARATION

Sausage, Fresh: Any of a variety of processed meat product including bratwurst, Polish sausage, breakfast links, smoked sausage, hot dogs, etc.

Place sausage side-by-side on sheet pans. Add a sufficient amount of hot water so that it just covers the bottom of each pan. Cover each pan with clear plastic wrap.

NOTE: For precooked sausage, follow the same time and temperature settings as fresh sausage. Cooking time for a precooked product will vary, particularly for less than full loads. When heating a full load, check the internal product temperature after approximately one (1) hour of cooking time.

MODELS	AS-250	500 si	ERIES		750 SERIES		1000 SERIES	1200 SERIES PER COMPARTMENT	
NUMBER OF SHELVES	3	4			5		none	none	
ITEMS PER SHELF	1 half-size sheet pan	1 half-size sheet pan 1		1	1 full-size sheet pan		1 full-size sheet pan	1 full-size sheet pan	
APPROXIMATE Maximum Capacity	3 half-size sheet pans	4 half-size s	heet pans	5 f	full-size sheet pa	ans	8 full-size sheet pans	8 full-size sheet pans	
PANS	18" x 13" x 1" (GN 1/1: 530 x 325 x 20mm) (NO SHELVES REQUIRED)	18" x 13" x 1 (GN 1/1: 530 x (NO SHELVES	325 x 20mm)	(GN	' x 26" x 1 " on shi I 2/1: 530 x 650 x 20 (no shelves required)mm)	18" x 26" x 1" (GN 1/1 x 20mm) (ON WIRE SHELVES)	18" x 26" x 1" (GN 1/1 x 20mm) (on wire shelves)	
ov	ERNIGHT COOK & H	OLD:	DOO	RV	ENTS:		NAL INTERNAL TEN	IPERATURE	
PERNIGHT	Not Recommend	ed	о	pen	n Full AFTER OVERRIDE: 160°F (71°C)				
Т	О СООК ВҮ	PROBE				т	О СООК ВУ	ГІМЕ	
	PROBE		• Press and release control ON/OFF key.						
						 Press the HOLD key. Press the up and down arrows to set the holding temperature to 160°F (71°C). 			
OVERRIDE	ALLOWANCE:					• Pre	ss the COOK key. ss the up and down arro perature to 250°F (121°C		
						• Pre	ss TIME key. ss the up and down arro /2 to 2 hours.	ows to set the timer for	
	SS STAR	• •	CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED.						
MIN	IRED			MA	XIMUM HOLDING	TIME			
	none Ed in "HOLD" cy Robe temperature are s					חווח	6 Hours be based on internal	PRODUCT TEMPERATURES	
DUE TO VARIATION	S IN PRODUCT QUALITY, WE	EIGHT, AND DES	IRED DEGRE	E OF	DONENESS, THE	соок	ING TIMER OR PROBE TEMP AL TEMPERATURE REQUIREN	ERATURE MAY NEED TO BE	

CHICKEN BREASTS

PRODUCT SPECIFICATIONS and PREPARATION

Chicken Breasts, Boneless: 4 to 8 oz (113 to 227 grams)

Place chicken breasts on sheet pans, side-by-side, not quite touching. Brush chicken with oil, butter, or margarine (OPTIONAL), and lightly sprinkle with salt, pepper, and paprika.

MODELS	AS-250	500 s	ERIES		750 SERIES	6	1000 SERIES	1200 SERIES PER COMPARTMENT		
NUMBER OF SHELVES	3	4			6		none	none		
ITEMS PER SHELF	1 half-size sheet pan	1 half-size sheet pan 1		1 f	1 full-size sheet pan		1 full-size sheet pan	1 full-size sheet pan		
APPROXIMATE MAXIMUM CAPACITY	3 half-size sheet pans	4 half-size sheet pans 6			ull-size sheet pa	ans	8 full-size sheet pans	8 full-size sheet pans		
PANS	18" x 13" x 1" (GN 1/1: 530 x 325 x 20mm) (NO SHELVES REQUIRED)	18" x 13" x 1 (GN 1/1: 530 x (NO SHELVES	325 x 20mm)	(GN	x 26" x 1" on shi 2/1: 530 x 650 x 20 No shelves required)mm)	18" x 26" x 1" (GN 1/1 x 20mm) (ON WIRE SHELVES)	18" x 26" x 1" (GN 1/1 x 20mm) (ON WIRE SHELVES)		
ov	ERNIGHT COOK & H	OLD:	DOO	RV	ENTS:		NAL INTERNAL TEN	IPERATURE		
ERNICH	Not Recommend	ed	Ο	pen	Full	AF	TER OVERRIDE:	185°F (85°C)		
T(О СООК ВҮ	PROBE				т	О СООК ВУ	ГІМЕ		
	PROBE			• Pre	ss and release control ON	ı∕OFF key.				
	COOKING BY PRODUCT PROBE TEMPERATURE IS NOT RECOMMENDED FOR THIS ITEM.					 Press the HOLD key. Press the up and down arrows to set the holding temperature to 160°F (71°C). 				
OVERRIDE	ALLOWANCE:				 Press the COOK key. Press the up and down arrows to set the cooking temperature to 275°F (135°C). 					
					 Press the TIME key. 1-1/2 to 2 hours for the first pan plus, add 30 minutes for each additional pan. 					
CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED.						AIT F	OSE THE OVEN DOOR. FOR THE AUDIBLE SIGN/ CATE OVEN HAS PREHEATE			
MIN	MINIMUM HOLDING TIME REQUIRED						MAXIMUM HOLDING TIME			
none TIME REQUIRED IN "HOLD" CYCLE BEFORE SERVING.					6 Hours					
DUE TO VARIATION	IS IN PRODUCT QUALITY, WE	EIGHT, AND DES	SIRED DEGRE	E OF	DONENESS, THE	соок	BE BASED ON INTERNAL Ing timer or probe temp al temperature requirem	ERATURE MAY NEED TO BE		

CHICKEN, PIECES and HALVES

PRODUCT SPECIFICATIONS and PREPARATION

Chicken: 2-1/2 lb to 2-3/4 lb (1,1 kg to 1,2 kg) average weight

Clean chicken and remove excess fat. Brush chicken with oil, butter, or margarine (OPTIONAL). Season as desired and sprinkle with paprika.

When holding longer than 30 minutes, cover chicken with clear plastic wrap.

MODELS	AS-250	500 SERIES		750 SERIES		1000 SERIES	1200 SERIES PER COMPARTMENT
NUMBER OF SHELVES	2	3		3		none	none
ITEMS PER SHELF	1 half-size sheet pan	1 half-size sheet pan	1 half-size sheet pan 1 full-size			1 full-size sheet pan	1 full-size sheet pan
APPROXIMATE MAXIMUM CAPACITY	12 halves 2 half-size sheet pans	18 halves or 60 pieces 3 half-size sheet pans				8 halves or 160 pieces 4 full-size sheet pans	48 halves or 160 pieces 4 full-size sheet pans
PANS	18" x 13" x 1" (GN 1/1: 530 x 325 x 20mm) (NO SHELVES REQUIRED)	18" x 13" x 1" on shelves (GN 1/1: 530 x 325 x 20mm) (NO SHELVES REQUIRED)	(GN	" x 26" x 1" on shelv N 2/1: 530 x 650 x 20m; (No shelves required)		18" x 26" x 1" (GN 1/1 x 20mm) (ON WIRE SHELVES)	18" x 26" x 1" (GN 1/1 x 20mm) (ON WIRE SHELVES)
OV PERNICI	ERNIGHT COOK & H Not Recommend					AL INTERNAL TEN FER OVERRIDE:	IPERATURE 185°F (85°C)
т	О СООК ВҮ	PROBE			то	COOK BY	ГІМЕ
• P.	•	Press	s and release control ON	I/OFF key.			
• P	temperature to 160° F (71°C).					s the HOLD key. s the up and down arro perature to 160°F (71°C)	
соок Р.	ress the COOK key. ress the up and down ar emperature to 275° to 30 ALLOWANCE: 12	0°F (135° to 149°C).	;	 Press the COOK key. Press the up and down arrows to set the cooking temperature to 275° to 300°F (135° to 149°C). 			
P. P.	ress the PROBE key. ress the up and down ar emperature to 170° to 17. isert the product probe i	rrows to set the probe 5°F (77° to 79°C).		• Press the TIME key. • Set cooking timer for 2-1/2 to 3 hours.			/2 to 3 hours.
(((WAIT	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA		RT		T FO	DE THE OVEN DOOR. DR THE AUDIBLE SIGNA ATE OVEN HAS PREHEATE	/ /
MIN	IMUM HOLDING TI	ME REQUIRED			MAX	KIMUM HOLDING	TIME
TIME REQUIRE	30 Minutes					8 Hours holding longer than 30 chicken with clear plas	
THE TIME AND PR DUE TO VARIATION	OBE TEMPERATURE ARE S S IN PRODUCT QUALITY, WE DINGLY. ALWAYS FOLLOW LO	UGGESTED GUIDELINES ON Eight, and desired degr	ILY. EE OF	DONENESS, THE CO	οοκιν	IG TIMER OR PROBE TEMP	ERATURE MAY NEED TO BE

CHICKEN, WHOLE

PRODUCT SPECIFICATIONS and PREPARATION

Chicken, Whole: 2-1/4 lb to 2-3/4 lb (1 to 1,2 kg)

Clean chicken and remove excess fat. Brush chicken with oil, butter, or margarine (OPTIONAL). Season as desired and sprinkle with paprika.

For better whole bird appearance, fold chicken wings and tuck under the back of the bird. Make a slit in the skin of the chicken (lower end of the bird), cross chicken legs and insert both legs through the slit.

If barbecue sauce is desired, heat sauce to 150°F (66°C) and coat chicken approximately 1 hour before serving.

MODELS	AS-250	500 s	ERIES	750 SERIES	S	1000 SERIES	1200 SERIES PER COMPARTMENT	
NUMBER OF SHELVES	2	2		2		none	none	
ITEMS PER SHELF	3 Chickens	4 Chic	kens	9 Chickens		9 Chickens	9 Chickens	
APPROXIMATE MAXIMUM CAPACITY	6 Chickens 6 full-size pans	8 Chic 2 half-size s		18 Chickens 2 full-size sheet p	ans	27 Chickens 3 full-size sheet pans	27 Chickens 3 full-size sheet pans	
PANS	12" x 20" x 1"	18" x 13" x 1 (GN 1/1 > (NO SHELVES	(20mm)	18" x 26" x 1" on sh (GN 2/1 x 20mm) (NO SHELVES REQUIRE)	18" x 26" x 1" (GN 1/1 x 20mm) (ON WIRE SHELVES)	18" x 26" x 1" (GN 1/1 x 20mm) (ON WIRE SHELVES)	
ov	ERNIGHT COOK & H	OLD:	DOO	R VENTS:		NAL INTERNAL TEN	IPERATURE	
2 ERNIGHT	Optional		Ο	pen Full	AF	TER OVERRIDE:	185°F (85°C)	
T	О СООК ВҮ	PROBE			Т	О СООК ВУ	ГІМЕ	
μη ημη · P	Press and release control Press the HOLD key. Press the up and down ar	,	ne holding		• Press and release control ON/OFF key.			
HOLD to HOLD • P • P • P to cook • Wi	emperature to 160°F (71° Press the COOK key. Press the up and down ar emperature* to 300°F (14 hen cooking and holding ith clear plastic wrap for ermostat to 250°F (121°C	C). crows to set th 9°C). overnight, co cooking. Set	ne cooking over the par		ows to set the holding). ows to set the cooking 0°F (135° TO 149°C). vernight, cover the pans			
	ALLOWANCE: 10° Press the PROBE key. Press the up and down and emperature to 175°F (79°	rrows to set th			 with clear plastic wrap for cooking. Set cooking thermostat to 250°F (121°C) for 4 hours. Press the TIME key. Set cooking timer for 3 to 3-1/2 hours. 			
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG	in chicken thi		AIT F	OSE THE OVEN DOOR. FOR THE AUDIBLE SIGN/ CATE OVEN HAS PREHEATE			
MIN	MINIMUM HOLDING TIME REQUIRED MAXIMUM HOLDING						TIME	
TIME REQUIR	1 Hour ed in "HOLD" cy	CLE BEFOR	E SERVIN	G.	8 to 10 Hours			
THE TIME AND P	ROBE TEMPERATURE ARE S	UGGESTED GUI	DELINES ONI	LY. ALL COOKING S				

ADJUSTED ACCORDINGLY. ALWAYS FOLLOW LOCAL HEALTH (HYGIENE) REGULATIONS FOR ALL INTERNAL TEMPERATURE REQUIREMENTS.

CORNISH HENS

PRODUCT SPECIFICATIONS and PREPARATION

Rock Cornish Hens: 12 oz (340 grams) each

Clean hens and remove excess fat. Fold wings and tuck under the back of the bird. Make a slit in the skin of the hen (LOWER END OF BIRD), cross hen legs and insert both legs through the slit. Brush hens with oil, butter, or margarine (OPTIONAL). Season as desired and sprinkle with paprika. Space evenly on sheet pans.

MODELS	AS-250	500 SERIES		750 SERIES	1000 SERIES	1200 SERIES PER COMPARTMENT		
NUMBER OF SHELVES	1	2		3	none	none		
ITEMS PER SHELF	1 half-size sheet pan 9 hens per pan	1 half-size sheet pan 9 hens per pan			1 full-size sheet pan 18 hens per pan	1 full-size sheet pan 18 hens per pan		
APPROXIMATE MAXIMUM CAPACITY	1 half-size sheet pan 9 Cornish hens	2 half-size sheet pans 18 Cornish hens			4 full-size sheet pans 72 Cornish hens	4 full-size sheet pans 72 Cornish hens		
PANS	18" x 13" x 1 (GN 1/1 x 20mm) (NO SHELVES REQUIRED)	18" x 13" x 1" on shelves (GN 1/1x 20mm) (No shelves required)		" x 26" x 1" on shelves (GN 2/1 x 20mm) (NO SHELVES REQUIRED)	18" x 26" x 1" (GN 1/1 x 20mm) (on wire shelves)	18" x 26" x 1" (GN 1/1 x 20mm) (ON WIRE SHELVES)		
OV SZERNIGH	ERNIGHT COOK & H Not Recommend				NAL INTERNAL TEN TER OVERRIDE:	IPERATURE 175°F (79°C)		
Т	О СООК ВҮ	PROBE		тс	COOK BY	ГІМЕ		
• P	ress and release control	on/off key.		• Pre	ss and release control OM	J/OFF key.		
• P	temperature to 160°F (71°C).				 Press the HOLD key. Press the up and down arrows to set the holding temperature to 160°F (71°C). 			
соок Р.	ress the COOK key. ress the up and down ar emperature to 275°F (135	°C).	;	 Press the COOK key. Press the up and down arrows to set the cook temperature to 275°F (135°C). 				
P P te	ALLOWANCE: 10 ress the PROBE key. ress the up and down ar emperature to 165°F (74° nsert the product probe	rows to set the probe C).		соок • Press the TIME key. • Set cooking timer for 3 to 3-1/2 hours.				
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA		RT	CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS				
MINI	MUM HOLDING T	IME REQUIRED		МА	XIMUM HOLDING	TIME		
	1 Hour Ed in "HOLD" cy	CI E BEFORE SERVI	16	4 to 6 Hours				
THE TIME AND PR DUE TO VARIATION	ROBE TEMPERATURE ARE S S IN PRODUCT QUALITY, WE	UGGESTED GUIDELINES ON Eight, and desired degr	ILY. EE OF	DONENESS, THE COOK	BE BASED ON INTERNAL ING TIMER OR PROBE TEMP AL TEMPERATURE REQUIREN	ERATURE MAY NEED TO BE		

DUCK, WHOLE

PRODUCT SPECIFICATIONS and PREPARATION

Duck, Whole: 4 to 5 lb (2 kg)

Season as desired. Rub with oil and paprika and place directly on wire shelves.

MODELS	AS-250	500 SERIES		750 SERIES		1000 SERIES	1200 SERIES	
NUMBER OF SHELVES	1	2		2		3	3	
ITEMS PER SHELF	3 Ducks	3 Ducks		6 Ducks		4 Ducks	4 Ducks	
APPROXIMATE Maximum Capacity	3 Ducks	6 Ducks		12 Ducks		12 Ducks	12 Ducks	
PANS	none	none		none		none	none	
OV RENIGE	ERNIGHT COOK & H Not Recommend			VENTS: FINAL INTERNAL TEMPERATURE AFTER OVERRIDE: 185° to 190F (85° to 88°C)				
т	О СООК ВҮ	PROBE			ТО	COOK BY	ГІМЕ	
• P:	ress and release control	on/off key.			Pres	s and release control ON	I/OFF key.	
• P1	 Press the HOLD key. Press the up and down arrows to set the holding temperature to 160°F (71°C). 					ss the HOLD key. ss the up and down arro perature to 160°F (71°C)		
• Pi	ress the COOK key. ress the up and down ar mperature to 300°F (149		g	 Press the COOK key. Press the up and down arrows to set the cooking temperature to 300°F (149°C). 				
OVERRIDE	ALLOWANCE: 20	°F (11°C)		СООК	terri		-).	
• Pi	ress the PROBE key. ress the up and down ar mperature to 165° to 17 usert the product probe i	0°F (74° to 77°C).				ss the TIME key. cooking timer for 2-1	/2 to 3 hours.	
E(((WAIT	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA		RT		IT F	OSE THE OVEN DOOR. OR THE AUDIBLE SIGNA CATE OVEN HAS PREHEATE	//	
MINI	MUM HOLDING T	IME REQUIRED		MAXIMUM HOLDING TIME				
	1 Hour			8 Hours				
	ED IN "HOLD" CY							
DUE TO VARIATION	OBE TEMPERATURE ARE S S IN PRODUCT QUALITY, WE DINGLY. ALWAYS FOLLOW LO	IGHT, AND DESIRED DEGF	EE OF	DONENESS, THE C	οοκι	NG TIMER OR PROBE TEMP	ERATURE MAY NEED TO BE	

TURKEY, WHOLE

PRODUCT SPECIFICATIONS and PREPARATION

Turkey, Whole: up to 25 lb (11 kg)

Turkey must be fully thawed. Season as desired. Rub with oil, butter or margarine (OPTIONAL).

Place directly on wire shelves.

MODELS	AS-250	500 SERIES	750 SERIES	1000 SERIES	1200 SERIES			
NUMBER OF SHELVES	1	1	1	2	2			
ITEMS PER SHELF	1 Turkey up to 18 lb (8 kg)	1 Turkey	2 Turkeys	2 Turkeys	2 Turkeys			
APPROXIMATE MAXIMUM CAPACITY	1 Turkey	1 Turkey	2 Turkeys	4 Turkeys	4 Turkeys			
PANS	none	none	none	none	none			
OV SZERNICH OV	ERNIGHT COOK & H Highly Recommen			NAL INTERNAL TEN TER OVERRIDE:	MPERATURE 175°F (79°C)			
Т	о соок ву	PROBE	т	о соок ву	TIME			
• P	ress and release control	ON/OFF key.	• Pre	• Press and release control ON/OFF key.				
• P	ress the HOLD key. ress the up and down ar emperature to 160°F (71°		• Pre	ess the HOLD key. The up and down arro Sperature to 160°F (71°C				
Соок • Р.	ress the COOK key. ress the up and down ar emperature to 275°F (135 ALLOWANCE: 10	ч°С).	• Pre	• Press the up and down arrows to set the cooking temperature to 275°F (135°C).				
Pre-		we be be a construction of the probe	• Pre	• Press the TIME key. • Set cooking timer for 3 to 3-1/2 hours.				
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA			CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS				
MINI	MUM HOLDING T	IME REQUIRED	MA	XIMUM HOLDING	TIME			
	1 Hour ed in "HOLD" cy			4 to 6 Hours				
THE TIME AND PR DUE TO VARIATION	ROBE TEMPERATURE ARE S S IN PRODUCT QUALITY, WE	UGGESTED GUIDELINES ON IGHT, AND DESIRED DEGRE	LY. ALL COOKING SHOULD E OF DONENESS, THE COOP) BE BASED ON INTERNAL (ING TIMER OR PROBE TEMP IAL TEMPERATURE REQUIREN	ERATURE MAY NEED TO BE			

TURKEY BREAST

PRODUCT SPECIFICATIONS and PREPARATION

Turkey Breast: 10 to 15 lb (5 to 7 kg)

Turkey breast should be at a refrigerated temperature of 38°F to 40°F (3°C to 4°C) when placed in a preheated oven. Season as desired. Brush with oil, butter, or margarine (OPTIONAL), and sprinkle with paprika. Place breasts directly on wire shelves.


MODELS	AS-250	500 SERIES	750 SERIES	1000 SERIES	1200 SERIES PER COMPARTMENT			
NUMBER OF SHELVES	2	2	2	3	3			
ITEMS PER SHELF	1 Turkey Breast	2 Turkey Breasts	4 Turkey Breasts	3 Turkey Breasts	3 Turkey Breasts			
APPROXIMATE MAXIMUM CAPACITY	2 Turkey Breasts	4 Turkey Breasts	8 Turkey Breasts	9 Turkey Breasts	9 Turkey Breasts			
PANS	none	none	none	none	none			
OV PERNIGH	ERNIGHT COOK & H Optional [*]			AFTER OVERRIDE:				
тс	о соок ву	PROBE	Т	O COOK BY	ТІМЕ			
• P	ress and release control	on/off key.	• P	ress and release control O	N/OFF key.			
• Pr HOLD • Pr	ress the HOLD key. ress the up and down ar mperature to 160°F (71° ress the COOK key. ress the up and down ar mperature to 250°F (121 *When cooking and hol set the cook thermosta	C). rows to set the cooking °C). ding overnight,	HOLD · P te	 HOLD Press the COOK key. Press the up and down arrows to set the cooking temperature to 250° to 275°F (121° to 135°C). *When cooking and holding overnight, set the cook thermostat at 250°F (121°C). 				
	ALLOWANCE: 8°	F (4°C) average						
• Pr	ress the PROBE key. ress the up and down ar mperature to 165° to 170 sert the product probe.			Press the TIME key. Set cooking timer for 3-3	1/2 to 4-1/2 hours.			
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA			CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIGN DICATE OVEN HAS PREHEATE				
MINI	MUM HOLDING T	IME REQUIRED	M	AXIMUM HOLDING	TIME			
TIME REQUIRE	1 Hour ed in "HOLD" cy	CLE BEFORE SERVIN	G.	10 Hours				
DUE TO VARIATION	S IN PRODUCT QUALITY, WE	IGHT, AND DESIRED DEGRE	E OF DONENESS, THE CO	LD BE BASED ON INTERNAL OKING TIMER OR PROBE TEMP RNAL TEMPERATURE REQUIREI	PERATURE MAY NEED TO BE			

TURKEY ROLL

PRODUCT SPECIFICATIONS and PREPARATION

Turkey Roll, Precooked, Frozen: 8 to 12 lb (4 to 5 kg)

Place fully frozen turkey rolls directly on wire shelves to reheat.




FISH, BAKED

PRODUCT SPECIFICATIONS and PREPARATION

Fish Fillets, Fresh or Frozen: 6 to 8 oz (170 to 227 grams)

Spray or coat sheet pans with oil. Place fillets side-by-side on sheet pans. Season as desired.




SALMON STEAKS

PRODUCT SPECIFICATIONS and PREPARATION

Salmon Steaks: 6 to 8 oz (170 to 227 grams), 1" (25mm) thick

Spray or coat sheet pans with oil, butter or margarine. Place steaks side-by-side on sheet pans. Season as desired.



TROUT

PRODUCT SPECIFICATIONS and PREPARATION

Trout, Whole: 1 lb (454 grams) dressed

Spray or coat sheet pans with oil. Wipe trout with a damp towel and place side-by-side on sheet pans. Season as desired.

MODELS	AS-250	500 s	ERIES	750 SERIE	S	1000 SERIES	1200 SERIES PER COMPARTMENT		
NUMBER OF SHELVES	4	6		6		none	none		
ITEMS PER SHELF	6 trout 1 half-size sheet pan	6 tro 1 half-size s		12 trout 1 full-size sheet pan		12 trout 1 full-size sheet pan	12 trout 1 full-size sheet pan		
APPROXIMATE MAXIMUM CAPACITY	24 trout 4 half-size sheet pans	36 tro 6 half-size s		72 trout 6 full-size sheet _]	pans	96 trout 8 full-size sheet pans	96 trout 8 full-size sheet pans		
PANS	18" x 13" x 1" (GN 1/1 x 20mm) (NO SHELVES REQUIRED)	18" x 13" x 1" ((GN 1/1 x (NO SHELVES	20mm)	18" x 26" x 1" on shi (GN 2/1 x 20mi (no shelves requi	m)	18" x 26" x 1" (GN 1/1 x 20mm) (on wire shelves)	18" x 26" x 1" (GN 1/1 x 20mm) (on wire shelves)		
ov	OVERNIGHT COOK & HOLD: DOOR					NAL INTERNAL TEN	IPERATURE		
2 ERNIGIT	Not Recommend	ed	One-	Half Open	AF	TER OVERRIDE: 15	5-160°F (68-71°C)		
т	О СООК ВҮ	PROBE			ТС	О СООК ВУ Т	ГІМЕ		
	COOKING BY PF	RODUCT	PROBE		• Pre	ess and release control ON	I/OFF key.		
	TEMPERATURE IS NOT RECOMMENDED FOR THIS ITEM.					 Press the HOLD key. Press the up and down arrows to set the holding temperature to 160°F (71°C). 			
OVERRIDE	ALLOWANCE:			Соок	• Press the up and down arrows to set the cooking temperature to 275° F (135°C).				
					 Press the TIME key. Press the up and down arrows to set the time to 1 to 1-1/2 hours. 				
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA		SS START		ναιτ ι	OSE THE OVEN DOOR. FOR THE AUDIBLE SIGNA ICATE OVEN HAS PREHEATE			
MINI	MUM HOLDING T	IME REQU	JIRED		MAXIMUM HOLDING TIME				
	none					4 to 6 Hours			
TIME REQUIRE	ED IN "HOLD" CY	CLE BEFOR	RE SERVINO	э.					
DUE TO VARIATION	S IN PRODUCT QUALITY, WE	EIGHT, AND DE	SIRED DEGREE	OF DONENESS, THE	соок) BE BASED ON INTERNAL (ING TIMER OR PROBE TEMP) IAL TEMPERATURE REQUIREM	ERATURE MAY NEED TO BE		

POTATOES

PRODUCT SPECIFICATIONS and PREPARATION

Potatoes, Baking: 80 to 90 count

Always store potatoes at room temperature.

Wash potatoes before placing in a preheated oven. Allow oven to preheat for a minimum of 30 minutes. Place potatoes directly on wire shelves.

MODELS	AS-250	500 s	ERIES	750 SERIES	S	1000 SERIES	1200 SERIES PER COMPARTMENT		
NUMBER OF SHELVES	2	3		4		4	4		
ITEMS PER SHELF	10 to 12 per shelf	10 to 12 p	er shelf	20 to 25 per shelf		20 to 25 per shelf	20 to 25 per shelf		
APPROXIMATE MAXIMUM CAPACITY	20 to 24 potatoes	30 to 36 potatoes		80 to 100 potatoe	25	80 to 100 potatoes	80 to 100 potatoes		
PANS	none	nor	ne	none		none	none		
OV DERNIGHT OV	ERNIGHT COOK & H Not Recommend			R VENTS: Den Full		NAL INTERNAL TEN TER OVERRIDE:	IPERATURE 190°F (88°C)		
т	О СООК ВҮ	PROB			T	О СООК ВУ	ТІМЕ		
	COOKING BY PF	RODUCT	PROBE		• Pre	ess and release control or	n/off key.		
	TEMPERATU RECOMMENDED				temperature to 190°F (88°C).				
COOK ○	ALLOWANCE:				• Pre	ess the COOK key. The up and down arro operature to 325°F (163°C			
					• Press the TIME key. • Press the up and down arrows to set the time to 1-1/2 to 3 hours.				
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA				AIT I	OSE THE OVEN DOOR. FOR THE AUDIBLE SIGN/ ICATE OVEN HAS PREHEATE	AL PRESS		
MINI	MUM HOLDING T	IME REQU	JIRED		MAXIMUM HOLDING TIME				
TIME REQUIRE	none Ed in "HOLD" cy	CLE BEFOF	RE SERVINO	G.	7 Hours				
DUE TO VARIATION	S IN PRODUCT QUALITY, WE	IGHT, AND DE	SIRED DEGRE	E OF DONENESS, THE	COOK	D BE BASED ON INTERNAL (ING TIMER OR PROBE TEMP IAL TEMPERATURE REQUIREN	ERATURE MAY NEED TO BE		

QUICHE

PRODUCT SPECIFICATIONS and PREPARATION

Prebake the shells in pie plates at 275°F (135°C) for approximately 40 minutes. Pour the quiche mixture into the prebaked shells and bake in a preheated oven.

Quiche is done when product sets up.

MODELS	AS-250	500 s	ERIES		750 SERIES	3	1000 SERIES	1200 SERIES	
NUMBER OF SHELVES	2	2			4		8	8	
ITEMS PER SHELF	2 quiche	2 qui	che		5 quiche		3 quiche	3 quiche	
APPROXIMATE MAXIMUM CAPACITY	4 quiche	4 quiche			20 quiche		24 quiche	24 quiche	
PANS	8" to 9" pie plate (203mm to 229mm)	8" to 9" p (203mm to	^ I		" to 9" pie pla)3mm to 229n		8" to 9" pie plate (203mm to 229mm)	8" to 9" pie plate (203mm to 229mm)	
OV PERNICIT OV	D00 01	RV	ENTS: Full	FII AF	NAL INTERNAL TEN TER OVERRIDE:	N/A			
Т				ТС	соок ву	TIME			
	PROBE			• Pre	ess and release control o	ON/OFF key.			
	TEMPERATURE IS NOT RECOMMENDED FOR THIS ITEM.					 Press the HOLD key. Press the up and down arrows to set the holding temperature to 160°F (71°C). 			
COOK	ALLOWANCE:				 Press the COOK key. Press the up and down arrows to set the cooking temperature to 275°F (135°C). 				
					 Press the TIME key. Press the up and down arrows to select a cook time of approximately 2 hours or until product sets up. 				
		r	CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED.						
MINI	MUM HOLDING T	IME REQU	IIRED		MAXIMUM HOLDING TIME				
TIME REQUIRE	none Ed in "HOLD" cy	CLE BEFOR	E SERVIN	G.			5 Hours		
DUE TO VARIATION	S IN PRODUCT QUALITY, WE	IGHT, AND DES	IRED DEGRE	E OF	DONENESS, THE	соок	BE BASED ON INTERNAL ING TIMER OR PROBE TEMP AL TEMPERATURE REQUIREN	ERATURE MAY NEED TO BE	

RICE

PRODUCT SPECIFICATIONS and PREPARATION

Use converted, long-grain rice only. Follow package directions for proportional amounts of rice to liquid. Heat liquid or water to 170°F (77°C) and add rice. Fill pans to half the pan depth and cover pans with foil.

MODELS	AS-250	500 si	ERIES		750 SERIES	5	1000 SERIES	1200 SERIES			
NUMBER OF SHELVES	none	nor	ie		none		3	3			
ITEMS PER SHELF	1 full-size pan	1 full-siz	ze pan	2	2 full-size pans		1 full-size pan	1 full-size pan			
APPROXIMATE MAXIMUM CAPACITY	2 full-size pans	2 full-size pans		4	full-size pans	5	3 full-size pans	3 full-size pans			
PANS	12" x 20" x 2-1/2"	12" x 20" x 2-1/2" 1		12'	' x 20" x 2-1/2	2"	12" x 20" x 2-1/2"	12" x 20" x 2-1/2"			
	(GN 1/1 x 65mm)	(GN 1/1 ×	(65mm)	(GI	N 1/1 x 65mn	n)	(GN 1/1 x 65mm)	(GN 1/1 x 65mm)			
OV PERNICI	ſ	R V Clos	ENTS:	AF		70°F (71° to 77°C)					
т	о соок ву	PROBE				ТС	COOK BY	ГІМЕ			
	COOKING BY PF	RODUCT I	PROBE			• Pre	ess and release control o	on/off key.			
	TEMPERATURE IS NOT RECOMMENDED FOR THIS ITEM.					 Press the HOLD key. Press the up and down arrows to set the holding temperature to 160°F (71°C). 					
COOK	VERRIDE ALLOWANCE:						 Press the COOK key. Press the up and down arrows to set the cooking temperature to 275°F (135°С). 				
					 Press the TIME key. Press the up and down arrows to select a cook time of approximately 3-1/2 to 4 hours. 						
				AIT F	OSE THE OVEN DOOR. FOR THE AUDIBLE SIGNA CATE OVEN HAS PREHEATE						
MINI	MUM HOLDING T	IME REQU	JIRED	ļ	MAXIMUM HOLDING TIME						
TIME REQUIRE	none TIME REQUIRED IN "HOLD" CYCLE BEFORE SERVING.						8 Hours				
DUE TO VARIATION	S IN PRODUCT QUALITY, WE	IGHT, AND DES	SIRED DEGRE	E OF	DONENESS, THE	соок) BE BASED ON INTERNAL (ING TIMER OR PROBE TEMP (AL TEMPERATURE REQUIREM	ERATURE MAY NEED TO BE			

BAKED EGG CUSTARD

PRODUCT SPECIFICATIONS and PREPARATION

Use a favorite custard recipe. Pour custard mixture into cups to a depth of 2/3 the container height and place cups on a sheet pan. Product volume and cook time is predicated on cup size.


NO WATER BATH IS REQUIRED. Bake in a preheated oven. Custard is done when product has set or when knife inserted in center of cup is clean when removed.

MODELS	AS-250	500 s	ERIES	750 SERIE	S	1000 SERIES	1200 SERIES PER COMPARTMENT		
NUMBER OF SHELVES	3	4		4		none	none		
ITEMS PER SHELF	1 half-size sheet pan	1 half-size s	sheet pan	1 full-size sheet pan		1 full-size sheet pan	1 full-size sheet pan		
APPROXIMATE MAXIMUM CAPACITY	3 half-size sheet pans	4 half-size sheet pans 4		4 full-size sheet	pans	5 full-size sheet pans	5 full-size sheet pans		
PANS	18" x 13" x 1" (GN 1/1 x 20mm) (NO SHELVES REQUIRED)	18" x 13 (GN 1/1 x (NO SHELVES	20mm)	18" x 26" x 1 (GN 2/1 x 20m (NO SHELVES REQU	m)	18" x 26" x 1" (GN 1/1 x 20mm) (ON WIRE SHELVES)	18" x 26" x 1" (GN 1/1 x 20mm) (ON WIRE SHELVES)		
ernicit ov	OVERNIGHT COOK & HOLD: DOOR					NAL INTERNAL TEN FTER OVERRIDE:	MPERATURE N/A		
Т	О СООК ВҮ	PROBE			ТС	О СООК ВУ	TIME		
Θ	COOKING BY PF	RODUCT	PROBE		• Pre	ess and release control ON	N/OFF key.		
						HOLD DO NOT SET.			
COOK	ALLOWANCE:			Соок	• Pre	ess the COOK key. The up and down arro aperature to 250°F (121°C			
					 Press the TIME key. Press the up and down arrows to select a cook time of approximately 60-90 min., 4 oz. ramekins, up to 3 hours for 4" steam pans 				
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA				CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED.				
MINI	MUM HOLDING T	IME REQU	JIRED		MAXIMUM HOLDING TIME				
TIME REQUIR	none Ed in "HOLD" cy	CLE BEFOR	E SERVIN	g.		none			
DUE TO VARIATION	S IN PRODUCT QUALITY, WE	IGHT, AND DES	SIRED DEGREI	E OF DONENESS, TH	E COOK	D BE BASED ON INTERNAL (ING TIMER OR PROBE TEMP IAL TEMPERATURE REQUIREM	ERATURE MAY NEED TO BE		

SHEET CAKE

PRODUCT SPECIFICATIONS and PREPARATION


Use a favorite cake recipe or mix. Pour batter in pans to one-half the pan depth. Keep oven door closed during the cooking cycle. The cake is done when a toothpick inserted in the center of the cake is clean when removed.



CHEESE CAKE

PRODUCT SPECIFICATIONS and PREPARATION

Use a favorite cheese cake recipe or mix. Pour batter into springform pans and bake in a preheated oven. The cheese cake is done when a toothpick inserted in the center is clean when removed. To prevent cracking, allow the cheese cake to remain in the oven until it reaches room temperature.



PRECOOKED FROZEN FINGER FOODS

PRODUCT SPECIFICATIONS and PREPARATION

CHICKEN NUGGETS: Approximately 40 per full-size sheet pan.

CORN DOGS: Approximately 30 per full-size sheet pan.

EGG ROLLS: Approximately 40 per full-size sheet pan.

MINI PIZZA: Approximately 12 to 15 per full-size sheet pan.

Line sheet pans with baking pan liners (OPTIONAL) and insert wire pan grid. Place items side-by-side on the wire pan grids.

MODELS	AS-250	500 SERIES	750 SERIES	\$	1000 SERIES	1200 SERIES PER COMPARTMENT		
NUMBER OF SHELVES	2	3	5		none	none		
ITEMS PER SHELF	1 half-size sheet pan	1 half-size sheet pan	1 full-size sheet pan		1 full-size sheet pan	1 full-size sheet pan		
APPROXIMATE MAXIMUM CAPACITY	2 half-size sheet pans	3 half-size sheet pans	5 full-size sheet pa	ans	5 full-size sheet pans	5 full-size sheet pans		
PANS	18" x 13" x 1" (GN 1/1 x 20mm) (NO SHELVES REQUIRED)	18" x 13" x 1" (GN 1/1 x 20mm) (NO SHELVES REQUIRED)	18" x 26" x 1" (GN 1/1 x 20mm) (NO SHELVES REQUIRE		18" x 26" x 1" (GN 1/1 x 20mm) (on wire shelves)	18" x 26" x 1" (GN 1/1 x 20mm) (on wire shelves)		
OV ALERNIGHT OV	ERNIGHT COOK & H		R VENTS: pen Full		NAL INTERNAL TEN TER OVERRIDE:	MPERATURE 150°F (66°C)		
		то сос	ΟΚ ΒΥ ΤΙΜ	Ε				
			COC	OKII	NG TIME TO BE SET:	2-1/2 hours		
• P	ress and release control ress the HOLD key. ress the up and down ar emperature to 160°F (71°	rrows to set the holding	OVEN FOR Set an inde	DO NOT ALLOW THE PRODUCT TO REMAIN IN THE OVEN FOR THE FULL SET COOKING TIME. Set an independent timer (or mechanical bill timer on equipped models) using the following guidelines: CORN DOGS: 30 to 45 minutes EGG ROLL: 45 to 60 minutes				
• P	ress the COOK key. ress the up and down ar emperature to 275°F (135		СН	CHICKEN NUGGETS: 45 to 60 minutes MINI PIZZA: 60 minutes				
• F	Press the TIME key. Press the up and down a ime of approximately 2-7		Cooking tim product rea internal pro	Product may be heated from a refrigerated or frozen state. Cooking times must be adjusted accordingly. Make certain product reaches the fully heated temperature. Check internal product temperature before removing product from oven and adjust heating time as required.				
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEA			CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED.				
MIN	IMUM HOLDING T	IME REQUIRED		MA	XIMUM HOLDING	ТІМЕ		
TIME REQUIR	none ed in "HOLD" cy	CLE BEFORE SERVIN	Generally ex	Maximum holding time varies from product to product. Generally expect a 1 to 3 hour maximum holding time for product acceptability.				
THE TIME AND PF DUE TO VARIATION	ROBE TEMPERATURE ARE S IS IN PRODUCT QUALITY, WE DINGLY. ALWAYS FOLLOW LO	UGGESTED GUIDELINES ON Eight, and desired degre	LY. ALL COOKING SH E OF DONENESS, THE	соок	ING TIMER OR PROBE TEMP	ERATURE MAY NEED TO BE		


FROZEN CONVENIENCE ENTRÉE PANS

PRODUCT SPECIFICATIONS and PREPARATION

PREHEAT THE OVEN. PRODUCT MUST BE FULLY FROZEN WHEN PLACED IN A PREHEATED OVEN.

Leave product in the original container with foil cover in place. Pour 1/2 gallon (1 liter) of hot water into the drip pan located on the bottom surface of the oven compartment. Place containers directly on wire shelves according to the diagram shown.

MODELS	AS-250	500 SEI	RIES	750 SERIES	6	1000 SERIES	1200 SERIES	
NUMBER OF SHELVES	_	_		3		5	5	
ITEMS PER SHELF	—	_		4 foil half-size pans		2 foil half size pans	2 foil half-size pans	
APPROXIMATE MAXIMUM CAPACITY	_	_		12 foil half-size pa	ans	10 foil half-size pans	10 foil half-size pans	
PANS	_	_		4-1/4 qts: 10" x 12" x 2-1/2' (GN/1/2: 3,75 ltr: 265 x 325 x 65mm)		4-1/4 qts: 10" x 12" x 2-1/2" (GN/1/2: 3,75 ltr: 265 x 325 x 65mm)	4-1/4 qts: 10" x 12" x 2-1/2" (GN/1/2: 3,75 ltr: 265 x 325 x 65mm)	
OV BEENIGHT OV	ERNIGHT COOK & H Optional	OLD:		VENTS: losed		NAL INTERNAL TEN TER OVERRIDE:	140°F (60°C)	
Т	О СООК ВҮ	PROBE			ТС	О СООК ВУ	ГІМЕ	
	COOKING BY PF				• Pre	ss and release control ON	ı∕OFF key.	
	RECOMMENDED The probe canr			 Press the HOLD key. Press the up and down arrows to set the holding temperature to 160°F (71°C). 				
COOK COOK COVERRIDE	<i>into a froze</i> ALLOWANCE:	n product.		СООК	• Pre	ss the COOK key. ss the up and down arro perature to 275°F (135°C		
					• See	ess the TIME key. 9 pan placement diagra 1 provide the setting shown on n		
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG IDICATE OVEN HAS PREHEA	-	S START	CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED.				
MIN	IMUM HOLDING T	IME REQUI	RED		MA	XIMUM HOLDING	ТІМЕ	
TIME REQUIR	1 Hour ed in "HOLD" cy	CLE BEFORE	SERVING	16 to 18 Hours				
DUE TO VARIATION	ROBE TEMPERATURE ARE S IS IN PRODUCT QUALITY, WE DINGLY. ALWAYS FOLLOW LO	IGHT, AND DESIF	RED DEGREE	OF DONENESS, THE	соок	ING TIMER OR PROBE TEMP	ERATURE MAY NEED TO BE	




Frozen convenience entrées removed from the original food processor's intact packaging must be treated as a product for reheating. Products for reheating must reach an internal product temperature of 165°F (74°C) for the amount of time specified by local health (hygiene) regulations.

FROZEN CONVENIENCE PORTIONED ENTRÉES

PRODUCT SPECIFICATIONS and PREPARATION

REHEAT THE OVEN. PRODUCT MUST BE FULLY FROZEN WHEN PLACED IN A PREHEATED OVEN. Leave product in the original container with foil cover in place. Pour 1/2 gallon (1 liter) of hot water into the drip pan located on the bottom surface of the oven compartment. Place containers directly on wire shelves according to the diagram shown.

DO NOT OVER-COOK — CHECK INTERNAL PRODUCT TEMPERATURE



BREAKFAST SANDWICHES

PRODUCT SPECIFICATIONS and PREPARATION

Thaw biscuits, croissants, or English muffins and slice horizontally. Place each ingredient on the lower half of the bread slice in the following order. Place upper half of bread slice on top of the other ingredients and wrap each sandwich in clear plastic wrap. Line sheet pans with baking pan liners (optional) and insert wire pan grid. Place wrapped sandwiches side-by-side on the wire pan grids.

- 1. Sausage patty, ham slices, or precooked bacon, frozen or thawed.
- 2. Egg patty (OPTIONAL), frozen or thawed.
- 3. 1/2 oz (14 gm) slice of American processed cheese (OPTIONAL).

MODELS	AS-250	500 se	RIES	750 SERIES	6	1000 SERIES	1200 SERIES		
NUMBER OF SHELVES	2	3		3		none	none		
ITEMS PER SHELF	1 half-size sheet pan	1 half-size	sheet pan	1 full-size sheet	pan	1 full-size sheet pan	1 full-size sheet pan		
APPROXIMATE MAXIMUM CAPACITY	2 half-size sheet pans	3 half-size sheet pans		3 full-size sheet	pans	5 full-size sheet pans	5 full-size sheet pans		
PANS	18" x 13" x 1" (GN 1/1: 20mm deep) (NO SHELVES REQUIRED)	18" x 13 (GN 1/1: 20 (NO SHELVES		18" x 26" x 1 (GN 2/1: 20mm c (NO SHELVES REQUI	leep)	18" x 26" x 1" (GN 1/1: 20mm deep) (ON WIRE SHELVES)	18" x 26" x 1" (GN 1/1: 20mm deep) (ON WIRE SHELVES)		
OV SERNICIT OV	ERNIGHT COOK & H Not Recommend	ed	O	R VENTS: Den Full	VENTS: FINAL INTERNAL TEMPERATURE AFTER OVERRIDE:				
		то	000	K BY TIM	E				
• P:	ress and release contro	l on/off key.				G TIME TO BE SET: W THE PRODUCT			
• Pi	ress the HOLD key. ress the up and down a olding temperature to 2		the	Set an indep	pend	R THE FULL SET (ent timer (or mechans) s) using the following	nical bill timer on		
• Pi	ress the COOK key. ress the up and down a poking temperature to 2			MAKE CE	45 to 60 minutes MAKE CERTAIN PRODUCT REACHES THE FULLY				
					HEATED TEMPERATURE.				
• I	Press the TIME key. Press the up and down rook time of approxima			CHECK	INT	ERNAL PRODUCT	TEMPERATURE		
				BEFORE F	BEFORE REMOVING PRODUCT FROM OVEN AND				
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEAT		SS START	ADJ	ADJUST HEATING TIME AS REQUIRED.				
MINI	MUM HOLDING TI	ME REQU	IRED		MAXIMUM HOLDING TIME				
	none ed in "HOLD" cy				2 to 3 Hours				
DUE TO VARIATION	OBE TEMPERATURE ARE SU S IN PRODUCT QUALITY, WE	IGHT, AND DESI	RED DEGREI	E OF DONENESS, THE	соок		ERATURE MAY NEED TO BE		

ADJUSTED ACCORDINGLY. ALWAYS FOLLOW LOCAL HEALTH (HYGIENE) REGULATIONS FOR ALL INTERNAL TEMPERATURE REQUIREMENTS.

COOKIES

PRODUCT SPECIFICATIONS and PREPARATION

Premixed frozen commercial cookie dough at room temperature.

Premixed frozen commercial cookie dough pieces.

Preheat oven at 325°F (163°C) for a minimum of one hour. Line full-size sheet pans with baking pan liners. Use a number 30 scoop to produce a 1 oz (28 gm) cookie. Evenly space portioned cookie dough on sheet pans and load all pans in the oven at one time. Oven doors must remain closed during baking. DO NOT OVER-BAKE.

Approximate pan capacity: 24 cookies per full-size sheet pan.

MODELS	AS-250	500 SERIES	750 SERIES		1000 SERIES	1200 SERIES	
NUMBER OF SHELVES	3	6	6		none	none	
ITEMS PER SHELF	1 half-size sheet pan	1 half-size sheet pan	1 full-size sheet pan		1 full-size sheet pan	1 full-size sheet pan	
APPROXIMATE MAXIMUM CAPACITY	3 half-size sheet pans	6 half-size sheet pans	6 full-size sheet pa	ins	8 full-size sheet pans	8 full-size sheet pans	
PANS	18" x 13" x 1"	18" x 13" x 1"	18" x 26" x 1"		18" x 26" x 1"	18" x 26" x 1"	
PANS	(GN 1/1 x 20mm) (no shelves required)	(GN 1/1 x 20mm) (no shelves required)	(GN 1/1 x 20mm) (NO SHELVES REQUIRE		(GN 1/1 x 20mm) (ON WIRE SHELVES)	(GN 1/1 x 20mm) (on wire shelves)	
ov ov	ERNIGHT COOK & H	OLD: DOO	R VENTS:		NAL INTERNAL TEN	IPERATURE	
C ERNICH	NO	0	pen Full	AF	TER OVERRIDE:	N/A	
		то сос	OK BY TIM	E			
	ress and release control o DO NO ress the COOK key.		Fresh: 1 full 2-3 fu	 COOKING TIME TO BE SET: Fresh: 1 full-size sheet pan: 20 minutes 2-3 full-size sheet pans: 45 minutes Frozen: 1 full-size sheet pan: 30 minutes 2-3 full-size sheet pans: 45-60 minutes Cookies will continue to bake for approximately 3 minutes after being removed from the oven. Take this factor into consideration to prevent over-baking. Place 			
• Pi	ress the up and down ar poking temperature to 32		2-3 ± Cookies will 3 minutes af				
• Pi	ress the TIME key. ress the up and down ar ook time.	rows to select a	cookies on b	oake	ry rack for cooling.		
	CLOSE THE OVEN DOOR. FOR THE AUDIBLE SIG DICATE OVEN HAS PREHEAT						
MINI	MUM HOLDING T	IME REQUIRED		MA	XIMUM HOLDING	TIME	
	none				none		
TIME REQUIRE	ED IN "HOLD" CY	CLE BEFORE SERVIN	G.				
THE TIME AND PR DUE TO VARIATION	ROBE TEMPERATURE ARE S S IN PRODUCT QUALITY, WE	UGGESTED GUIDELINES ON Eight, and desired degre	LY. ALL COOKING SHO E OF DONENESS, THE C	соок	BE BASED ON INTERNAL ING TIMER OR PROBE TEMP AL TEMPERATURE REQUIREN	ERATURE MAY NEED TO BE	

DOUGHNUTS

PRODUCT SPECIFICATIONS and PREPARATION

FROZEN PRECOOKED DOUGHNUTS

Line sheet pans with baking pan liners and insert wire pan grid. Evenly space doughnuts on wire grids. Doughnuts can be heated from a thawed or fully frozen state. For more even heating, place pans with solid doughnuts toward the top of the oven compartment and doughnuts with holes toward the bottom of the compartment.

Approximate pan capacity: 30 doughnuts per full-size sheet pan

MODELS	AS-250	500 si	ERIES	750 SERIES		1000 SERIES	1200 SERIES PER COMPARTMENT
NUMBER OF SHELVES	2	4		4		none	none
ITEMS PER SHELF	1 half-size sheet pan	1 half-size s	heet pan	1 full-size sheet pan		1 full-size sheet pan	1 full-size sheet pan
APPROXIMATE MAXIMUM CAPACITY	2 half-size sheet pans	4 half-size sheet pans		4 full-size sheet p	ans	8 full-size sheet pans	8 full-size sheet pans
PANS	18" x 13" x 1" (GN 1/1 x 20mm) (NO SHELVES REQUIRED)	18" x 13 (GN 1/1 x (no shelves i	20mm)	18" x 26" x 1" (GN 1/1 x 20mm (NO SHELVES REQUIR		18" x 26" x 1" (GN 1/1 x 20mm) (on wire shelves)	18" x 26" x 1" (GN 1/1 x 20mm) (on wire shelves)
OV PRINCESS	0	R VENTS: pen Full	AF	NAL INTERNAL TEN TER OVERRIDE: 100° to 11	MPERATURE 10°F (38° to 43°C)		
		тс		OK BY TIN	1E		
		DO NOT A OVEN FOR Set an indep	COOKING TIME TO BE SET: 2-1/2 hours DO NOT ALLOW THE PRODUCT TO REMAIN IN THE OVEN FOR THE FULL SET COOKING TIME. Set an independent timer (or mechanical bill timer on equipped models) using the following guidelines:				
	t a rs.	TEMPERAT removing pr required. Remove from has been rea	45 to 60 minutes MAKE CERTAIN PRODUCT REACHES THE FULLY HEATED TEMPERATURE. Check internal product temperature before removing product from oven and adjust heating time as required. Remove from oven as soon as the required internal temperature has been reached. Glaze while still warm. Immediately place glazed doughnuts in a heated display case.				
<u> </u>	DICATE OVEN HAS PREHEA				MA	XIMUM HOLDING	TIME
			4 to 6 Hours				

ADJUSTED ACCORDINGLY. ALWAYS FOLLOW LOCAL HEALTH (HYGIENE) REGULATIONS FOR ALL INTERNAL TEMPERATURE REQUIREMENTS.

DOUGH PROOFING

PRODUCT SPECIFICATIONS and PREPARATION

For use with dough in the form of loaves or rolls as required. Capacities shown are provided as a general guideline only and will depend on the size and shape of the selected items to be proofed. Additional wire shelves may be required for maximum capacities shown below.


OPTION:

For added humidity, add approximately 2 cups (0,24 liter) of water in the drip pan located at the bottom of the oven.

MODELS	AS-250	500 si	ERIES	7	50 SERIES	5	1000 SERIES	1200 SERIES	
NUMBER OF SHELVES	3	6			6		none	none	
ITEMS PER SHELF	1 half-size sheet pan	1 half-size s	sheet pan	1 ful	1 full-size sheet pan		1 full-size sheet pan	1 full-size sheet pan	
APPROXIMATE MAXIMUM CAPACITY	3 half-size sheet pans	6 half-size sheet pans 6		6 full	l-size sheet pa	ans	8 full-size sheet pans	8 full-size sheet pans	
PANS	18" x 13" x 1" ON SHELVES (GN 1/1: 530 x 325 x 20mm)			(GN 2/	26" x 1" on shi 1: 530 x 650 x 20 shelves required	mm)	18" x 26" x 1" (GN 1/1: 530 x 325 x 20mm) (ON WIRE SHELVES)	18" x 26" x 1" (GN 1/1: 530 x 325 x 20mm (ON WIRE SHELVES)	
OV ERNIGHT OV		R VE			NAL INTERNAL TEN TER OVERRIDE:	IPERATURE N/A			
Т				ТС	соок ву	ΓΙΜΕ			
				• Pre	ss and release control ON	ı∕OFF key.			
	PRODUCT PROBE CANNOT BE USED FOR DOUGH PROOFING.					 Press the HOLD key. Press the up and down arrows to set the holding temperature to 90° TO 100°F (32° to 38°C). 			
OVERRIDE	ALLOWANCE:				Соок Ортезь the COOK key.				
PROBE					 Press the TIME key. Press the up and down arrows to set the time based on size and quantity of dough, generally, 45 to 90 mintues. 				
		r r	CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS						
MIN	IMUM HOLDING T	IME REQU	JIRED		MAXIMUM HOLDING TIME				
TIME REQUIRI	N/A ed in "HOLD" cy	CLE BEFOR	E SERVIN	G.			N/A		
							BE BASED ON INTERNAL		

PROCEDURE BLANK: ELECTRONIC OVEN COOKING

PRODUCT SPECIFICATIONS and PREPARATION



SMOKER OPERATION

COOKING • SMOKING • HOLDING PROCEDURES

1. PREPARE UNIT FOR COOKING

- A. Insert and adjust the required number of shelves inside the cooking cavity.Insert each shelf with curved edge of the shelf toward the back of the oven.
- B. Adjust the inside door vents as indicated in the individual cooking procedure selected.

NOTE: ALWAYS KEEP DOOR VENTS CLOSED WHEN COOKING WITH THE SMOKING FUNCTION.

C. Insert drip pan on the bottom surface of the oven cavity.

2. PREHEAT OVEN



- соок С. Рге "Р
- B. Press and set "COOK" thermostat to required cooking temperature.

A. Press power switch "ON."

C. Press and set "PROBE" or "TIME."



D. Press and set "**HOLD**" thermostat to required holding temperature.

The oven is automatically programmed to ((preheat to the set cooking temperature. The oven will produce an audible signal when fully preheated.



SMOKING TIMES

It is recommended the operator be familiar with the taste preferences of the area. Initially experimenting with a minimal amount of smoking time is suggested. LIGHT SMOKE FLAVOR 10 MINUTES MEDIUM SMOKE FLAVOR 30 MINUTES HEAVY SMOKE FLAVOR 40 MINUTES VERY HEAVY SMOKE FLAVOR 60 MINUTES* EXTRA HEAVY SMOKE FLAVOR 80 MINUTES*

*FOR A SMOKING TIME OVER 60 MINUTES: Reload wood chip container and activate smoking timer as needed.

SMOKER OPERATION

COOKING • SMOKING • HOLDING PROCEDURES HOT SMOKE

3. PREPARE PRODUCT FOR COOKING

A. Refer to individual cooking instructions.

4. PREPARE WOOD CHIPS

A. Take one container load of dry wood chips and soak the chips in water for 5 to 10 minutes.



- B. Shake excess water off wood chips.
- C. Remove Wood Chip Container from the interior back panel of the smoker. Place the moistened chips in the Wood Chip Container and replace the container in the oven.

5. LOAD PRODUCT ON SHELVES

- A. Refer to individual cooking instructions.Do NOT overload the oven.
- B. Most meat products are cooked directly on wire shelves. For many products, the use of pans is not recommended. See individual product guidelines for recommendations.

6. SET SMOKING TIMER

The Smoking Timer activates the heating element located within the Wood Chip Container. When the Wood Chip Container is full, the heating element can be activated to produce smoke for a period of approximately 1 hour.

TO SET SMOKING FUNCTION:



- Press the SMOKER KEY.
- Press the up △ and down ▽ arrow keys to select the smoke time in minutes.



7. OVERNIGHT COOK AND HOLD

For maximum product tenderizing and to reduce labor during peak preparation hours, it is highly recommended that many products be cooked and held overnight. Refer to individual cooking instructions.

SMOKER OPERATION

COOKING • SMOKING • HOLDING PROCEDURES

COLD SMOKE

THE OVEN MUST BE AT ROOM **TEMPERATURE BEFORE BEGINNING** THE COLD SMOKE PROCEDURE.



A. Press power switch "ON."



- B. Press HOLD KEY.
 - Press the up \triangle and down \bigtriangledown arrow keys to set HOLD temperature to 32°F (0°C).



- C. Press and hold the "SMOKER" key for approximately 5 seconds until an audible signal (beep) is heard and smoke time is displayed.
 - Press the up \triangle and down \bigtriangledown arrow keys to select the smoke time in minutes.



- D. Insert sanitized PROBE into the product and allow temperature of probe to reach product temperature (approximately 10 seconds).
- - E. Press PROBE KEY.
 - Press the up \triangle and down \bigtriangledown arrow keys to set PROBE temperature to 50°F (10°C).





NOTE: If probe temperature is above the set probe temperature of 50° F (10° C), the probe light will flash and the unit will beep 3 times every 15 seconds to alert the operator to a product over temperature condition.

THE USE OF IMPROPER MATERIALS FOR THE SMOKING

FUNCTION COULD RESULT IN DAMAGE, HAZARD, EQUIPMENT FAILURE OR COULD REDUCE THE OVERALL LIFE OF THE OVEN. DO NOT USE SAWDUST FOR SMOKING. DO NOT USE WOOD CHIPS SMALLER THAN THUMBNAIL SIZE.

***OVEN DEFAULT TEMPERATURE ADJUSTMENT**

• Holding the SMOKER KEY for 5 seconds will set the oven to a default temperature of 60°F (16°C) to prevent the oven from producing heat.



TO INCREASE THE DEFAULT TEMPERATURE: Press the HOLD KEY and press the up \triangle arrow to set a higher default temperature.



ELECTRONIC SMOKING OVEN COOKING GUIDELINES SMOKED BEEF BRISKET **PRODUCT SPECIFICATIONS and PREPARATION** MODEL 767-SK/III, 1767-SK/III SHELVES Beef Brisket, Fresh: 9 to 13 lb (4 to 6 kg) 3 PER COMPARTMENT Season brisket as desired. Place brisket directly on wire shelves, fat side down. Briskets can also be wrapped in ITEMS clear plastic wrap for the cooking, smoking, and holding 3 to 4 roasts PER SHELF function (OPTIONAL). MAXIMUM 12 roasts NOTE: Due to the density of this cut of meat a up to 100 lb (45 kg) CAPACITY smoking time of 1 hour will provide a medium smoke flavor. PAN none USAGE **OVERNIGHT COOK & HOLD:** DOOR FINAL INTERNAL TEMPERATURE: VENTS: 165°F (73°C) Highly Recommended ERNIGH Closed AT END OF OVERRIDE PERIOD TO COOK BY PROBE то соок ву тіме • Press and release control ON/OFF key. • Press and release control ON/OFF key. Œ • Press the COOK key. • Press the COOK key. • Press the up and down arrows to set the • Press the up and down arrows to set the cooking temperature to 250°F (121°C). cooking temperature to 250°F (121°C). • Press the TIME key. OVERRIDE ALLOWANCE: 6°F (3,3°C) • Press the up and down arrows to set the time to 20 minutes per pound for the first • Insert the product probe. roast (44 minutes per kilogram)

Press the PROBE key.
Press the up and down arrows

- Press the up and down arrows to set the probe temperature to 160°F (71°C).
- Press the HOLD key.
 Press the up and down arrows to set the holding temperature to 160°F (71°C).
- Press the SMOKER key.
 Press the up and down arrows to set the smoke time to 1 hour.

CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED.

MINIMUM HOLDING TIME REQUIRED

6 Hours

TIME REQUIRED IN "HOLD" CYCLE BEFORE SERVING.


plus

Press the HOLD key.
Press the up and down arrows to set the holding temperature to 160°F (71°C).

add 30 minutes for each additional roast.



- Press the SMOKER key.
- Press the up and down arrows to set the smoke time to 1 hour.





24 Hours

THE TIME AND PROBE TEMPERATURE ARE SUGGESTED GUIDELINES ONLY. ALL COOKING SHOULD BE BASED ON INTERNAL PRODUCT TEMPERATURES. DUE TO VARIATIONS IN PRODUCT QUALITY, WEIGHT, AND DESIRED DEGREE OF DONENESS, THE COOKING TIMER OR PROBE TEMPERATURE MAY NEED TO BE ADJUSTED ACCORDINGLY. ALWAYS FOLLOW LOCAL HEALTH (HYGIENE) REGULATIONS FOR ALL INTERNAL TEMPERATURE REQUIREMENTS.


ぶ


START


SMOKED FRESH HAMS **PRODUCT SPECIFICATIONS and PREPARATION** MODEL 767-SK/III, 1767-SK/III SHELVES **Pork Fresh Ham:** 14 to 17 lb (6 to 8 kg) 2 PER COMPARTMENT Season as desired and place hams directly on wire shelves. ITEMS 3 to 4 hams PER SHELF **NOTE:** This product requires 3 to 4 smoke cycles of 1 hour each with a full wood chip container for MAXIMUM 6 to 8 hams each cycle. Press the SMOKER key and up to 100 lb (45 kg) CAPACITY reset the smoke timer to one hour for each cycle. PAN none USAGE DOOR **OVERNIGHT COOK & HOLD:** FINAL INTERNAL TEMPERATURE: VENTS: 160°F (71°C) Optional Closed ERNIG AT END OF OVERRIDE PERIOD TO COOK BY PROBE то соок ву тіме • Press and release control ON/OFF key. • Press and release control ON/OFF key. (I)T • Press the COOK key. • Press the COOK key. • Press the up and down arrows to • Press the up and down arrows set the cooking temperature to to set the cooking temperature 250°to 275°F (121°to 135°C). to 250°to 275°F (121°to 135°C). • Press the TIME key. OVERRIDE ALLOWANCE: 12°F (7°C) • Press the up and down arrows to set the time to 12 minutes per pound for the first • Insert the product probe. ham (26 minutes per kilogram) • Press the PROBE key. plus. • Press the up and down arrows to set the add 30 minutes for each additional ham. probe temperature to148°F (64°C). • Press the HOLD key. • Press the HOLD key. • Press the up and down arrows to set the • Press the up and down arrows to set the holding temperature to 160°F (71°C). holding temperature to 160°F (71°C). • Press the SMOKER key. • Press the SMOKER key. Press the up and down arrows to set the Press the up and down arrows to set the smoke time to 1 hour for each cycle smoke time to 1 hour for each cycle as as indicated above. indicated above. CLOSE THE OVEN DOOR. CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS ゟ WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED. TO INDICATE OVEN HAS PREHEATED. START MINIMUM HOLDING TIME REQUIRED MAXIMUM HOLDING TIME 2 Hours 10 Hours TIME REQUIRED IN "HOLD" CYCLE BEFORE SERVING. THE TIME AND PROBE TEMPERATURE ARE SUGGESTED GUIDELINES ONLY. ALL COOKING SHOULD BE BASED ON INTERNAL PRODUCT TEMPERATURES.


DUE TO VARIATIONS IN PRODUCT QUALITY, WEIGHT, AND DESIRED DEGREE OF DONENESS, THE COOKING TIMER OR PROBE TEMPERATURE MAY NEED TO BE

ADJUSTED ACCORDINGLY. ALWAYS FOLLOW LOCAL HEALTH (HYGIENE) REGULATIONS FOR ALL INTERNAL TEMPERATURE REQUIREMENTS.












SMOKED SALMON **PRODUCT SPECIFICATIONS and PREPARATION** MODEL 767-SK/III, 1767-SK/III SHELVES Salmon, Whole: 8 to 10 lb (4 to 5 kg) 2 PFR COMPARTMENT Scale and wash fish thoroughly. If desired, fish can be ITEMS placed in a salt brine and refrigerated for 2 to 3 hours. 1 full-size sheet pan Place fish upright on sheet pans. PER SHELF MAXIMUM DO NOT LAY FISH ON ITS SIDE. 3 full-size sheet pans 6 whole salmon CAPACITY *NOTE: Fill wood chip container and set smoke timer twice for a 2-hour, heavy smoke PAN 18" x 26" x 1" flavor $(GN 2/1 \times 20 \text{mm no shelves})$ USAGE **OVERNIGHT COOK & HOLD:** DOOR FINAL INTERNAL TEMPERATURE: VENTS: 150°F (66°C) Not Recommended ERNIGH Closed AT END OF OVERRIDE PERIOD TO COOK BY PROBE то соок ву тіме • Press and release control ON/OFF key. • Press and release control ON/OFF key. (1) • Press the COOK key. • Press the COOK key. • Press the up and down arrows to set the • Press the up and down arrows to set the cooking temperature to 275°F (135°C). cooking temperature to 275°F (135°C). OVERRIDE ALLOWANCE: 35°F (19°C) • Press the TIME key. • Press the up and down arrows to set the • Insert the product probe. cooking time to 2 to 2-1/2 hours. • Press the PROBE key. • Press the up and down arrows to set the probe temperature to 115°F (46°C). • Press the HOLD key. • Press the HOLD key. • Press the up and down arrows to set the • Press the up and down arrows to set the holding temperature to 160°F (71°C). holding temperature to 160°F (71°C). • Press the SMOKER key. • Press the SMOKER key. • Press the up and down arrows to set the smoke time to 1 hour for mild* smoke flavor. • Press the up and down arrows to set the smoke time to 1 hour for mild* smoke flavor. CLOSE THE OVEN DOOR. CLOSE THE OVEN DOOR. WAIT FOR THE AUDIBLE SIGNAL PRESS ぶ WAIT FOR THE AUDIBLE SIGNAL PRESS TO INDICATE OVEN HAS PREHEATED. START TO INDICATE OVEN HAS PREHEATED. MINIMUM HOLDING TIME REQUIRED MAXIMUM HOLDING TIME 1 to 2 Hours 10 Hours TIME REQUIRED IN "HOLD" CYCLE BEFORE SERVING. THE TIME AND PROBE TEMPERATURE ARE SUGGESTED GUIDELINES ONLY. ALL COOKING SHOULD BE BASED ON INTERNAL PRODUCT TEMPERATURES. DUE TO VARIATIONS IN PRODUCT QUALITY, WEIGHT, AND DESIRED DEGREE OF DONENESS, THE COOKING TIMER OR PROBE TEMPERATURE MAY NEED TO BE

ADJUSTED ACCORDINGLY. ALWAYS FOLLOW LOCAL HEALTH (HYGIENE) REGULATIONS FOR ALL INTERNAL TEMPERATURE REQUIREMENTS.







COLD SMOKED SALMON

PRODUCT SPECIFICATIONS and PREPARATION

SAUMON FUME

Fresh Salmon Fillets: 2-1/2 to 4 lb (1 to 2 kg) each

INGREDIENTS REQUIRED

Fresh Salmon Fillets or Sides Sea Salt: Large Crystals Granulated Sugar or

Brown Sugar (for best color)



WOOD CHIP CONTAINER: FULL

DOOR VENTS: CLOSED

SUPPLIES REQUIRED

Clear Plastic Wrap

Paper Toweling Wire Mesh Grids

Tweezers

Ice: 3 to 4 lb (1 to 2 kg)

PREPARATION

Remove bones from fillets with a tweezers to avoid rupturing tissue.

SALTING

50% Sea Salt or Kosher Salt

50% Granulated or Brown Sugar


To remove moisture from the raw salmon, blend salt and sugar mixture thoroughly and pack firmly around each fillet. Cover salt-filled pans with clear plastic wrap and refrigerate for 24 hours. Following the 24 hour refrigeration period, remove fillets from salt/sugar mixture and rinse thoroughly under cold, running water. Pat dry with paper toweling. Place fillets sideby-side on a sheet pan and return, uncovered, to the refrigerator for a period of 6 hours for the final drying period.


OVEN MUST BE AT ROOM TEMPERATURE BEFORE BEGINNING THE COLD SMOKE PROCEDURE.

Soak wood chips in water according to directions (5 to 10 minutes), fill wood chip container full and insert in chip holder located at the back of the oven.

Fill pan with ice and locate pan in shelf position number 7 (just above wood chip container).

Place prepared salmon fillets on a wire grid as indicated on the diagram and insert wire grid on oven shelf beginning with the top shelf position.





Insert product probe into the center of the middle salmon fillet located in the top shelf position, or central shelf position when smoking a full load. To maintain proper color, the internal temperature of the salmon must not exceed 77°F (25°C). For this reason, it is important to begin the smoking process with the oven at room temperature.

Make certain oven vents are closed. Close oven door and set the SMOKE TIMER for 10 to 20 minutes depending on taste preference. Smoke time operates concurrently with oven time. The fillets must remain in the oven for a total period of 2 hours. Do not open the oven door during this 2 hour period.

Following the required oven time, remove the fillets, cover with clear plastic wrap and refrigerate until fully chilled.

FOOD HOLDING - FUNCTION & VALUE

In the previous sections, cooking procedures in the Halo Heat Low Temperature Cooking and Holding Oven have been emphasized. If practical to the individual food service operation, these ovens can also be used without the cooking function to hold foods at proper serving temperatures. Individual holding cabinets can also be used to accomplish this function.

Food production in most food service facilities is accomplished in a variety of different cooking equipment. Food quality can be easily lost between the time a product is removed from an oven and the time of direct service. Regardless of the method of preparation, proper handling of food within this time period is of critical importance to the food service operator. Halo Heat hot food holding equipment is able to support any type of food preparation by extending the longest possible holding life for the widest variety of products.

For maximum efficiency, hot food holding equipment should be selected on the basis of the full range of functions this equipment can provide to the individual operation. For example, dough proofing, bulk food holding for buffet service or other situations, and the transportation of hot foods are some of the major functions of these cabinets for multi-purpose utility. When properly planned, Halo Heat holding equipment can be a time management aid, support the food service operation by extending preparation times outside of peak preparation hours, and provide a quality product in prolonged holding situations.

Consult an Alto-Shaam representative for information on compatible holding equipment or for recommendation on full systems tailored to meet specific requirements.



GENERAL HOLDING GUIDELINES

Chefs, cooks and other specialized food service personnel employ varied methods of cooking. Proper holding temperatures for a specific food product must be based on the moisture content of the product, product density, volume, and proper serving temperatures. Safe holding temperatures must also be correlated with palatability in determining the length of holding time for a specific product.

Halo Heat maintains the maximum amount of product moisture content without the addition of water, water vapor, or steam. Maintaining maximum natural product moisture preserves the natural flavor of the product and provides a more genuine taste. In addition to product moisture retention, the gentle properties of Halo Heat maintain a consistent temperature throughout the cabinet without the necessity of a heat distribution fan, thereby preventing further moisture loss due to evaporation or dehydration.

In an enclosed holding environment, too much moisture content is a condition which can be relieved. A product achieving extremely high temperatures in preparation must be allowed to decrease in temperature before being placed in a controlled holding atmosphere. If the product is not allowed to decrease in temperature, excessive condensation will form increasing the moisture content on the outside of the product. To preserve the safety and quality of freshly cooked foods however, a maximum of 1 to 2 minutes must be the only time period allowed for the initial heat to be released from the product.

Most Halo Heat holding equipment is provided with a thermostat control between 60° and 200°F (16° to 93°C). If the unit is equipped with vents, close the vents for moist holding and open the vents for crisp holding.

If the unit is equipped with a thermostat indicating a range of between 1 and 10, use a metalstemmed, indicating thermometer to measure the internal temperature of the product(s) being held. Adjust the thermostat setting to achieve the best overall setting based on internal product temperature.

GENERAL HOLDING CABINET OPERATION

PREHEAT THE HOLDING CABINET
 200°F (93°C) FOR 30 MINUTES

When the thermostat is turned clockwise to an "**ON**" position, the red indicator light will illuminate and will remain lit as long as the unit is calling for heat. Allow a minimum of 30 minutes of preheating before loading the holding cabinet with food. The red indicator light will go "**OUT**" after approximately 30 minutes preheat time, or when the air temperature inside the unit reaches the temperature set by the operator. Verify the full preheated temperature with the holding temperature gauge located on the control panel of the cabinet.

2. LOAD THE CABINET WITH HOT FOOD ONLY.

The purpose of the holding cabinet is to maintain hot food at proper serving temperature.

Only HOT food should be placed into the cabinet.

Before loading the cabinet with food, use a food thermometer to make certain all products are at an internal temperature range of 140° to 160°F (60° to 71°C). Any food product not within the proper temperature range should be heated before loading into the holding cabinet.

3. RESET THE THERMOSTAT TO 180°F (82°C).

Make certain the cabinet doors are securely closed, and reset the thermostat to 180° F (82° C).

THIS WILL NOT NECESSARILY BE THE FINAL SETTING.

Proper temperature range for the products being held will depend on the type and quantity of product. When holding food for prolonged periods, it is advisable to periodically check the internal temperature of each item with a food thermometer to assure maintenance of the proper temperature range of 140° to 200°F (60° to 93°C).

HOLDING TEMPERATURE RANGE

HOLDING IEM	PERATURE	RANGE	
MEAT	FAHRENHEIT	CELSIUS	
BEEF ROAST — Rare	130°F	54°C	
BEEF ROAST — Med/Well Done	155°F	68°C	
BEEF BRISKET	160° — 175°F	71° — 79°C	
CORN BEEF	160° — 175°F	71° — 79°C	
PASTRAMI	160° — 175°F	71° — 79°C	
PRIME RIB — Rare	130°F	54°C	
STEAKS — Broiled/Fried	140° — 160°F	60° — 71°C	
RIBS — Beef or Pork	160°F	71°C	
VEAL	160° — 175°F	71° — 79°C	
НАМ	160° — 175°F	71° — 79°C	
PORK	160° — 175°F	71° — 79°C	
LAMB	160° — 175°F	71° — 79°C	
POULTRY			
CHICKEN — Fried/Baked	160° — 175°F	71° — 79°C	
DUCK	160° — 175°F	71° — 79°C	
TURKEY	160° — 175°F	71° — 79°C	
GENERAL	160° — 175°F	71° — 79°C	
FISH/SEAFOOD			
FISH — Baked/Fried	160° — 175°F	71° — 79°C	
LOBSTER	160° — 175°F	71° — 79°C	
SHRIMP — Fried	160° — 175°F	71° — 79°C	
BAKED GOODS			
BREADS/ROLLS	120° — 140°F	49° — 60°C	
MISCELLANEOUS	-		
CASSEROLES	160° — 175°F	71° — 79°C	
DOUGH — Proofing	80° — 100°F	27° — 38°C	
EGGS —Fried	150° — 160°F	66° — 71°C	
FROZEN ENTREES	160° — 175°F	71° — 79°C	
HORS D'OEUVRES	160° — 180°F	71° — 82°C	
PASTA	160° — 180°F	71° — 82°C	
PIZZA	160° — 180°F	71° — 82°C	
POTATOES	180°F	82°C	
PLATED MEALS	140° — 165°F	60°— 74°C	
SAUCES	140° — 200°F	60° — 93°C	
SOUP	140° — 200°F	60° — 93°C	
VEGETABLES	160° — 175°F	71° — 79°C	
THE HOLDING TEMPERATURES LISTED ARE SUGGESTED			
GUIDELINES ONLY. ALL FOOD HOLDING SHOULD BE BASED ON INTERNAL PRODUCT TEMPERATURES. ALWAYS FOLLOW LOCAL HELATH (HYGIENE) REGULATIONS FOR ALL INTERNAL TEMPERATURE REQUIREMENTS.			

SANITATION and HANDLING

Food flavor and aroma are usually so closely related it is difficult, if not impossible, to separate them. There is also an important, inseparable relationship between cleanliness and food flavor. Cleanliness, top operating efficiency, and appearance of equipment contribute considerably to savory, appetizing foods. Good equipment that is kept clean, works better and lasts longer.

Most food imparts its own particular aroma and many foods also absorb existing odors. Unfortunately, during this absorption, there is no distinction between GOOD and BAD odors. The majority of objectionable flavors and odors troubling food service operations are caused by bacteria growth. Sourness, rancidity, mustiness, stale or other OFF flavors are usually the result of bacterial activity.

The easiest way to insure full, natural food flavor is through comprehensive cleanliness. This means good control of both visible soil (dirt) and invisible soil (microorganisms). Clean surfaces don't smell. This is a basic and important fact to assure good quality in food of all kinds.

A thorough approach to sanitation will provide essential cleanliness. It will assure an attractive appearance of equipment, along with maximum efficiency and utility. More importantly, a good sanitation program provides one of the key elements in the prevention of food-borne illnesses.

A controlled holding environment for prepared foods is just one of the important factors involved in the prevention of foodborne illnesses. Temperature monitoring and control during receiving, storage, preparation and the service of foods are of equal importance. The most accurate method of measuring safe temperatures of both hot and cold foods is by internal product temperature. A quality thermometer is an effective tool for this purpose and should be routinely used on all products that require holding at a specific temperature.

HOT FOODS		
40° to 140°F	DANGER ZONE	4° to 60°C
70° to 120°F	CRITICAL ZONE	21° to $49^\circ C$
140° to 165°F	SAFE ZONE	60° to $74^\circ C$
COLD FOODS		
ABOVE 40°F	DANGER ZONE	ABOVE 4°C
40°F or BELOW	SAFE ZONE 4	4°C or BELOW
FROZEN FOODS		
ABOVE 32°F	DANGER ZONE	ABOVE 0°C
0° to 32°F	CRITICAL ZONE	-18° to 0°C
0°F or BELOW	SAFE ZONE -1	18°C or BELOW

A comprehensive sanitation program should focus on the training of staff in basic sanitation procedures. This includes personal hygiene, proper handling of raw foods, cooking to a safe internal product temperature, and the routine monitoring of internal temperatures from receiving through service. Personal cleanliness is generally the most difficult field to control. Rigid rules of personal hygiene and practice must be instituted and maintained with standards set at the highest levels.


Most food-borne illnesses can be prevented through proper temperature control and a comprehensive program of sanitation. All these factors are important to build quality service as the foundation of customer satisfaction.

FOOD SAFETY GUIDELINES

Safe food handling practices to prevent foodborne illness is of critical importance to the health and safety of your customers. HACCP, an acronym for Hazard Analysis (at) Critical Control Points, is a quality control program of operating procedures to assure food integrity, quality, and safety. Taking steps necessary to augment food safety practices are both cost effective and relatively simple. While HACCP guidelines go far beyond the scope of this booklet, additional information is available by contacting the USDA/FDA Food-borne Illness Education Information Center.

All heated food must be maintained at $140^{\circ}F$ to $150^{\circ}F$ (60°C to 65°C) after being heated. Foods that have been heated followed by refrigerated storage must be reheated to a minimum of $165^{\circ}F$ (74°C) to prevent bacteria growth.

- All stored food items must be covered and placed in a cooler or freezer at a minimum height of 6-inches (152mm) above the floor.
- Employees serving food, preparing food, or washing utensils must wear an effective hair covering.
- Employees must wash their hands before serving or preparing food.
- Soap and towels must be provided at the hand-sink which must only be used for washing hands.
- No smoking or use of tobacco products is allowed in the food preparation or service area.
- All serving containers must be stored with food contact surfaces covered or in the down position.
- All utensils must be washed in a threecompartment sink and dipped in a final sanitation rinse. A pH test kit must be used to check the rinse water.
- Food preparation surfaces must not be used for the storage of non-food items.
- All cold food must be stored at or below 40°F (4°C).
- Frozen foods must not be thawed at room temperature or in water. Use the cooler for thawing and thaw foods slowly.



SUMMARY

In the United States, the Food and Drug Administration has a published Food Code as a reference guide for the prevention of food-borne illness in retail outlets such as restaurants, institutions, and grocery stores. Provisions of this Food Code are compatible with the concept and terminology of Hazard Analysis (at) Critical Control Points (HACCP) and contains expanded provisions for food safety. The FDA publication, along with local codes, should be the final word with regard to all issues regarding food safety and sanitation in the U.S. For more information contact:

Center for Food Safety and Applied Nutrition Food and Drug Administration PHONE: 1-888-SAFEFOOD www.foodsafety.gov

COOKING NOT	ES
Your Service H 1-800-558-2	Alto-Shaam has established a twenty-four hour emergency service call center to offer immediate customer access to a local authorized service agency outside of standard business hours. The emergency service access is provided exclusively for Alto-Shaam equipment and is available throughout the United States through the use of Alto-Shaam's toll-free number. Emergency service access is available seven days a week including holidays.



W164 N9221 Water Street • P.O. Box 450 • Menomonee Falls, Wisconsin 53052-0450 • U.S.A. PHONE: (262)251-3800 (800)558-8744 u.s.a./canada • FAX: (262)251-7067 (800)329-8744 u.s.a. • www.alto-shaam.com

Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website <u>http://myh66.com</u> <u>http://usermanuals.us</u> <u>http://www.somanuals.com</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.cc</u> <u>http://www.4manuals.com</u> <u>http://www.404manual.com</u> <u>http://www.luxmanual.com</u> <u>http://aubethermostatmanual.com</u> Golf course search by state

http://golfingnear.com Email search by domain

http://emailbydomain.com Auto manuals search

http://auto.somanuals.com TV manuals search

http://tv.somanuals.com