

BOSE® MIE2 MOBILE HEADSET

Owner's Guide | Brugervejledning | Bedienungsanleitung Guía de usuario | Notice d'utilisation | Manuale di istruzioni Gebruiksaanwijzing | Bruksanvisningen Podręcznik użytkownika | Felhasználói útmutató Omistajan opas | คู่มือผู้ใช้ | 사용자 안내서 | 用户指南 使用者指南 | オーナーズガイド | と此 | Charles |

Welcome

Thank you for purchasing the Bose® MIE2 mobile headset. The Bose® MIE2 mobile headset offers a combination of lifelike audio and communications performance and comfortable fit not available from most conventional earbuds.


Register your product

Now is a good time to register your headset. You can do this easily by going to http://global.Bose.com/register.



This product conforms to all EU Directive requirements as applicable by law. The complete Declaration of Conformity can be found at www.Bose.com/compliance.

WARNING: DO NOT use mobile phone adapters to connect headset to airplane seat jacks as this could result in personal injury such as burns or property damage due to overheating. Remove and disconnect immediately if you experience warming sensation or loss of audio.





*Headset comes with medium StavHear™ tips attached

©2010 Bose Corporation. No part of this work may be reproduced, modified, distributed, or otherwise used without prior written permission. All trademarks referenced herein are property of Bose Corporation.

FNGLISH

.

Download from Www.Somanuals.com. All Manuals Search And Download.

Connecting to a mobile phone or audio device

You can connect the headset to your mobile phone with either the 3.5 mm stereo plug (compatible with standard headphone jacks) or by using one of the two included 2.5 mm adapter cables if needed.

The correct connection should allow:

- Stereo sound to be heard during music playback and communications
- Your voice to be heard by the person on the other end of a phone call
- The Answer/End button to operate as expected

Compatible with many music-enabled mobile phones. Refer to the enclosed compatibility list or visit www.Bose.com/phones for the latest list of compatible phones.

Without adapter

If your phone has a 3.5 mm headphone/headset jack, you do not need to use the included adapters.



Device with 3.5 mm headphone/ headset jack

- Plug the headset into the headphone/headset jack on the phone.
- 2. Put on the headset.



With adapter

The Bose MIE2 mobile headset includes two unique phone adapters. Each is identified by a small symbol (circle, triangle) on the top of the plug.


If your phone has a 2.5 mm headphone/headset jack, you will need to use one of these adapters

- Select the appropriate adapter
- Attach the adapter to the headset cable.
- Plug the headset with the adapter into the headphone/ headset jack on the phone.
- Put on the headset.

Note: If your phone does not respond when you press the Answer/End button, you are getting partial or no sound, or the microphone is not picking up soul

microphone is not picking-up sound, you may be using the wrong adapter. Try the other adapter and check again. Refer to www.Bose.com/phones to determine which adapter is compatible with your phone.

Device with 2.5 mm headphone/ headset jack



Answering and ending calls

The Bose® MIE2 mobile headset includes an easy to access Answer/End button with integrated microphone. Simply press the Answer/End button to perform an action.


Note: Some phones may require you to press twice or press and hold the Answer/End button for a few seconds to perform functions.

Answering calls

When you receive an incoming call, press and release the Answer/End button to answer.

Ending calls

When you are ready to end your call, press and release the Answer/End button



Using a single earpiece

The Bose® MIE2 mobile headset can be used with only the right (R) earpiece in your ear. This allows you to take calls and still hear surrounding sounds.

Importance of Proper Fit

When you wear the headset properly, it provides the comfort and clarity you expect from Bose®.

Fitting the headphones to your ear

The headphone earpiece has a soft StayHear™ tip attached, allowing it to rest comfortably in the bowl of your ear. The wing part of the tip fits just under your ear ridge.

Note: Each tip is marked with either an L or an R to indicate which earpiece it is for. Be sure to attach the left StayHear™ tip to the left earpiece and the right StayHear™ tip to the right earpiece.



To determine if the tip is the right size:

- 1. Insert the earpiece into the canal just enough
- for the headphone to rest lightly against your ear.

 2. Tilt the headphone back and press the tip wing under the ear ridge until it is secure.

The tips should fit comfortably yet securely in the bowl of the ear.






Changing ear tips

Select the type and size of eartip that provides you with the best comfort and fit

- 1. Gently peel the edges of the attached tip away from the earpiece, using care not to tear the tip.
 - CAUTION: To prevent damage, do not pull on the StavHearTM tip wing.
- 2. Position the opening of the new tip over the nozzle and the small slot over the nozzle book

Note: Fach tip is marked with either an L or an R to indicate which earniece it is for. Be sure to attach the left StavHear™ tip to the left earpiece





secured

StavHear™ tins









Adjusting for comfort and stability

There are several ways you can adjust your headset to provide additional comfort and stability. Using the adjustment slider and clothing clip you can customize how you wear your headset

Using the adjustment slider

Move the adjustment slider up or down to reduce or increase the amount of loose cord. between the left and right earpiece. Finding the right position for the slider can help optimize the placement of the Answer/End button and integrated microphone.



Using the clothing clip

Use the clothing clip to fasten the cable to your clothing, for convenience, stability, and to help manage the cable. This can be helpful during high-movement activities or when using the headset in a single earpiece configuration.



TroubleshootingIf you experience any trouble using your headset, try the following troubleshooting instructions. If you still need help, see the contact information on the inside back cover for assistance in your area.

Problem What to do

No audio/intermittent	Make sure that the headset plug is securely connected to the headphone/headset jack (not the line out jack). Try another audio device.
Sound is coming from only one earpiece	Make sure you are using the correct mobile phone adapter and that it is securely connected. Unplug the headset from the audio source, then plug back in making sure they are securely connected. Try another audio device.
Incoming call ring tone not heard through headset	 Make sure your phone is set to pass the ring tone through to the headset. Check your phone settings and make adjustments as needed.
	Note: This feature may not be available on all phones.
Excessive bass	Turn off any audio enhancement features on the audio source.
Low volume/poor audio	Turn off any "sound checker" or other audio signal altering features on the audio source. Make sure ear tips and headset nozzles are clear of any debris or wax build-up. Make sure the volume level of the audio source is turned up.
Microphone is not picking-up sound	Make sure you are using the correct mobile phone adapter and that it is securely connected. Make sure the microphone is not being blocked or covered. The microphone is located on the back of the Answer/End button (you may notice the small opening for the microphone).
Phone not responding when Answer/End button is pressed	Make sure you are using the correct mobile phone adapter and that it is securely connected.
	Note: Some phones may require you to press and hold the Answer/End button for a few seconds to perform functions.
Phone unexpectedly ends call	Some phones will end a call if the headset is unplugged during a call. Make sure that the headset plug is securely connected to the headphone/headset jack. Check phone signal strength to ensure network coverage.
Ear tips falling off	Make sure the ear tips are securely attached to the earpiece and nozzle hook.
Lost ear tip	Visit owners.Bose.com for replacement tips.
Sound is muffled from earpiece	Make sure ear tips and headset nozzles are clear of any debris or wax build-up. Unplug the headset from the audio source, then plug back in making sure they are securely connected. Try another audio device.

Cleaning

Your headset may require periodic cleaning:

- Ear tips: First, remove them from the headset and wash the tips with a mild detergent and water. Make sure you thoroughly rinse and dry them before putting them back on the headset.
- Headset nozzles, Microphone, Answer/End button: Clean only with a dry, soft cotton swab or equivalent. Never insert any cleaning tool into the nozzle or microphone opening.

WARNINGS:

 Contains small parts which may be a choking hazard Not suitable for children under age 3.



- This product contains magnetic material.
- Long-term exposure to loud music may cause hearing damage. It is best to avoid high volume levels when using headphones, especially for extended periods.
- See caution when using your headset/headphones while operating a vehicle or engaging in any activity that requires your full attention. Check and follow local laws regarding mobile phone and headset/headphones use. Some jurisdictions impose specific limitations, such as single earpiece conflouration on the use of such products while drivina.

CAUTIONS:

- Sounds that you rely on as reminders or warnings may have an unfamiliar character when using headphones. Be aware of how these sounds may vary in character so you can recognize them as needed.
- Do not drop, sit on, or allow the headset to be immersed in water.

Limited Warranty

Your Bose® MIE2 mobile headset is covered by a limited warranty. Details of the limited warranty are provided on the product registration card that is included in the cardon. Please refer to the card for instructions on how to register. Failure to register will not affect your limited warranty rights.

What you must do to obtain Limited Warranty service
Return the product, with proof of purchase from an authorized
Bose dealer, using the following procedures:

- Contact the Bose organization in your country/region (visit Global.Bose.com for contact information in your country/ region) for specific return and shipping instructions.
- Label and ship the product, freight prepaid, to the address provided by the Bose organization in your country.
- Place any necessary Return Authorization Number prominently on the outside of the carton. Cartons not bearing a Return Authorization Number, where required, will be refused.

BOSE CORPORATION

USA

The Mountain, Framingham, MA, 01701 888-757-9943 owners.Bose.com

Canada

9133 Leslie Street, Suite 120, L4B 4N1 800-905-2177 www.Bose.ca

Australia

Unit 3/2 Holker St.Newington NSW, 2127 1800 023 367 www.Bose.com.au

Belgique/Belgie

B-3700 Tongeren 012-390800 www.Bosebelgium.be

China

2203-2305 22F, West Gate Tower/1038 West Nanjing Road-MeiLongzhen Plaza, Shanghai, 200041 86-22-62713000 ext. 162 www.Bose.cn

Denmark

2605 Brondby 04343-7777 www.Bose.dk

Deutschland

D-61381 Friedrichsdorf 06172-71040 www.Bose.de

France

78100 Saint Germain en Laye 01-30616363 www.Bosefrance.fr

India

Shriram Bhartiya Kala Kendra, 1 Copernicus Marg, New Delhi, 100-001 91-11-2307-3825-3826-3827 www.Boseindia.com

Ireland

Castlebury Road, Carrickmacross, Co Monaghan 042-9671500 www.Bose ie

Download from Www Somanuals com, All Manuals Search And Download

Italia

Via della Magliana 876 Roma, 00148 06.60.292.555 www.Bose it

Japan

Karakida Center bldg., 1-53-9 Karakida, Tama-shi, Tokyo, 2060035 81-423-575250 www.Bose.co.jp

Mexico

Paseo de las Palmas # 405, 11000 52-55-52-02-35-45 FAX: 52-55-52-02-41-95 www.Bose.com.mx

Nederland

1135 GE Edam 0299-390111 www.Bose.nl

New Zealand

0800 501 511 www.Bose.co.nz

Norge

N-2213 Kongsvinger 62-82-15-60 www.Bose.no

Österreich

Wienerbergstrasse 7 (10.OG) 01-60404340 www.Bose.at

Schweiz

Hauptsrasse 134 061-9757733 www.Bose.ch

Sverige

S-43153 Mölndal 031-878850 www.Bose.se

United Kingdom

1 Ambley Green, Gillingham Business Park, Gillingham, Kent, ME8 ONJ 0780-741-4500 Info_uk@Bose.com

Hong Kong

Suite 1203, Midas Plaza, 1 Tai Yau Street, San Po Kong, Kowloon, Hong Kong (852) 21239000 support_hk@Bose.com

Finland

Kornetintie 6b Helsinki, 380 +358 10 778 6900 www.Bose.fi

Poland

ul. Woloska 12 Warszawa, 02-675 +48 (0)22-8522928 www.Bose.pl

World Wide Web

www.Bose.com www.Boseeurope.com





©2010 Bose Corporation, The Mountain, Framingham, MA 01701-9168 USA AM327410 Rev.00

Download from Www.Somanuals.com. All Manuals Search And Download.

Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com