& Cobra®

Cobra Electronics Corporation 6500 West Cortland Street Chicago, IL60707

If You Think You Need Service

For technical assistance, please call our Automated Help Desk which can assist you by answering the most frequently asked questions about Cobra products. (773) 889-3087

24 hours a day, 7 days a week.

A Consumer Service Representative can be reached through this same number 8:00 am
- 8:00 pm, Monday through Friday, CST.

Technical assistance is also available on-line in the Frequently Asked Questions (FAQ) section at www.cobraelec.com or by e-mail to productinfo@cobraelec.com

If you think you need service call 1.773.889.3087

"If your product should require fatory service please call Cobra first before sending your unit in. This will ensure the fastest turn-around time on your repair

You may be asked to send your unit to the Cobra factory. It will be necessary to furnish the following in order to have the product serviced and returned.

- 1. For Warranty Repair include some form of proof-of-purchase, such as a mechanical reproduction or carbon or a sales receipt. If you send the original receipt it cannot be returned.
- Send the entire product.
- 3. Enclose a description of what is happening with the unit. Include a typed or clearly print name and address of where the unit is to be returned.
- 4. Pack unit securely to prevent damage in transit. If possible, use the original packing material.
- 5. Ship prepaid and insured by way of a traceable carrier such as United Parcel Service (UPS) or First Class Mail: to avoid loss in transit to: Cobra Factory Service, Cobra Electronics Corporation,6500 W. Cortland St., Chicago, IL 60707.
- 6. If the unit is in warranty, upon receipt of your unit it will either be repaired or exchanged depending on the model. Please allow approximately 3 to 4 weeks before contacting us for status. If the unit is out of warranty a letter will automatically be sent informing you of the repair charge or replacement charge. If you have any questions, please call 1.773.889.3087 for


Cobra Electronics Corp.© 1998 Printed in Thailand

Part No. 480-269-P-001

&Cobra HH 34

Operating Instructions for your Cobra HH 34

Citizens Band 2-Way Handheld **CB Radio**



The CB Story

The Citizens Band lies between the shortwave broadcast and 10-meter Amateur radio bands and was established by law in 1949. The Class D twoway communications service was opened in 1959.

FCC Regulations

FCC regulations permit only "transmissions" (one party to another) rather than "broadcasts" (to a wide audience). Advertising is not allowed on CB Channels because it is considered "broadcasting."

FCC Warnings

Replacement or substitution of transistors, regular diodes or other parts of a unique nature, with parts other than those recommended by Cobra, may cause a violation of the technical regulations of Part 95 of the FCC Rules, or violation of Type Acceptance requirements of Part 2 of the Rules.

Citizens Band (CB) Radio operators are not required to obtain an FCC license to operate their CB equipment or provide station identification.

Nevertheless, an operator of a CB radio station is still required to comply with the communic ations act and with the rules of CB Radio Operation.

What's Included with Your HH 34

- High Efficiency Antenna
- 2 Removable Belt Clip
- 3. Wrist Strap
- 4 12 Volt Cigarette Lighter Plug



"Ingenious Products for Easier Communication."



Controls and Indicators

Our Thanks to You

1. BNC Antenna Connector

2. Squelch Control

3. On/Off Volume Control

4. Removable Belt Clip

5. 12 Volt DC Power Jack


6. Power Saver (HI/LOW) Switch


7. Channel Up/Down Key

8. PTT (Push To Talk) Key 9. Battery Chamber

10. LED Channel Display

TX(transmit)/
Batt (low battery) LED





Thank you for purchasing the Cobra HH 34 handheld CB. Properly used, this Cobra product will give you many years of reliable service.

Customer Support

Should you encounter any problems with the product or not understand its many features, please refer to this owner's manual. If, after referring to the manual, you still need help, call Cobra Customer Service at 773.889.3087.

Cobra Customer Serviæ

Live operators are available M-F 8:00 am - 8:00 pm CST at: 773.889.3087

Automated Technical Assistance available 24 hours a day, seven days a week.E-mail questions to: productinfo@cobraelec.com

Cobra on the World Wide Web: Frequently Asked Questions (FAQ) can be found on-line at: www.cobraelec.com





hh 34 manual layout.4 10/1/98 10:04 All Page 7

How to Use Your Cobra HH 34

Features	
FCC Regulations FCC Warnings Included Accessories Controls & Indicators Our Thanks to You Customer Support	1
FCC Regulations FCC Warnings Included Accessories Controls & Indicators Our Thanks to You Customer Support	A
FCC Warnings Included Accessories Controls & Indicators Our Thanks to You Customer Support	
Controls & Indicators Our Thanks to You Customer Support	
Our Thanks to You Customer Support	
Customer Support	A
	A
Operating Your HH 34	
Antenna	2
Belt Clip	3
Battery Installation	
Turning on Your CB	
Setting Squelch	4
Selecting a Channel	6
LED Display	7
Transmit/Receive	8
In Vehicle Use	1
Power Saver-HI/LOW	
How Your CB Can Serve You	
A Few Rules You Should Know	
Channel 9 Emergency Messages	.1:
CB 10 Codes	
Frequency Ranges	
HH 34 Specifications	1
Warranty Information	
Optional Accessories	
Order Form	
If You Think You Need ServiceBack Co)VE

Features of This Product

- 40 CB Channels
- Full 4 Watt RF Power
- Power Saver (HI/LOW)
- LED Channel Display
- High Efficiency Flexible Antenna
- BNC Antenna Connector
- TX Transmit Indicator

..20Back Cover Omni Directional Microphone



Operation Operation

Attach Antenna


Attach Antenna 1 Insert.




超阳34

8


2



Attach Belt Clip








 Slide belt clip up on rails of base until
 To remove belt clip, lift tab out and slide lift tab out and slide belt clip down.

Install Batteries



- Remove battery chamber cover.
- 2 *Install* batteries by polarity markings.
- 3 Replace cover.

Battery Installation

Ignoring polarity markings can cause damage to both the unit and the batteries.

The HH 34 requires 9'AA" alkaline or NiCad batteries (not included with the unit).

When batteries are low or need charging the TX/Batt LED will remain on. Replace alkaline batteries or recharge NiCad batteries.

3

Operation

Turning On

Setting Squelch

NOISE TO THE STORY OF STORY

Gate closed

Turning On

Rotate ON - OFF Volume Control @ clockwise.



Setting Squelch

Squelch is the "control gate" for incoming signals.



Turn volume up louder than normal.



2 Fully clockwise closes the "gate", allowing no incoming signals.



3 Fully counterclockwise opens the "gate" and all signals enter.



◆ To achieve the Desired Squelch Setting (DSS), turn the Squelch control counterclockwise until you hear noise. Now turn the control clockwise just until the noise stops. This is the DSS setting and only strong signals will enter.

Gate open

	G AT E O P E N
$x_{3}^{2}x_{2}^{2}x_{3}^{2}x$	⊴್> ■
NOISE THE FOR THE FOR	CCSncOor
0.5555 5(0.5555 5(0	2575 STCD
	011
WEAK SIGNALS	
	X5.
MEDIUM SIGNALS	
STRONG SIGNALS	

Gate set to Desired Squelch Setting (DSS)

STRONG SIGNALS	
MEDIU M SIGNALS	
WEAK SIGNALS	
<u>(,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,</u>	Н
NOISE THE STORY OF THE STORY	
	U

4

5

Operation


Select Channel

Select Channel

1 Turn power ON.

For higher channel, push △ UP arrow key.
 For lower Channel, push → DOWN arrow key.

For quick advance, push and hold arrow key(s).



Note

When switching from one chan-nel to another, squelch will need to be reset. See Setting Squelch on page 4.

6

LED Display

All needed information is displayed.





Note

TX/Batt Indicator

This LED will illuminate red when batteries are low and need recharging / replacement or when the PTT button is pushed and held (which means your unit is transmitting).

Download from Www.Somanuals.com. All Manuals Search And Download.

Operation


Your HH 34 is always ready to

receive incoming signals when the PTT button is released.

9

Transmit/Receive Transmit/Receive

8





● To transmit, push and hold PTT button.

While PTT button is pressed you cannot receive transmissions.



2 TX/BATT (transmit) indicator will illuminate red.





• Release PTT button to receive incoming transmissions.

Download from Www.Somanuals.com. All Manuals Search And Download.

How Your CB Can Serve You

In Vehicle Use

Note

Due to the characteristics of CB transmissions, it is neccesary to use an external car roof antenna (item #ATW 400) and a BNC adapter (#ATW 401) to receive optimal performance while in your vehicle. See Accessories section on page 19.

Note

DC/Power Cord is provided.

Power Saver-HI/LOW


Not

TX/BATT indicator will illuminate red when the batteries need recharging or replacement.

Note

Battery life is increased up to 50% while in Battery Save LOW Mode. This reduces power output to 1 watt.


In Vehicle Use



The HH 34 can be connected to your cigarette lighter with the provided car cord. This power connection does NOT charge the batteries.

Power Saver-HI/LOW

Reduces the power to 1 watt. This does not decrease the unit's ability to receive but does reduce the transmitting range.



To utilize Power Save slide switch to LOW.
 This mode will extend the unit's battery life.

· Warn of traffic problems

- · Provide weather and road data
- Provide help in event of an emergency
- Provide direct contact with home or office
- Assist police by reporting erratic drivers
- Get "local information" to find destination
- · Communicate with family and friends
- Suggest spots to eat and sleep
- Keep you alert while traveling

A Few Rules You Should Know

- A. Conversations cannot last more than 5 minutes with another station. A one minute break is required to let others use the channel.
- B. You cannot blast others off the air by use of illegally amplified transmitters or illegally high an tennas.
- C. You cannot use CB to promote illegal activities.
- D. Profanity is not allowed.
- E. You may not transmit music with a CB.
- F. Selling of merchandise and/or services is prohibited.

A Few Rules You Should Know

Auto Battery Save

Note

Auto Battery Save will not effect the receiving range of the HH 34.

Battery life is approximately 20 hours under normal use conditions.





How Your CB Can Serve You

How Your CB Can Serve You

Channel 9 Emergency Messages

Note

If no response on channel 9, try channels 19 or 14.

1. Set to channel 9 for emergencies

Be sure antenna is properly connected.

2. CB Distress Data

When transmitting an emergency, you should request a "REACT BASE" and provide the CB distress data (called CLIP):

C all Sign Identify yourself.
L ocation Be exact.
I njuries Number. Type. Trapped?
P roblem Give details and help needed

Transmit **CLIP** repeatedly so any monitor can assist.

The FCC gives these examples of permitted and prohibited messages for channel 9. These are only guidelines and not all-inclusive:

Permitted	Example Message
Yes	"Tornado sighted six miles north of town."
No	"Post number 10. No tornado sighted."
Yes	"Out of gas on I-95 at mile marker 211."
No	"Out of gas in my driveway."
Yes	"Four car accident on I-94 at Exit 11. Send police and ambulance."
No	"Traffic moving smoothly on I-94."
Yes	"Weather Bureau has issued thunderstorm warning. Bring sailboat into port."
No	"Attention motorists. Weather Bureau advises snow tomorrow will accumulate 4 to 6 inches."
Yes	"Fire in building at 539 Main, Evanston."
No	"Halloween patrol number 3. All quiet."





How Your CB Can Serve You

How Your CB Can Serve You

CB 10-Codes

	CB 10)-Codes	10.20	Time is up for contest
	Citizor	n Bands have adopted the "10-CODES" for	10-29 10-30	Time is up for contact Does not conform to FCC rules
		ard questions and answers. These codes	10-30	
		le quick and easy communication, especially	10-33	Emergency traffic Trouble at this station
		sy areas. Following are some of the more		
		ion codes and meanings:	10-35	Confidential information
	0.1.	Manadana	10-36	Correct time is
	Code	Meaning	10-37	Wrecker needed at
	10-1	Receiving poorly	10-38	Ambulance needed
	10-2	Receiving well	10-39	Message delivered
	10-3	Stop transmitting	10-41	Turn to channel
	10-4	OK,message received	10-42	Traffic accident at
	10-5	Relay message	10-43	Traffic tie up at
	10-6	Busy, stand by	10-44	Have a message for
	10-7	Out of service, leaving	10-45	All units within range please report
	10-8	In service, subject to call	10-50	Break channel
	10-9	Repeat message	10-60	What is next message number?
	10-10	Transmission completed standing by	10-62	Unable to copy. Use phone
	10-11	Talking too rapidly	10-63	Net directed to
	10-12	Visitors present	10-64	Net clear
	10-13	Advise weather/roads	10-65	Awaiting your next message/assignment
	10-16	Make pick up at	10-67	All units comply
	10-17	Urgent business	10-70	Fire at
	10-18	Anything for us?	10-71	Proceed, transmission in sequence
	10-19	Return to base	10-77	Negative contact
	10-20	My location is	10-81	Reserve hotel room for
	10-21	Call by phone	10-82	Reserve room for
	10-22	Report in person to	10-85	My address is
	10-23	Stand by	10-91	Talk closer to mic
	10-24 10-25	Completed last assignment Can you contact	10-93	Check my frequency on this channel
	10-25	Disregard last info	10-93	Give me a long count
	10-20	Moving to channel	10-94	Mission completed, all units secure
	10-27	Identify your station		Police needed at
	.0 20		10-200	rolice needed at
7.	7			






Frequency Ranges

HH34 Specifications

The COBRA HH34 transceiver represents one of the most advanced AM two-way radios used as a Class D station in the Citizens Radio Service. This unit features advanced Phase Lock Loop (PLL) circuitry providing complete coverage of all 40 CB channels.

CB Channel	Channel Freq. In MHz	CB Channel	Channel Freq. In MHz
1	26.965	21	27.215
2	26.975	22	27.225
3	26.985	23	27.255
4	27.005	24	27.235
5	27.015	25	27.245
6	27.025	26	27.265
7	27.035	27	27.275
8	27.055	28	27.285
9	27.065	29	27.295
10	27.075	30	27.305
11	27.085	31	27.315
12	27.105	32	27.325
13	27.115	33	27.335
14	27.125	34	27.345
15	27.135	35	27.355
16	27.155	36	27.365
17	27.165	37	27.375
18	27.175	38	27.385
19	27.185	39	27.395
20	27.205	40	27.405

OPERATING TEMPERATURE RANGE MICROPHONE INPUT VOLTAGE	CB - 26.965 TO 27.405 MHZ 0.005 % PLL (PHASE LOCK LOOP) SYNTHESIZER -30° C TO + 50° C ELECTRET, PUSH-TO-TALK 13.0V DC, INTERNAL BATTERIES, 13 OUT 13.8 VDC, EXTERNAL TYPE BNC
MODULATION	300 - 3000 HZ AT -6 DB . 50 OHMS,UNBALANCED
RECEIVER CB SENSITIVITY IF FREQUENCY	1 ST - 10.690 MHZ,2ND - 455 KHZ 500 - 100 M MAXIMUM AT 10 % DISTORTION 300 - 3000 HZ AT -6 DB GREATER THAN 60 DB 50 DB MIN. BUILT - IN



17

Limited Two Year Warranty

Optional Accessories



Cobra Electronics Corporation

6500 West Cortland Street Chicago, Illinois 60707 COBRA ELECTRONICS CORPORATION warrants that its COBRA CB Radios, and the component parts thereof, will be free of defects in workmanship and materials for period of two (2) years from the date of first consumer purchase. This warranty may be enforced by the first consumer purchaser, provided that the product is utilized within the LLSA.


COBRA will, without charge, repair or replace, at its option, defective CB radios, products or component parts upon delivery to the COBRA factory Service Department, accompanied by proof of the date of first consumer purchase, such as a duplicated copy of a sales receipt.

You must pay any initial shipping charges required to ship the product for warranty service, but the return charges will be at Cobra's expense, if the product is repaired or replaced under warranty.

Exclusions: This limited warranty does not apply: 1) to any product damaged by accident;2) in the event of misuse or abuse of the product or as a result of unauthorized alterations or repairs;3) if the serial number has been altered, defaced or removed;4) if the owner of the product resides outside the U.S.A.

All implied warranties, including warranties of merchantability and fitness for a particular pur pose are limited in duration to the length of this warranty. COBRA shall not be liable for any incidental, consequential or other damages; including, without limitation, damages resulting from loss of use or cost of installation.

Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above limitations may not apply to you.



You Can Find These Fine Accessories At Your Local Cobra CB Dealer

If you wish, you can order directly from Cobra.

Order by phone Call 1.773.889.3087

Call 1.773.889.3087 (Press 1 from the main menu) 8 a.m.-8 p.m. M-F CST.

Order by mail or fax

Please fill out order form on next page, and mail/fax directly to Cobra.







Accessory Order Form

hh 34 manual layout.4 10/1/98 10:04 (All) Page 26

Item#	Description	Cost Ea.	Qty.	Amount
CA-41	Long Range Antenna	\$25.95		
ATW-400	Magnetic Mount Weather Antenna	\$29.95		
CA-43	BNC/S0239 Antenna Adapter	\$5.95		
HA-BC	Replacement Belt Clip	\$4.95		
Prices subj	ect to change without notice.	Subtotal		
Fax Table Tax Table and 7% Cook Co. residents add .75% (7.75% total) Chicago residents add .75% (8.75% total)		(Tax if applicable) Shipping/handling Total		
				\$4.00

Indiana residents add 5% Michigan residents add 4 % Minnesota residents add 6% Ohio residents add 6 % Wisconsin residents add 5%

For credit card orders fill out order form and fax to:1.773.622.2269 or call 1.773.889.3087 (Press 1 from the main menu) 8:00 am - 8:00 pm,M-F, CST.

Please print clearly Name Address (No P.O. Box) City State Zip Telephone (___) Credit Card No. Exp. Date Customer Signature

Allow 4 to 6 weeks for delivery. Offer valid in Continental U.S.only.

Circle One: Visa MasterCard Discover





Free Manuals Download Website

http://myh66.com

http://usermanuals.us

http://www.somanuals.com

http://www.4manuals.cc

http://www.manual-lib.com

http://www.404manual.com

http://www.luxmanual.com

http://aubethermostatmanual.com

Golf course search by state

http://golfingnear.com

Email search by domain

http://emailbydomain.com

Auto manuals search

http://auto.somanuals.com

TV manuals search

http://tv.somanuals.com